

Clavinova®

CVP-709
CVP-705

Data List
Daten-Liste
Liste des données
Lista de datos
Lista de dados

Piano Types in the Piano Room..... 2
Klaviermodelle im Piano Room
Types de piano dans Piano Room
Tipos de pianos de Piano Room
Tipos de piano do Piano Room

Accompaniment Types in the Piano Room 3
Begleitungsarten im Piano Room
Types d'accompagnements dans Piano Room
Tipos de acompañamientos de Piano Room
Tipos de acompanhamento do Piano Room

Voice List 4
Voice-Liste
Liste des sonorités
Lista de voces
Lista de vozes

Mega Voice Map..... 30
Sound-Zuordnungen der Mega Voices
Carte des sonorités Mega Voice
Mapa de Mega Voice
Mapa de voz mega

Drum/key Assignment List..... 35
Liste der Tastenzuordnungen der Schlaginstrumente
Liste des affectations d'instrument de batterie/touche de clavier
Lista de asignación de teclas/batería
Lista de atribuições de bateria/tecla

Style List..... 43
Liste der Styles
Liste des styles
Lista de estilos
Lista de estilos

Chord Types Recognized in the Fingered Mode..... 49
Im Fingered-Modus erkannte Akkordarten
Types d'accords reconnus en mode Fingered
Tipos de acordes reconocidos en el modo Fingered (digitado)
Tipos de acorde reconhecidos no modo dedilhado

Effect Type List..... 50
Liste der Effektypen
Liste des types d'effet
Lista de tipos de efecto
Lista de tipos de efeito

Vocal Harmony Type List 59
Liste der Vocal-Harmony-Typen
Liste des types d'harmonies vocales
Lista de tipos de armonías vocales
Lista de tipos de harmonia vocal

Vocal Effect Type List..... 60
Liste der Gesangseffekt-Typen
Liste des types d'effets vocaux
Lista de tipos de efectos vocales
Lista de tipos de efeito vocal

Parameter Chart 61
Parametertabelle
Tableau des paramètres
Gráfico de parámetros
Gráfico de parâmetro

Piano Types in the Piano Room / Klaviermodelle im Piano Room / Types de piano dans Piano Room / Tipos de pianos de Piano Room / Tipos de piano do Piano Room

CVP-709

Voice Name
CFX Grand
Bösendorfer
Pop Grand
Upright Piano
Honky Tonk Upright
Suitcase Hard
Vintage EP
CP80 Studio
TX816 EP Bright

CVP-705

Voice Name
CFX Grand
Bösendorfer
Pop Grand
Upright Piano
Honky Tonk Upright
Suitcase EP
Vintage EP
CP80 Stage
Sweet DX

Accompaniment Types in the Piano Room / Begleitungsarten im Piano Room / Types d'accompagnements dans Piano Room / Tipos de acompañamientos de Piano Room / Tipos de acompanhamento do Piano Room

CVP-709

Style Name
Contemp Gtr Pop
Standard Piano Bld
Acoustic Gtr Ballad
Funky Shuffle
Swing Medium
Cool Jazz Waltz
Standard Waltz
Brazilian Bossa
Rumba Bolero
West Coast Beat
80s American Pop
70s Piano Hit
60s Big Hit
Vintage R&R
Easy 8Beat 1
6-8 Soul Ballad
Easy 8Beat 2
6-8 Ballad Rock
90s Piano Ballad
Smooth Ballad
MOR 16Beat
Easy Acoustic Bld
70s Cool Shuffle
Easy Country Pop
70s Country Swing
Standard Swing
Slow Country Pop
Country Pop Ballad
The Blues
Cool Jazz Club
Slow Jazz Ballad
Fast Jazz
Easy Waltz
Mod Broadway Bld
Cartoon Ballad
Standard Rumba
Cool Bossa
Bossa Slow
Bossa Fast
Samba Fast

CVP-705

Style Name
Contemp Gtr Pop
Standard Piano Bld
Acoustic Gtr Ballad
Funky Shuffle
Swing Medium
Cool Jazz Waltz
Standard Waltz
Brazilian Bossa
Rumba Bolero
West Coast Beat
80s American Pop
70s Piano Hit
60s Big Hit
Vintage R&R
Easy 8Beat 1
6-8 Soul Ballad
Easy 8Beat 2
6-8 Ballad Rock
90s Piano Ballad
Smooth Ballad
MOR 16Beat
Easy Acoustic Bld
70s Cool Shuffle
Easy Country Pop
70s Country Swing
Standard Swing
Slow Country Pop
Country Pop Ballad
The Blues
Cool Jazz Club
Slow Jazz Ballad
Fast Jazz
Easy Waltz
Mod Broadway Bld
Cartoon Ballad
Standard Rumba
Cool Bossa
Bossa Slow
Bossa Fast
Samba Fast

Voice List / Voice-Liste / Liste des sonorités / Lista de voces / Lista de vozes

CVP-709

Main Category: PIANO

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
VRM Piano	CFX Grand	108	0	0	VRM
	Bösendorfer	108	6	0	VRM
	Pop Grand	108	17	1	VRM
	Mellow Piano	108	18	0	VRM
	Studio Grand	108	30	0	VRM
	Themic Grand	108	6	1	VRM
	Bright Piano	108	16	1	VRM
	Ambient Piano	108	27	3	VRM
	Rock Piano	108	16	2	VRM
	Stage Piano	108	31	0	VRM
	Grand Piano 1octave	108	22	1	VRM
	Grand Piano 2octaves	108	23	1	VRM
	Cocktail Piano	108	28	3	VRM
Grand Piano	CFX Grand	0	122	0	Natural!
	Bösendorfer	104	18	0	Natural!
	Pop Grand	104	6	0	Natural!
	Mellow Piano	0	124	0	Natural!
	Studio Grand	104	19	0	Natural!
	Themic Grand	104	18	1	Natural!
	Bright Piano	0	123	0	Natural!
	Ambient Piano	104	19	3	Natural!
	Rock Piano	0	124	2	Natural!
	Stage Piano	104	20	0	Natural!
	Grand Piano 1octave	0	123	3	Natural!
	Grand Piano 2octaves	0	124	3	Natural!
	Cocktail Piano	104	20	3	Natural!
Upright Piano	Upright Piano	104	13	0	Natural!
	Pop Upright	104	13	1	Natural!
	70s Ballad Piano	104	14	0	Natural!
	Chill Out Piano	104	15	0	Natural!
	Honky Tonk Upright	104	13	3	Natural!
	Saloon Upright	104	14	1	Natural!
	Upright 1octave	104	14	3	Natural!
	Upright 2octaves	104	15	3	Natural!
Piano Layer	Superstar Grand	108	25	4	Natural!
	Imperial Ballad	108	26	4	Natural!
	CFX DX Layer	108	33	2	Natural!
	Bösendorfer DX Layer	108	34	2	Natural!
	MIDI Grand	104	2	2	Natural!
	MIDI Grand Pad	104	3	2	Natural!
	Grand Piano & Choir	108	25	0	Natural!
	Bright Grand Pad	104	8	0	Natural!
	Grand Piano & Strings	108	23	0	Natural!
	Grand Piano & Orchestra	104	12	0	Natural!
	Piano & EP 1	108	25	2	Natural!
	Piano & EP 2	108	26	2	Natural!
	Grand Pad Layer	108	32	2	Natural!
	Warm Grand Pad	108	24	0	Natural!
Electric Piano	Suitcase Hard	104	16	4	Cool!
	Suitcase Soft	104	7	4	Cool!
	Vintage EP	104	8	4	Cool!
	Suitcase Ballad	104	9	4	Cool!
	Suitcase Phaser	104	10	4	Cool!
	Suitcase Drive	104	11	4	Cool!
	Suitcase Tremolo	104	12	4	Cool!
	Suitcase Jazz	104	13	4	Cool!
	Suitcase Warmth	104	14	4	Cool!
	Vintage EP Drive	104	15	4	Cool!
	Suitcase EP	0	118	4	Cool!
	Vintage EP	0	116	4	Regular
	Electric Piano 1	0	119	4	Cool!
	Electric Piano 2	0	122	4	Natural!
	Stage EP	0	117	4	Regular
	Funky EP	0	123	4	Natural!

Main Category: PIANO

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
Electric Piano	Tremolo Suitcase EP	0	113	4	Cool!
	Tremolo Stage EP	0	124	4	Natural!
	Smooth Tine	0	119	5	Regular
	CP80 Studio	0	123	2	Natural!
	Magnetics	104	0	4	Regular
	CP80 Stage	0	113	2	Regular
	FM E.Piano	TX816 EP Bright	104	10	5
TX816 EP Mellow		104	11	5	Cool!
TX816 EP Warm		104	12	5	Cool!
Studio Ballad DX		104	9	5	Regular
Sparkle Stack		0	121	5	Cool!
Sweet DX		104	0	5	Cool!
Ballad DX		0	124	5	Cool!
DX Dynamics		0	123	5	Cool!
Ballad Bells		104	2	5	Cool!
Galaxy EP		0	114	4	Cool!
DX7 EP		0	122	5	Natural!
Dream DX		104	3	5	Cool!
Midnight DX		104	1	5	Cool!
Piano Sweeper		104	3	99	Regular
Pianosphere	104	19	88	Regular	
Clavi	Clavi	8	33	20	S.Art!
	Clavi Funk	8	34	20	S.Art!
	Clavi Drive	8	36	20	S.Art!
	Clavi Bright	0	112	7	Regular
	Clavi Warm	0	122	7	Natural!
	Wah Clavi	0	113	7	Regular
	Funk Clavi	0	123	7	Natural!
	Phase Clavi	0	115	7	Regular
	Harpisichord	Harpisichord 1	0	122	6
Harpisichord 2		8	32	112	S.Art!
Harpisichord 3		0	125	6	Natural!
Harpisichord Coupler		0	123	6	Natural!
Grand Harpischord		0	113	6	Live!
Harpisichord & Strings		0	124	6	Natural!

Main Category: ORGAN

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
Tonewheel Organ	Whiter Bars	8	32	29	S.Art!
	Curved Bars	0	121	16	Cool!
	All Bars Out	8	32	30	S.Art!
	Even Bars	0	111	16	Cool!
	Jazz Rotary	8	32	113	S.Art!
	Vintage Fast	0	127	16	Cool!
	Classic Bars	8	34	29	S.Art!
	Scanner Jazz	0	118	18	Cool!
	Rock Rotary	8	33	113	S.Art!
	Organ-a-Go-Go	104	0	16	Cool!
	Prog Rock Organ	8	33	29	S.Art!
	Organ Accomp 1	0	108	17	Regular
	R&B Tremolo	0	111	18	Cool!
	Organ Accomp 2	0	107	17	Regular
	Classic Jazz	0	117	16	Cool!
	Organ Accomp 3	0	106	17	Regular
	Hold It Fast	0	111	17	Cool!
	Organ Accomp 4	0	105	17	Regular
	Full Rocker	0	115	18	Cool!
	Organ Accomp 5	0	104	17	Regular
	Whiter Bars Slow	104	1	17	Cool!
	Whiter Bars Fast	104	0	17	Cool!
	Jazz Organ Slow	0	126	17	Cool!
	Jazz Organ Fast	0	127	17	Cool!

CVP-709

Main Category: ORGAN

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
Tonewheel Organ	All Bars Out Slow	104	1	18	Cool!
	All Bars Out Fast	104	0	18	Cool!
	All Bars Phase	104	2	18	Cool!
	Rotor Organ	0	117	18	Cool!
	Mellow Drawbar	0	115	17	Regular
	Two Channels Organ	0	109	17	Cool!
Transistor Organ	60s Combo 1	104	32	16	Cool!
	60s Combo 2	104	33	16	Cool!
	60s Combo 3	104	34	16	Cool!
	60s Combo 4	104	35	16	Cool!
	Euro Organ	0	118	16	Regular
Classical Pipe	Lieblich Gedackt	104	6	19	Regular
	Diapason	104	4	19	Regular
	Claribel 8' & Flute 4'	104	5	19	Regular
	Soft Reeds	104	7	19	Regular
	Grand Jeu	104	1	19	Live!
	Fonds Et Anches	104	2	19	Live!
	Organo Pleno	104	3	19	Live!
	Tutti	104	0	19	Live!
	Full Organ	0	112	19	Regular
	Pipe Organ 8'	0	124	19	Natural!
	Pipe Organ Principal	0	123	19	Natural!
	Chapel Organ	0	113	19	Regular
	Pipe Organ Twelfth	0	125	19	Natural!
	Hymn Organ	0	114	19	Regular
	Pipe Organ Tutti 1	0	126	19	Natural!
	Church Organ	0	115	19	Regular
	Pipe Organ Tutti 2	0	122	19	Natural!
	Theatre Pipe	Full Theatre	0	127	18
Tibia 8'		104	6	17	Regular
Sweet Theatre		0	126	18	Regular
Tibia 8'&4'		104	9	16	Regular
Ballroom Organ		0	115	3	Regular
Tibia 16'&4'		104	8	16	Regular
Tibia Chorus		104	5	17	Regular
Vox Humana 8'		104	7	17	Regular
Vox Humana & Tibia		104	10	16	Regular
Theatre Trumpet 8'		0	124	16	Regular
Theatre Kinura 8'		0	123	16	Regular
Theatre Trumpet & Kinura		0	125	17	Regular
Theatre Trumpet 16'&8'		0	124	17	Regular
Organ Flutes		Organ Flutes	10	0	8
	USD Smile	10	1	8	OrganFlutes
	Reggae Bars	10	2	8	OrganFlutes
	Warm Theatre	10	3	8	OrganFlutes
	Organ Pops	10	4	8	OrganFlutes
	Rock Organ	10	5	8	OrganFlutes
	Soul Percussion	10	6	8	OrganFlutes
	Gospel Truth	10	7	8	OrganFlutes
	Pad Organ	10	8	8	OrganFlutes
	Full Organ	10	9	8	OrganFlutes
	String Bars	10	0	9	OrganFlutes
	Latin Spin	10	1	9	OrganFlutes
	Shady Bars	10	2	9	OrganFlutes
	Funk Organ	10	3	9	OrganFlutes
	Ballad Organ	10	4	9	OrganFlutes
	Rich Bars	10	5	9	OrganFlutes
	Trumpet Bars	10	6	9	OrganFlutes
	Soul Bars	10	7	9	OrganFlutes
	Clari Bars	10	8	9	OrganFlutes
	Jazz Squabble	10	9	9	OrganFlutes
	Euro Perc	10	0	10	OrganFlutes
	Ballad Euro	10	1	10	OrganFlutes
	Euro Reeds	10	2	10	OrganFlutes

Main Category: ORGAN

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
Organ Flutes	Even Warmth	10	3	10	OrganFlutes
	Bright Euro	10	4	10	OrganFlutes
	Euro Accomp 1	10	7	10	OrganFlutes
	Full Euro	10	6	10	OrganFlutes
	Euro Accomp 2	10	8	10	OrganFlutes
	Euro Pops	10	5	10	OrganFlutes
	Euro Accomp 3	10	9	10	OrganFlutes
	Harmonica	Harmonica	8	64	104
Blues Harp		8	65	104	S.Art2!
Harmonica		0	112	22	Sweet!
Accordion	Full Accordion Register	104	2	21	Regular
	French Musette Acc.	0	119	21	Regular
	Master Accordion	0	118	21	Regular
	Steirische	0	117	21	Regular
	Jazz Accordion	0	120	21	Regular
	Cassotto	104	0	21	Regular
	Cajun	104	3	21	Regular
	Accordion Clarinet	104	1	21	Regular
	Bandoneon	0	113	23	Regular
	Tango Accordion	0	114	23	Regular
	Full Register Bass	104	5	21	Regular
	Musette Bass	0	123	21	Regular
	Master Bass	0	122	21	Regular
	Cajun Bass	104	6	21	Regular
	Accordion Bass	0	121	21	Regular
Tango Bass	0	115	23	Regular	

Main Category: GUITAR&BASS

Sub Category 1	Voice Name	Voice Number			Voice Type	
		MSB	LSB	Prg		
Nylon Acoustic	Flamenco Guitar	8	35	1	S.Art!	
	Spanish Guitar	8	34	1	S.Art!	
	Spanish Electro Acoustic	8	36	1	S.Art!	
	Slide Spanish Guitar	104	9	25	Live!	
	Concert Guitar	8	32	0	S.Art!	
	Dynamic Nylon	0	116	24	Live!	
	Hard Flamenco	0	118	24	Live!	
	Nylon Guitar	8	34	0	S.Art!	
	Classical Guitar	0	115	24	Live!	
	Slide Nylon	0	117	24	Live!	
	Nylon Mute	0	119	24	Live!	
	Electro Acoustic Guitar	8	35	0	S.Art!	
	Steel Acoustic	Steel Acoustic Guitar	8	37	1	S.Art!
		Steel Acoustic Strum	104	10	25	Live!
Steel Guitar Twin 1		104	12	25	Live!	
Steel Guitar Twin 2		104	13	25	Live!	
Chicken Pick Guitar		104	11	25	Live!	
12String Guitar Twin		8	39	1	S.Art!	
Chicken Pick Switch		8	38	1	S.Art!	
12String Strumming		8	40	1	S.Art!	
Steel Guitar		8	32	1	S.Art!	
Slide Steel		0	118	25	Live!	
Folk Guitar Harmonics		8	33	1	S.Art!	
Dynamic Steel		0	116	25	Live!	
Steel Guitar Strum		0	117	25	Live!	
Steel Guitar Mute		0	120	25	Live!	
12String Guitar	0	113	25	Live!		
Clean Solid	Shadowed Guitar	8	56	3	S.Art!	
	Oldies Guitar	8	52	5	S.Art!	
	Vintage Short Delay	8	48	5	S.Art!	
	Finger Slap Slide	8	51	3	S.Art!	
	Rough Fingers	8	39	4	S.Art!	
	Clean Fingers	8	38	4	S.Art!	

CVP-709**Main Category: GUITAR&BASS**

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
Clean Solid	Country Pick Drive	8	40	4	S.Art!
	Country Pick Vintage	8	41	4	S.Art!
	Pure Vintage	8	42	5	S.Art!
	Bluesy Fingers	8	37	4	S.Art!
	Jazz Combo	8	54	5	S.Art!
	Finger Chorus	8	42	3	S.Art!
	Warm Solid	8	33	3	S.Art!
	Single Coil Clean	8	39	3	S.Art!
	Clean Solid	8	34	3	S.Art!
	Bright Chorus	8	45	3	S.Art!
	Vintage Slap	8	48	3	S.Art!
	Ballad Delay	8	46	3	S.Art!
	Vintage Pure	8	47	3	S.Art!
	Jazz Vintage	8	38	6	S.Art!
	Jazz Artist	8	39	6	S.Art!
	Finger Bright	8	50	3	S.Art!
	Slide Clean	0	117	28	Cool!
	Warm Electric	8	32	3	S.Art!
	Slide Warm	104	6	27	Cool!
	Clean Electric	8	35	3	S.Art!
	Slide Pick	104	7	27	Cool!
	Jazz Clean	8	32	6	S.Art!
	Country Pick	8	44	3	S.Art!
	Jazz Solo Guitar	0	116	26	Cool!
	Semi Acoustic	8	33	6	S.Art!
	Electric Guitar	0	114	28	Cool!
	Chorus Solid	0	107	27	Cool!
	Dynamic Mute	0	118	28	Cool!
	Slide Solid	0	110	27	Cool!
	Cool Wah Guitar	104	4	27	Regular
	Slap Solid	0	108	27	Cool!
	Slapback	104	0	27	Cool!
	Light Chorus	8	53	3	S.Art!
	Funk Slap	8	49	3	S.Art!
	Smooth Jazz Guitar	8	35	6	S.Art!
	Slide Finger	104	5	27	Cool!
	Lounge Guitar	104	1	26	Regular
	Vintage Muted Guitar	104	0	28	Cool!
	Vintage Spring	8	54	3	S.Art!
	Vintage Muted Echo	0	115	28	Regular
	Vintage Open	0	123	27	Regular
	Vintage Strum	0	126	27	Regular
	Funk Guitar	0	116	28	Cool!
	70s Solid Guitar	8	38	3	S.Art!
	Slide Jazz	104	0	26	Cool!
	Jazz Guitar	0	115	26	Cool!
	Clean Guitar	0	112	27	Cool!
	60s Clean	0	117	27	Regular
	Tremolo Solid	0	111	27	Cool!
	Muted Guitar	0	119	28	Cool!
	Ballad Solid	0	109	27	Cool!
	Octave Guitar	0	113	26	Regular
	Distortion Solid	Solo King	8	50	5
Rhythm King		8	53	5	S.Art!
Vintage Distortion Full		8	43	5	S.Art!
Vintage Distortion Solo		8	44	5	S.Art!
Vintage Distortion Stage		8	45	5	S.Art!
Vintage Heavy		8	47	5	S.Art!
Vintage Overdrive Wah		8	46	5	S.Art!
Rock Hero		8	35	5	S.Art!
Stage Lead		8	38	5	S.Art!
Grunge Guitar		8	40	5	S.Art!
Big Combo		8	51	5	S.Art!
Vintage Warm Drive		8	49	5	S.Art!

Main Category: GUITAR&BASS

Sub Category 1	Voice Name	Voice Number			Voice Type	
		MSB	LSB	Prg		
Distortion Solid	Overdrive Wah	8	39	5	S.Art!	
	Vintage Amp	8	41	3	S.Art!	
	Rock Legend	8	34	5	S.Art!	
	Finger Amp	8	43	3	S.Art!	
	Vintage Rock	8	36	5	S.Art!	
	Slide Pick Amp	104	8	27	Cool!	
	Guitar Hero	8	32	5	S.Art!	
	Half Drive	8	37	3	S.Art!	
	Blues Slap Slide	8	36	4	S.Art!	
	Classic Stack	8	41	5	S.Art!	
	Vintage Blues	8	37	5	S.Art!	
	Crunch Guitar	8	33	5	S.Art!	
	Blues Warm	8	34	4	S.Art!	
	Heavy Rock	8	32	4	S.Art!	
	Bluesy Night	8	55	3	S.Art!	
	Stereo Rock	104	2	30	Cool!	
	Blues Bright	8	35	4	S.Art!	
	Feedbacker	8	33	4	S.Art!	
	Power Lead	0	115	30	Cool!	
	Vintage Amp	0	115	29	Regular	
	Metal Master	0	120	30	Regular	
	Vintage Lead	0	125	27	Cool!	
	Crunch Guitar	0	113	30	Regular	
	Blues Guitar	0	117	29	Cool!	
	Heavy Stack	0	114	30	Regular	
	World	Pedal Steel Amp	8	52	3	S.Art!
		Mandolin	0	114	25	Sweet!
Pedal Steel		8	36	3	S.Art!	
Zither 1		104	1	15	Regular	
Banjo		104	0	105	Regular	
Zither 2		104	0	15	Regular	
Shamisen		0	112	106	Regular	
Dulcimer		0	112	15	Regular	
Koto		0	112	107	Regular	
Hackbrett		104	2	46	Regular	
Aloha Guitar		0	118	26	Regular	
Sitar	104	0	104	Regular		
Pedal Steel	0	115	27	Regular		
Bass	Vintage Round Bass	8	32	17	S.Art!	
	Acoustic Bass	8	32	16	S.Art!	
	Vintage Flatwound Bass	8	33	17	S.Art!	
	Soft Acoustic Bass	8	33	16	S.Art!	
	Vintage Mute Bass	8	32	18	S.Art!	
	Acoustic Bass & Cymbal	0	114	32	Regular	
	Vintage Pick Bass	104	1	34	Regular	
	Fusion Bass	0	113	36	Regular	
	Fretless Bass	8	32	19	S.Art!	
	Slap Bass	0	112	36	Regular	
	Vintage Round Bass	104	1	33	Cool!	
	Soft Acoustic Bass	104	2	32	Regular	
	Vintage Flatwound Bass	104	2	33	Cool!	
	Acoustic Bass	104	1	32	Regular	
	Vintage Mute Bass	104	3	33	Cool!	
	Ballroom Bass	104	0	32	Regular	
	Vintage Pick Mute Bass	104	0	34	Cool!	
	Half Mute Bass	0	115	33	Cool!	
	Fretless Bass	0	112	35	Cool!	
	Vintage Dyno Bass	104	2	34	Cool!	
	Rock Bass	0	114	34	Regular	
	Electric Bass	0	114	33	Cool!	
	Pick Dyno Bass	0	113	34	Cool!	
Mellow Finger Bass	0	112	33	Regular		
Super Fretless Bass	0	113	35	Regular		

CVP-709

Main Category: GUITAR&BASS

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
Bass	Pick Bass	0	112	34	Regular
	Funk Bass	0	112	37	Regular
Synth Bass	BPF Buzz	8	32	122	S.Art!
	Wobble (Pedal)	8	33	122	S.Art!
	Ramp Bass (Pedal)	8	34	122	S.Art!
	Square Pluck (Pedal)	8	35	122	S.Art!
	Deep Sub (Pedal)	104	18	87	Regular
	Modern Pop	104	19	87	Regular
	Multi Saw Bass	104	20	87	Regular
	Brite Dub Bass	104	21	87	Regular
	Pulse & Saw	104	22	87	Regular
	Twenty Five	104	23	87	Regular
	Punchy Square	104	24	87	Regular
	Softwood	104	25	87	Regular
	Punchy DX	104	26	87	Regular
	Dark Sequence Bass	104	27	87	Regular
	Pumping Saw	104	28	87	Regular
	Pumping Square	104	29	87	Regular
	Lo Bass	104	0	39	Regular
	Fat Pulse	104	2	39	Regular
	Dark Bass	104	1	39	Regular
	Wazzo Saw	104	3	80	Regular
	Moon Bass	104	0	38	Regular
	Deep Point	104	3	38	Regular
	Kick Bass	104	1	38	Regular
	Tight Bass	104	3	39	Regular
	Club Bass	104	2	38	Regular
	Competitor	104	4	38	Regular
	1o1 Sub	104	5	38	Regular
	Trance Bass	104	9	38	Regular
	Little Bass Synth	104	6	38	Regular
	Sub Cut Bass	104	5	39	Regular
	Tekno Bass	104	7	38	Regular
	Dyno Acid Bass	104	10	38	Regular
	Perc Punch	104	8	38	Regular
	Mini Sub	104	6	39	Regular
Square Bass	104	4	39	Regular	
Fat Sine Resonance	104	11	38	Regular	
Ballad Bass	104	7	39	Regular	
House Bass	0	116	38	Regular	
Velo Master	104	17	81	Regular	
Big Drone	0	118	38	Regular	
Sub Bass	0	114	39	Regular	
Hard Bass	0	114	38	Regular	
Resonance Bass	0	112	38	Regular	
TB Bass	0	117	39	Regular	

Main Category: STRINGS&VOCAL

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
String Solo	Jazz Violin	8	64	48	S.Art2!
	Classic 1st Violin	8	33	43	S.Art!
	Celtic Violin	8	65	48	S.Art2!
	Classic 2nd Violin	8	33	44	S.Art!
	Viola	0	112	41	Regular
	Classic Viola	8	33	45	S.Art!
	Cello	0	122	42	Natural!
	Classic Cello	8	33	46	S.Art!
	String Quartet	8	34	47	S.Art!
	Contrabass	0	112	43	Regular
	Violin	0	113	40	Sweet!
	Fiddle	0	112	110	Regular

Main Category: STRINGS&VOCAL

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
String Solo	Solo Violin	0	112	40	Regular
	Cello	0	112	42	Regular
String Ensemble	Romance Strings	8	43	49	S.Art!
	Pizzicato	0	113	45	Live!
	Concert Strings	8	32	49	S.Art!
	Real Tremolo Strings	104	0	44	Live!
	Broadway Strings	8	38	48	S.Art!
	Real Spiccato	104	6	48	Live!
	Chamber Strings	8	42	48	S.Art!
	Real String Pad	8	43	48	S.Art!
	Real Strings	8	33	49	S.Art!
	Classical Strings	8	36	48	S.Art!
	Real 1st Violins	8	32	43	S.Art!
	Classic 1st Violins	8	34	43	S.Art!
	Real 2nd Violins	8	32	44	S.Art!
	Classic 2nd Violins	8	34	44	S.Art!
	Real Violas	8	32	45	S.Art!
	Classic Violas	8	34	45	S.Art!
	Real Cellos	8	32	46	S.Art!
	Classic Cellos	8	34	46	S.Art!
	Real Contrabasses	8	32	47	S.Art!
	Spiccato	0	120	48	Live!
	Theatre Strings	8	37	48	S.Art!
	Lush Strings	8	41	48	S.Art!
	Ballroom Strings	8	35	49	S.Art!
	Studio Strings	8	32	48	S.Art!
	Strings	0	122	48	Natural!
	Movie Strings	0	123	48	Live!
	Disco Strings 1	0	123	49	Live!
	Ballad Strings	8	34	49	S.Art!
	Disco Strings 2	0	124	49	Live!
	Warm Strings	8	39	48	S.Art!
	Tremolo Strings	0	113	44	Live!
	Big Strings	8	40	48	S.Art!
	Spiccato	8	33	48	S.Art!
	Strings	0	117	49	Live!
Real Strings f	8	40	49	S.Art!	
Allegro	0	122	49	Live!	
Real Strings mf	8	41	49	S.Art!	
Dynamic Strings	0	124	48	Live!	
Real Strings p	8	42	49	S.Art!	
Chamber Strings	0	112	49	Regular	
Real Tremolo Sforzando	104	1	44	Live!	
Tremolo Bowing	8	34	48	S.Art!	
Strings f	0	119	48	Live!	
Real Strings f	104	4	49	Live!	
Strings mf	0	118	48	Live!	
Real Strings mf	104	5	49	Live!	
Strings p	0	117	48	Live!	
Real Strings p	104	6	49	Live!	
Orchestral Layers	Horns & Strings	8	38	49	S.Art!
	Symphonic Unison	104	0	49	Regular
	Tutti	0	120	49	Regular
	Theatre Orchestra	104	1	49	Regular
	Pizzicato Glocken	0	115	45	Live!
Pop Vocals	Haa	8	32	39	S.Art!
	Doo	8	38	40	S.Art!
	Wah	8	38	39	S.Art!
	Yoo	8	42	40	S.Art!
	Baa	8	41	39	S.Art!
	Ooh Boys	8	34	40	S.Art!
	Daa	8	45	39	S.Art!
	Ooh Girls	8	36	40	S.Art!
	Ooh	8	32	40	S.Art!

CVP-709**Main Category: STRINGS&VOCAL**

Sub Category 1	Voice Name	Voice Number			Voice Type	
		MSB	LSB	Prg		
Pop Vocals	Pop Vocal Ensemble	8	40	55	S.Art!	
	Haa Vibrato	8	33	39	S.Art!	
	Doo Vibrato	8	39	40	S.Art!	
	Wah Vibrato	8	39	39	S.Art!	
	Yoo Vibrato	8	43	40	S.Art!	
	Baa Vibrato	8	42	39	S.Art!	
	Ooh Boys Vibrato	8	35	40	S.Art!	
	Daa Vibrato	8	46	39	S.Art!	
	Ooh Girls Vibrato	8	37	40	S.Art!	
	Ooh Vibrato	8	33	40	S.Art!	
	Bee Vibrato	104	4	52	Live!	
	Haa	104	9	52	Live!	
	Doo	104	16	53	Live!	
	Wah	104	10	52	Live!	
	Yoo	104	18	53	Live!	
	Baa	104	12	52	Live!	
	Doo Boys	8	40	40	S.Art!	
	Daa	104	13	52	Live!	
	Doo Girls	8	41	40	S.Art!	
	Ooh	104	17	53	Live!	
	Hoo Wah	8	39	55	S.Art!	
	Aah-Ooh Auto	8	49	40	S.Art!	
	Soft Wah	8	40	39	S.Art!	
	Accomp Aah	104	15	52	Live!	
	Haa Boys	8	34	39	S.Art!	
	Accomp Ooh	104	15	53	Live!	
	Haa Girls	8	35	39	S.Art!	
	Mmh	0	117	52	Live!	
	HooWee Auto	8	56	55	S.Art!	
	Jazz Vocals	Shoo-Bee-Doo-Bah 1	8	32	55	S.Art!
		DoBeDoBe	8	48	55	S.Art!
		Shoo-Bee-Doo-Bah 2	8	47	55	S.Art!
		YaBaDaBa	8	51	55	S.Art!
BaDaYah		8	36	55	S.Art!	
Who Are You?		8	54	55	S.Art!	
What Should We Do?		8	53	55	S.Art!	
DoWeYoBe		8	52	55	S.Art!	
ShooBeeDynamic		8	35	55	S.Art!	
ShooBaDooBa		8	55	55	S.Art!	
Scat Vocalists		8	42	55	S.Art!	
Latin Vocals		8	41	55	S.Art!	
Jazz Singers Shoo		8	45	55	S.Art!	
Baroque Scat		8	43	55	S.Art!	
Jazz Singers Dwee		8	46	55	S.Art!	
Scatman Legato		8	50	55	S.Art!	
Gospel Choir		Gospel Hmm	8	32	54	S.Art!
	Wow Hey Hmm	8	35	54	S.Art!	
	Gospel Wow	8	33	54	S.Art!	
	Gospel Hmm	104	12	53	Live!	
	Gospel Hey	8	34	54	S.Art!	
	Gospel Wow	104	13	53	Live!	
	Gospel Hmm Aah (Pedal)	8	36	54	S.Art!	
	Gospel Hey	104	7	52	Live!	
	Gospel Wow Hey (Pedal)	8	37	54	S.Art!	
Classical Choir	Boys Choir Ooh	8	32	51	S.Art!	
	Boys Choir Aah	8	33	51	S.Art!	
	Soft Choir Ooh	8	35	51	S.Art!	
	Soft Choir Aah	8	36	51	S.Art!	
	Boys Choir Oh-Ah (Pedal)	8	34	51	S.Art!	
	Boys Choir Oh-Ah	8	49	55	S.Art!	
	Choir	0	122	52	Natural!	
	Choir & Organ	0	123	52	Natural!	
	Gothic Vox	0	113	53	Regular	

Main Category: BRASS&WOODWIND

Sub Category 1	Voice Name	Voice Number			Voice Type	
		MSB	LSB	Prg		
Brass Solo	Mute Trumpet	8	64	64	S.Art2!	
	Trumpet	8	66	65	S.Art2!	
	Big Band Trumpet	8	67	65	S.Art2!	
	Trombone	8	65	73	S.Art2!	
	Jazz Trumpet	8	64	65	S.Art2!	
	Classic Trumpet	8	65	65	S.Art2!	
	Bright Trumpet	8	32	64	S.Art!	
	Cornet	0	119	56	Sweet!	
	Silver Trumpet	8	33	64	S.Art!	
	Muted Trumpet	0	114	59	Sweet!	
	Golden Trumpet	8	34	64	S.Art!	
	Flugel Horn	0	118	56	Sweet!	
	Big Band Trumpet	8	37	64	S.Art!	
	Trombone	0	117	57	Sweet!	
	Trumpet Fall	8	38	64	S.Art!	
	Trumpet	0	115	56	Sweet!	
	Trumpet Shake	8	35	64	S.Art!	
	Mellow Trumpet	0	120	56	Sweet!	
	Silver Trumpet	0	121	56	Sweet!	
	Muted Cornet	104	0	59	Sweet!	
	Golden Trumpet	0	122	56	Sweet!	
	Baritone Horn	0	113	58	Regular	
	Tuba	104	0	58	Regular	
	Bright Trombone	104	0	57	Sweet!	
	Baritone Hit	0	114	58	Regular	
	Alp Bass	0	113	33	Regular	
	Brass Ensemble	Orchestral Trumpets	104	3	56	Live!
		Orchestral Trombones	104	3	57	Live!
		Orch Trumpets & Trombones 1	104	9	61	Live!
		Orch Trumpets & Trombones 2	104	10	61	Live!
		Symphony Horns 1	104	1	60	Live!
		Orch Octave Brass	104	12	61	Live!
		Symphony Horns 2	104	2	60	Live!
Warm Horns		8	33	60	S.Art!	
Symphony Horns 3		104	8	61	Live!	
Stopped Horns		104	3	60	Live!	
Pop Horns Dynamic		104	0	61	Live!	
Pop Horns Dynamic Shake		104	4	61	Live!	
Pop Horns Mellow		8	43	56	S.Art!	
Pop Horns Bright		8	44	56	S.Art!	
Pop Horns Accent		104	3	61	Live!	
Pop Horns Cresc		104	5	61	Live!	
Horns Fall Doit (Pedal)		8	46	56	S.Art!	
Horns Falls (Pedal)		8	47	56	S.Art!	
Swing Horns Warm		104	1	61	Live!	
Swing Horns Mute		104	2	61	Live!	
Orch Trumpets Fast		104	4	56	Live!	
Orch Trombones Fast		104	4	57	Live!	
Orch Horns Fast		104	4	60	Live!	
Orch Horns & Trombones		104	13	61	Live!	
Symphony Horns Fast		104	15	61	Live!	
Orch Horn Pad		104	11	61	Live!	
Warm Horns Section		8	41	56	S.Art!	
Bright Horns Section		8	42	56	S.Art!	
Ballad Brass		104	6	61	Live!	
Colliery Band		104	14	61	Live!	
Horns		104	0	60	Live!	
Big Band Brass		8	37	56	S.Art!	
Soft Horns		8	32	60	S.Art!	
Smooth Brass	8	36	56	S.Art!		
Dynamic Brass	0	127	61	Live!		
Power Brass	0	121	62	Live!		

CVP-709

Main Category: BRASS&WOODWIND

Sub Category 1	Voice Name	Voice Number			Voice Type	
		MSB	LSB	Prg		
Brass Ensemble	Accent Brass	0	109	61	Live!	
	Brass Falls f	8	34	56	S.Art!	
	Muted Horns	8	34	60	S.Art!	
	Brass Falls mf	8	35	56	S.Art!	
	Brass f	0	108	61	Live!	
	Brass Band	0	123	56	Live!	
	Brass mf	0	110	61	Live!	
	Soft Horns	0	117	60	Live!	
	Brass p	0	111	61	Live!	
	Soft Trombones	0	118	60	Live!	
	Brass Shake	8	32	56	S.Art!	
	Pop Brass	0	117	62	Live!	
	Accent Falls	8	38	56	S.Art!	
	Hyper Brass	0	118	62	Live!	
	Sforzando	0	105	61	Live!	
	Small Brass	0	120	60	Live!	
	Sforzando Fall	0	107	61	Live!	
	Ballroom Brass	0	113	59	Regular	
	Brass Dynamics	0	106	61	Live!	
	Octave Brass	0	116	62	Live!	
Sax Solo	Tenor Sax	8	66	80	S.Art2!	
	Jazz Tenor Sax	8	65	80	S.Art2!	
	Pop Soprano	8	64	84	S.Art2!	
	Breathy Tenor Sax	8	64	80	S.Art2!	
	Ballad Soprano	8	65	84	S.Art2!	
	Saxophone	8	32	82	S.Art!	
	Alto Sax	8	32	66	S.Art!	
	Big Band Sax	8	35	82	S.Art!	
	Soft Alto Sax	8	34	66	S.Art!	
	Rock Sax	8	33	82	S.Art!	
	Growl Sax	0	111	66	Sweet!	
	Soprano Sax	0	113	64	Sweet!	
	Pop Tenor Sax	0	127	66	Sweet!	
	Pop Alto Sax	104	0	65	Sweet!	
	Ballad Tenor Sax	0	126	66	Sweet!	
	Breathy Tenor Sax	0	117	66	Sweet!	
	Jazz Tenor Sax	0	125	66	Sweet!	
	Baritone Sax	104	0	67	Regular	
Sax Ensemble	Sax Section Fast Attack	0	116	66	Live!	
	Big Band Octave	0	108	66	Live!	
	Sax Section Unison	8	38	82	S.Art!	
	Big Band Unison	0	109	66	Live!	
	Sax Section	8	36	82	S.Art!	
	Big Band Saxes	0	110	66	Live!	
	Sax Section Octave	8	37	82	S.Art!	
	Ballad Section	0	119	66	Regular	
	Soft Saxes	8	39	82	S.Art!	
	Sax Appeal	0	123	66	Live!	
	Sax Section Hard	0	122	66	Live!	
	Moonlight	0	115	71	Regular	
	Sax Section Soft	0	121	66	Live!	
	Woodwind Solo	Classical Flute	8	64	74	S.Art2!
		Jazz Flute	8	65	74	S.Art2!
Clarinet		8	65	92	S.Art2!	
Orchestral Flute		8	32	73	S.Art!	
Romance Clarinet		8	66	92	S.Art2!	
Jazz Flute		0	114	73	Sweet!	
Ballad Clarinet		8	64	92	S.Art2!	
Orchestral Oboe		8	32	68	S.Art!	
Orchestral Clarinet		104	0	71	Live!	
Jazz Clarinet		0	114	71	Sweet!	
German Clarinet		104	2	71	Regular	
Orchestral Bassoon		104	0	70	Sweet!	
Classical Flute		0	115	73	Sweet!	

Main Category: BRASS&WOODWIND

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
Woodwind Solo	Classical Oboe	0	113	68	Sweet!
	Piccolo	0	112	72	Regular
	English Horn	0	112	69	Regular
Woodwind Ens	Flutes & Oboes	104	2	73	Regular
	Orchestral Woodwind	104	1	70	Regular
	Clarinet & Flutes	104	1	71	Regular
	Alto Flutes	104	1	73	Regular
	Clarinet & Oboe	104	1	68	Regular
	Flute Ensemble	0	116	73	Regular
	Oboe & Bassoon	104	2	68	Regular
Woodwind World	Irish Pipe Air	8	64	108	S.Art2!
	Ballad Pan Flute	0	113	75	Sweet!
	Irish Pipe Dance	8	65	108	S.Art2!
	Ocarina	0	112	79	Regular
	Celtic Duo	0	120	73	Regular
	Shakuhachi	0	112	77	Regular
	Bagpipe	0	112	109	Regular
	Recorder	0	112	74	Regular
	Whistle	0	112	78	Regular
	Chiff Pan Flute	0	113	73	Regular

Main Category: PERC&DRUMS

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
Chromatic Perc	Vibraphone	104	1	11	Sweet!
	Xylophone	104	0	13	Regular
	Jazz Vibraphone	0	113	11	Regular
	Marimba	104	0	12	Regular
	Tremolo Vibraphone	0	124	11	Natural!
	Orchestral Marimba	0	122	12	Natural!
	Vibraphone & JazzGt	8	33	11	S.Art!
	Glockenspiel	104	0	9	Regular
	Vibraphone & Flutes	0	114	11	Regular
	Steel Drums	0	112	114	Regular
	Vibraphone	0	122	11	Natural!
	Steel Drums	0	122	114	Natural!
	Music Box	0	112	10	Regular
	Kalimba	0	112	108	Regular
Orchestral Perc	Orchestral Harp	104	1	46	Regular
	Tubular Bells	0	112	14	Regular
	Mellow Harp	104	0	46	Regular
	Timpani	0	112	47	Regular
	Celesta	0	112	8	Regular
	Orchestra Hit	0	112	55	Regular
	Concert Celesta	0	122	8	Natural!
	Drum Kits	Real Drums	127	0	91
Power Kit 1		127	0	87	Live!Drums
Real Brushes		127	0	41	Live!Drums
Power Kit 2		127	0	88	Live!Drums
Acoustic Kit		127	0	89	Live!Drums
House Kit		127	0	60	Drums
Rock Kit		127	0	90	Live!Drums
Drum Machine		127	0	61	Drums
Studio Kit		127	0	86	Live!Drums
Analog T8 Kit		127	0	58	Drums
Analog T9 Kit		127	0	59	Drums
Jazz Kit		127	0	32	Drums
Break Kit		127	0	57	Drums
Hit Kit		127	0	4	Drums
Hip Hop Kit		127	0	56	Drums
Room Kit	127	0	8	Drums	
Dance Kit	127	0	27	Drums	
Electro Kit	127	0	24	Drums	

CVP-709**Main Category: PERC&DRUMS**

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
Drum Kits	Analog Kit	127	0	25	Drums
	Symphony Kit	127	0	48	Live!Drums
World Perc Kits	Pop Latin Kit 2	126	0	44	Live!SFX
	Cymbal Kit	126	0	49	Live!SFX
	Turkish Kit	126	0	67	Live!SFX
	Cuban Kit	126	0	40	Live!SFX
	Pop Latin Kit	126	0	43	Live!SFX
Vocal Effects	Gospel AdLibs	126	0	110	Live!SFX
	Vocal Effects Kit	126	0	109	Live!SFX
SFX	New SFX Kit 1	126	0	2	Live!SFX
	Helicopter	104	0	125	Live!
	New SFX Kit 2	126	0	3	Live!SFX
	Applause 1	104	0	126	Live!
	Noises Kit	126	0	8	SFX
	Applause 2	104	1	126	Live!
	Sea Shore	104	0	122	Live!
	Gun Shot	104	0	127	Live!

Main Category: SYNTH

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
Synth Lead	Square Stack (Pedal)	8	32	123	S.Art!
	Nasty Saw	104	10	90	Regular
	Growling Hook	104	11	90	Regular
	Loony Lead	104	15	90	Regular
	Ten Percent	104	18	90	Regular
	Cool HiPa (Pedal)	8	34	123	S.Art!
	Wheel Tech (Pedal)	8	36	123	S.Art!
	Redoubling (Pedal)	8	37	123	S.Art!
	Hard Teeth	104	16	90	Regular
	Cyclist	104	17	90	Regular
	Crowds	104	19	90	Regular
	Gemini	104	20	90	Regular
	Hands Up!	104	21	90	Regular
	Straight Raver	104	22	90	Regular
	Trance Artist	104	23	90	Regular
	Punchy Chordz	104	24	90	Regular
	Trancy Chordz	104	25	90	Regular
	Trancy Noise	104	1	122	Regular
	Unison Strings	104	9	50	Regular
	Med Det Strings	104	10	50	Regular
	Four Stack (Pedal)	8	33	123	S.Art!
	Nu Line (Pedal)	8	35	123	S.Art!
	Yipping	104	12	90	Regular
	Unstable Lead	104	13	90	Regular
	Persecutor	104	14	90	Regular
	Short Unison	104	4	84	Regular
	Brite Decay	104	5	84	Regular
	Tekk Tune	104	6	84	Regular
	Stacc Melody	104	7	84	Regular
	Pitchy Patch	104	8	84	Regular
	Soft Chordsyn	104	9	84	Regular
	Chord Buddy	104	10	84	Regular
	Tune Comp	104	11	84	Regular
	Arpeggio Line	104	12	84	Regular
	Soft Stepper	104	24	88	Regular
	PWM Picks	104	25	88	Regular
	Square Stepz	104	26	88	Regular
	Dyna Sequence	104	27	88	Regular
	Tri Picks	104	28	88	Regular
	Cracky	104	29	88	Regular
	Sub Lead	104	0	80	Regular
	Wire Lead	0	120	81	Regular

Main Category: SYNTH

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
Synth Lead	Soft Saw	104	16	81	Regular
	Soft R&B	0	119	80	Regular
	Fusion Lead	104	15	81	Regular
	Early Lead	0	118	81	Regular
	Oxygen	0	122	81	Regular
	Soft Square	104	5	80	Regular
	Matrix	0	123	81	Regular
	Detuned Vintage	104	1	84	Regular
	PWM Lead	104	1	81	Regular
	Hipa Lead	0	118	84	Regular
	Brassy Lead	104	5	62	Regular
	Punchy Hook	0	127	81	Regular
	Punch Lead	104	7	81	Regular
	Crying Lead	0	114	87	Regular
	Flange Filter	104	2	81	Regular
	Hip Lead	0	113	80	Regular
	Mouth Lead	104	0	81	Regular
	Hop Lead	0	117	80	Regular
	Tech Lead	0	117	84	Regular
	Analogon	0	115	81	Regular
	Tekkline	0	116	84	Regular
	Skyline	0	115	84	Regular
	Soft Mini	0	124	80	Regular
	Bleep Lead	104	0	84	Regular
Fire Wire	0	116	81	Regular	
Synth Perc	New Heaven	104	10	88	Regular
	Heaven Pad	104	3	91	Regular
	Fantasy Bells	104	11	88	Regular
	Breath Bells	104	15	88	Regular
	Itopia Bells	104	13	88	Regular
	Next Generation	104	9	51	Regular
	Sinesphere	104	18	88	Regular
	Organ Bells	104	12	88	Regular
	Spectrum Theme	104	14	88	Regular
	Sky Bells	104	16	88	Regular
	Flying Harmonics	104	1	99	Regular
	Perc Pad	104	0	101	Regular
	Nylon Heaven	104	2	99	Regular
	Mediterrain	0	114	99	Regular
	Airy Harp	104	17	88	Regular
	Lektro Codes	104	2	84	Regular
	Nylon Pad	104	0	99	Regular
	Simple Comp	104	12	81	Regular
	Bellsphere	104	5	88	Regular
	Ballad Comp	104	6	88	Regular
	Heaven Bell	104	0	100	Regular
	Digital Sequenced	104	2	87	Regular
	Bright Pad Bell	104	7	88	Regular
	Analog Sequenced	104	3	87	Regular
	Wild PWM	104	4	80	Regular
	Perc Sequence FS	104	6	87	Regular
	Resonant Clavi	104	2	90	Regular
	Perc Sequence FM 1	104	7	87	Regular
	Resonance Comp	104	4	62	Regular
	Perc Sequence FM 2	104	8	87	Regular
	Synth Sticks	104	0	106	Regular
	Attack	104	4	81	Regular
	Saz Feeze	104	0	97	Regular
	PWM Percussion	104	6	81	Regular
	Eastern Air	104	1	97	Regular
	Nomad	104	1	104	Regular
	Xtune	104	1	87	Regular
Stack Bell	104	8	88	Regular	

CVP-709

Main Category: SYNTH

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
Synth Perc	Perc Sequence Saw	104	11	81	Regular
	Nice Bell	104	9	88	Regular
Synth Strings	Synth Strings 1	0	112	50	Regular
	Butter Strings	104	2	50	Regular
	Synth Strings 2	0	113	50	Regular
	Bright Saw Pad	0	113	90	Regular
	Ober Strings	0	113	51	Regular
	Soft Ensemble	104	1	50	Regular
	Hipa Strings	0	114	95	Regular
	80s Pad	104	1	51	Regular
	Octave Strings	104	4	50	Regular
	Bright Pop Pad	104	3	50	Regular
	Doux Flange	104	3	95	Regular
	Premium Pad	104	0	51	Regular
	Light Pad	104	2	51	Regular
	Bright Pad Classic	104	3	90	Regular
	Medium Tune Pad	104	0	50	Regular
Synth Brass	Analog Brass	0	112	63	Regular
	1984 Synth	104	20	81	Regular
	Fat Synth Brass	0	116	63	Regular
	80s Brass	0	113	62	Regular
	Thin Brass	104	0	62	Regular
	Funky Analog	0	115	62	Regular
	Brass Profit	104	1	62	Regular
	Techno Brass	0	114	62	Regular
	Ober Brass	0	113	63	Regular
	Ober Horns	0	115	63	Regular
	Slow PWM Brass	104	2	62	Regular
	Soft Velo Brass	0	120	62	Regular
	Fast PWM Brass	104	6	62	Regular
	Soft Analog	0	114	63	Regular
	Synth Pad	All or Nothing	104	6	101
Whisper Gallery		104	0	92	Regular
Digisweeper		104	7	101	Regular
Hybrid Lines		104	4	91	Regular
Spectrum Pad		104	5	94	Regular
Midnight Special		104	3	101	Regular
Hybrid Pad		104	22	88	Regular
Atmo 5th		104	6	89	Regular
Deep Motion		104	4	95	Regular
Pad Voices		104	6	95	Live!
Skydiver		0	112	101	Regular
Aerosphere		104	1	94	Regular
Cross Phase		104	1	101	Regular
New Atmosphere		104	4	89	Regular
Galaxy Pad		104	3	88	Regular
VP Soft		104	0	89	Regular
Night Motion		104	4	88	Regular
Hot Swell		104	2	95	Regular
Morning Dew		104	0	94	Regular
Dark Fat Saw		104	2	89	Regular
Vapor Pad		104	1	89	Regular
Dark Light		104	3	89	Regular
Space Rider		104	1	95	Regular
Ambient Pad		104	0	88	Regular
Pearls Pad		104	2	88	Regular
Bright Fat Saw		104	5	90	Regular
Breath Pad		104	0	91	Regular
Early Digital		104	0	93	Regular
Noble Man		104	1	88	Regular
Super Dark Pad		0	119	89	Regular
Analog Pad		0	120	89	Regular
Analog Swell		0	119	95	Regular
Dark Angel Pad		0	121	89	Regular

Main Category: SYNTH

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
Synth Pad	Big Octave Pad	0	115	90	Regular
	Lite Pad	0	122	89	Regular
	Golden Age	0	115	88	Regular
	Pop Pad	0	112	90	Regular
	Solaris	0	114	94	Regular
	Glorious Phase	0	114	90	Regular
	Insomnia	0	113	94	Regular
	Ober Sweep	0	115	95	Regular
	Neo Warm Pad	0	115	89	Regular
	Time Travel	0	116	88	Regular
	Cyber Pad	0	113	99	Regular
	Bubblespace	0	113	101	Regular
	Bright Ober	0	113	95	Regular
	Mellow Pad	0	117	95	Regular
	Dark Pad	0	118	95	Regular
Synth Dance	Ana Dayz	104	3	51	Regular
	HPF Dance	104	0	90	Regular
	Bright Pad Trance	104	4	90	Regular
	Detuned Saw Octave	104	8	81	Regular
	Chillin Chords	104	6	51	Regular
	Dancy Hook	104	9	81	Regular
	Trance (Pedal)	104	0	95	Regular
	Vinlog Saw	104	3	81	Regular
	Club Lead	104	3	62	Regular
	Talk Mod Lead	104	0	87	Regular
	Trance Perc	104	5	81	Regular
	Chorus Saw Lead	104	10	81	Regular
	Chordmaster	104	13	81	Regular
	Faaat Comp	104	4	51	Regular
	Trance Sequence 1	104	4	87	Regular
	Fat Saw Hook	104	7	51	Regular
	Trance Sequence 2	104	5	87	Regular
	Tech Glide	104	14	81	Regular
Trance Sequence 3	104	1	90	Regular	
Dance Chords	104	5	51	Regular	
Dance Hook	0	112	86	Regular	
Trance Lead	0	121	80	Regular	
Octave Hook	0	113	86	Regular	
Synth Effects	Water Games	104	4	101	Regular
	Spectralis	104	4	94	Regular
	My Generation	104	5	101	Regular
	Metallic Rain	104	8	101	Regular
	Rainy Day	104	5	89	Regular
	Ambient Theme	104	20	88	Regular
	Warped Waves	104	2	94	Regular
	Reflecting Zone	104	21	88	Regular
	Sound Pictures	104	3	94	Regular
	The Fog	104	9	101	Regular
	Mystic Pad	104	6	94	Regular
	Sixth Sense	104	2	101	Regular
	Randomizer	104	10	101	Regular
	Pitch Fall	104	0	103	Regular
	Atlantis	104	11	101	Regular
	Perc Sequence Hipa	104	9	87	Regular
	Tric-Trac	104	2	97	Regular

CVP-709

Main Category: OTHERS

Sub Category 1	Sub Category 2	Voice Name	Voice Number			Voice Type	
			MSB	LSB	Prg		
Legacy	Piano	Studio Grand	0	115	0	Live!	
		Grand Piano	0	113	0	Live!	
		Pop Grand 2	104	11	0	Natural!	
		Pop Grand	104	5	0	Live!	
		Stage Piano	104	10	0	Natural!	
		Rock Piano	104	4	0	Live!	
		Warm Grand	0	114	0	Live!	
		Bright Piano	0	112	1	Live!	
		Ambient Piano	104	9	0	Natural!	
		Ambient Piano	104	3	0	Live!	
		Cocktail Piano	104	1	3	Natural!	
		Cocktail Piano	104	0	3	Live!	
		Honky Tonk	0	122	3	Natural!	
		Honky Tonk	0	112	3	Regular	
		Grand Piano 1octave	104	2	3	Natural!	
		Grand Piano 2octaves	104	3	3	Natural!	
		Octave Piano 1	0	113	3	Live!	
		Octave Piano 2	0	114	3	Live!	
		MIDI Grand	0	112	2	Regular	
		MIDI Grand	104	0	2	Live!	
		MIDI GrandPad	104	1	2	Live!	
		MIDI GrandSyn	104	1	0	Live!	
		Piano Orchestra	104	2	0	Live!	
		Harpichord	0	112	6	Live!	
		E.Piano	Ballad Stack	0	114	2	Regular
			Jazz Chorus	0	118	5	Regular
			Hyper Tines	0	113	5	Regular
			Venus EP	0	114	5	Regular
			Super DX	0	117	5	Regular
			Polaris EP	0	115	4	Regular
			DX Modern	0	112	5	Regular
			New Tines	0	116	5	Regular
	Phase EP		0	120	4	Regular	
	Modern EP		0	115	5	Regular	
	Funk EP		0	112	4	Regular	
	Chorus Bell		0	120	5	Regular	
	Stereo Clavi		0	114	7	Regular	
	Organ		Dance Organ	0	113	17	Regular
			Click Organ	0	112	17	Regular
		Rotary Switch	0	110	17	Cool!	
		Rotary Drive	0	116	18	Regular	
		Full Rocker 2	104	3	18	Cool!	
		Gospel Organ	0	119	16	Regular	
		Purple Organ	0	114	18	Regular	
		Percussive Organ	0	119	17	Regular	
		Drawbar Organ 1	0	120	17	Regular	
		Drawbar Organ 2	0	115	16	Regular	
		Rock Organ 1	0	112	18	Regular	
		Jazz Organ 1	0	112	16	Regular	
		Rock Organ 2	0	119	18	Regular	
		Jazz Organ 2	0	113	16	Regular	
		Rock Organ 3	0	113	18	Regular	
		Jazz Organ 3	0	120	16	Regular	
		Bright Drawbar	0	116	16	Regular	
		Electric Organ	0	118	17	Regular	
		60s Organ	0	116	17	Regular	
		Reed Organ	0	112	20	Regular	
		Tibia 8'&4' Accomp	0	122	16	Regular	
		Tibia 16'&4' Accomp	0	114	16	Regular	
		Tibia Full Accomp	0	114	17	Regular	
		Tibia 8' Accomp	0	122	17	Regular	
		Vox 8' Accomp	0	123	17	Regular	
		Vox & Tibia Accomp	0	125	16	Regular	
		Classic Jazz	0	126	16	OrganFlutes	

Main Category: OTHERS

Sub Category 1	Sub Category 2	Voice Name	Voice Number			Voice Type	
			MSB	LSB	Prg		
Legacy	A.Guitar	Flamenco Guitar	8	33	0	S.Art!	
		Folk Guitar	0	112	25	Regular	
		Campfire Guitar	0	115	25	Regular	
		18String Guitar	0	119	25	Regular	
	E.Guitar	Vintage Amp	8	40	3	S.Art!	
		70s Solid Guitar	104	1	27	Cool!	
		Warm Solid	104	2	27	Cool!	
		Clean Solid	104	3	27	Cool!	
		Muted Guitar	0	112	28	Regular	
		Funk Guitar	0	113	28	Regular	
		Solid Chord	0	121	27	Regular	
		Solid Guitar	0	118	27	Regular	
		Electric 12String	0	119	27	Regular	
		Tremolo Guitar	0	113	27	Regular	
		Wah Guitar	0	122	27	Regular	
		Chorus Guitar	0	124	27	Regular	
		Vintage Trem	0	120	27	Regular	
		Deep Chorus	0	114	27	Regular	
		Bright Clean	0	116	27	Regular	
		DX Jazz Guitar	0	117	26	Regular	
		Half Drive	104	0	29	Cool!	
		Smooth Lead	0	119	26	Regular	
		Rock Guitar	0	116	29	Regular	
		Lead Guitar	0	114	29	Regular	
		Overdrive Guitar	0	112	29	Regular	
		Guitar Hero	104	0	30	Cool!	
		Heavy Rock	104	1	30	Cool!	
		Power Chord	0	117	30	Regular	
		Voodoo Lead	0	116	30	Regular	
		Distortion Guitar	0	112	30	Regular	
		Feedback Guitar	0	113	29	Regular	
		Bass	Click Bass	0	115	38	Regular
			Punchy Bass	0	117	38	Regular
			Analog Bass	0	112	39	Regular
			DX Funk Bass	0	113	37	Regular
			Dry Synth Bass	0	116	39	Regular
	80s Synth Bass		0	115	39	Regular	
	HiQ Bass		0	113	38	Regular	
	Acoustic Bass		0	112	32	Regular	
	Accordion		Accordion	0	116	21	Regular
			Small Accordion	0	115	21	Regular
		Modern Harp	0	113	22	Regular	
		Blues Harp	0	114	22	Regular	
		Ballroom Accordion	0	112	23	Regular	
		Soft Accordion	0	114	21	Regular	
		Tutti Accordion	0	113	21	Regular	
		Musette Accordion	0	112	21	Regular	
	Strings	Orchestra Strings	0	116	49	Live!	
		Orch Strings	0	113	48	Regular	
		Symphonic	0	114	48	Regular	
		Concerto Strings	0	115	48	Regular	
		Slow Strings	0	113	49	Regular	
		Strings	0	112	48	Regular	
		Tremolo Strings	0	112	44	Regular	
		Bow Strings	0	116	48	Regular	
		Marcato	0	115	49	Regular	
		Pizzicato	0	112	45	Regular	
		String Falls	0	121	48	Live!	
		Analog Strings	0	112	51	Regular	
		Orch & Flute	0	119	49	Regular	
		Orch & Oboe	0	121	49	Regular	
		Orch & Horns	0	118	49	Regular	
		String Quartet	0	114	49	Regular	
		Harp	0	112	46	Regular	

CVP-709

Main Category: OTHERS

Sub Category 1	Sub Category 2	Voice Name	Voice Number			Voice Type
			MSB	LSB	Prg	
Legacy	Strings	Hackbrett 2	0	113	46	Regular
		Banjo 2	0	112	105	Regular
		Sitar 2	0	112	104	Regular
	Brass	Brass Section	0	112	61	Regular
		Brass Combo	0	115	66	Regular
		Natural Brass	0	124	61	Regular
		Bright Brass	0	120	61	Regular
		French Horns	0	112	60	Live!
		Mellow Horns	0	119	61	Regular
		Symphony Horns	0	115	60	Live!
		Symphony Brass	0	119	60	Live!
		Big Band Brass	0	113	61	Regular
		Mellow Brass	0	116	61	Regular
		Big Brass	0	121	61	Regular
		Small Brass	0	117	61	Regular
		Soft Brass	0	123	61	Regular
		Sforzando	0	125	61	Regular
		High Brass	0	115	61	Regular
		Breath Brass	0	116	60	Regular
		Full Horns	0	114	61	Regular
		Trumpet Ensemble	0	122	61	Regular
		Brass Hit	0	126	61	Regular
		Trombone Section	0	113	57	Regular
		Smooth Trombone	0	118	57	Regular
		Solo Trombone	0	112	57	Regular
		Trombone	0	116	57	Regular
		Soft Trombone	0	115	57	Regular
		Mellow Trombone	0	114	57	Regular
		Solo Trumpet	0	112	56	Regular
		Jazz Trumpet	0	116	56	Regular
		Muted Trumpet	0	112	59	Regular
		Flugel Horn	0	113	56	Regular
		Tuba 2	0	112	58	Regular
		Hybrid Comp	0	119	62	Regular
		Hybrihorn	0	113	60	Regular
		Hybripad	0	114	60	Regular
	Pop Brass	0	118	61	Regular	
	Synth Brass	0	112	62	Regular	
	Woodwind	Soprano Sax	0	112	64	Regular
		Alto Sax	0	112	65	Regular
		Tenor Sax	0	112	66	Regular
		Baritone Sax	0	112	67	Regular
		Alto Sax	0	114	65	Sweet!
		Saxophone	104	0	66	Sweet!
		Growl Sax	0	118	66	Regular
		Sax Stack	0	124	66	Regular
		Saxy Mood	0	120	66	Regular
		Flute	0	112	73	Regular
		Oboe	0	112	68	Regular
		Clarinet	0	112	71	Regular
		Bassoon	0	112	70	Regular
		Ethnic Flute	0	112	75	Regular
		Orch Flute	104	0	73	Sweet!
		Orch Oboe	104	0	68	Sweet!
		Woodwinds Ensemble	0	113	66	Regular
	Choir	Voices	0	113	54	Regular
		Choir	0	112	52	Regular
		Air Choir	0	112	54	Regular
		Hah Choir	0	114	52	Regular
		Uuh Choir	0	115	52	Regular
		Boys Choir Aah	104	8	52	Live!
		Boys Choir Ooh	104	8	53	Live!
		Gospel Voices	0	116	52	Live!
		Humming	0	118	52	Live!

Main Category: OTHERS

Sub Category 1	Sub Category 2	Voice Name	Voice Number			Voice Type	
			MSB	LSB	Prg		
Legacy	Choir	Vox Humana	0	112	53	Regular	
		Sweet Heaven	0	118	88	Regular	
		Dream Heaven	0	121	88	Regular	
		Bell Heaven	0	119	88	Regular	
		Pan Heaven	0	120	88	Regular	
		Pro Heaven	0	122	88	Regular	
		Sunbeam	0	123	88	Regular	
		Hah Pad	0	116	94	Regular	
		Percussion	Vibraphone	0	112	11	Regular
	Marimba		0	112	12	Regular	
	Xylophone		0	112	13	Regular	
	Glockenspiel		0	112	9	Regular	
	Drum Kit	Standard Kit 1	127	0	0	Live!Drums	
		Standard Kit 2	127	0	1	Live!Drums	
		Rock Kit	127	0	16	Drums	
		Brush Kit	127	0	40	Live!Drums	
		SFX Kit 1	126	0	0	SFX	
		SFX Kit 2	126	0	1	SFX	
		Arabic Kit	126	0	35	SFX	
		Pad	Psycho Pad	0	118	101	Regular
	Far East		0	112	97	Regular	
	Disclosure		0	116	89	Regular	
	Mystery		0	113	97	Regular	
	Sirius		0	114	101	Regular	
	S&H Groove		0	115	101	Regular	
	Velo Ashrami		0	116	101	Regular	
	Evening Stars		0	117	101	Regular	
	Angel Vibes		0	114	98	Regular	
	Glass Pad		0	114	93	Regular	
	DX Pad		0	112	92	Regular	
	Symbiont		0	113	88	Regular	
	Dark Moon		0	113	89	Regular	
	Ionosphere		0	115	94	Regular	
	Millennium		0	117	88	Regular	
	Atmosphere		0	112	99	Regular	
	Equinox		0	112	94	Regular	
	Fantasia		0	112	88	Regular	
	Stargate		0	114	88	Regular	
	Area 51		0	112	89	Regular	
	Digital Pad		0	115	93	Regular	
	Dunes		0	114	89	Regular	
	Messenger		0	116	95	Regular	
	Wave 2001		0	112	95	Regular	
	Xenon Pad		0	112	91	Regular	
	Magic Bell		8	32	120	S.Art!	
	Synth		Pro Lead	0	113	83	Regular
			Funky Lead	0	121	81	Regular
			Portatone	0	112	84	Regular
			Adrenaline	0	113	84	Regular
			Stardust	0	112	98	Regular
			Aero Lead	0	112	83	Regular
			Mini Lead	0	114	80	Regular
		Sun Bell	0	113	98	Regular	
		Hi Bias	0	116	80	Regular	
		Vinyl Lead	0	115	80	Regular	
		Pan Lead	0	122	80	Regular	
		String Bells	0	124	88	Regular	
		Padbells	0	126	88	Regular	
		Big Tune	0	118	89	Regular	
		Trumpet Saw	0	125	81	Regular	
		Paraglide	0	114	84	Regular	
		Robolead	0	124	81	Regular	
		Fargo	0	119	81	Regular	
	Big Lead	0	113	81	Regular		

CVP-709**Main Category: OTHERS**

Sub Category 1	Sub Category 2	Voice Name	Voice Number			Voice Type
			MSB	LSB	Prg	
Legacy	Synth	Warp	0	117	81	Regular
		Impact	0	113	87	Regular
		Under Heim	0	112	87	Regular
		Crystal Eyes	0	125	88	Regular
		Melody Maker	0	117	89	Regular
		Attack Saw	0	126	81	Regular
		Perc Square	0	123	80	Regular
		Square Lead	0	112	80	Regular
		Saw Lead	0	112	81	Regular
		Pop Lead	0	120	80	Regular
		Bright Mini	0	125	80	Regular
		Orbit Sine	0	126	80	Regular
		Blaster	0	114	81	Regular
		Tiny Lead	0	118	80	Regular
MegaVoices	A.Guitar	Nylon Guitar	8	0	0	MegaVoice
		Flamenco Guitar	8	3	0	MegaVoice
		Spanish Medium Guitar	8	4	0	MegaVoice
		Spanish Hard Guitar	8	5	0	MegaVoice
		Steel Acoustic Guitar	8	1	1	MegaVoice
		Steel Acoustic Guitar Slap	8	2	1	MegaVoice
		Steel Guitar Twin 1	8	5	1	MegaVoice
		Steel Guitar Twin 2	8	6	1	MegaVoice
		Steel Guitar	8	0	1	MegaVoice
		12String Guitar	8	1	2	MegaVoice
		12String Guitar Twin 1	8	7	1	MegaVoice
		12String Guitar Twin 2	8	8	1	MegaVoice
		Hi String Guitar	8	0	2	MegaVoice
		E.Guitar	Solid Guitar 1	8	1	3
	Solid Guitar 2		8	2	3	MegaVoice
	Finger Guitar		8	4	3	MegaVoice
	Finger Slap Guitar		8	5	3	MegaVoice
	Vintage Pick Guitar		8	6	3	MegaVoice
	Vintage Slap Guitar		8	7	3	MegaVoice
	Clean Guitar		8	0	3	MegaVoice
	Single Coil Guitar		8	3	3	MegaVoice
	Slap Amp Guitar		8	8	3	MegaVoice
	Jazz Guitar		8	0	6	MegaVoice
	Overdrive Guitar		8	0	4	MegaVoice
	Distortion Guitar		8	0	5	MegaVoice
	Bass		Acoustic Bass	8	0	16
		Vintage Round	8	1	17	MegaVoice
		Vintage Flat	8	2	17	MegaVoice
		Vintage Pick	8	1	18	MegaVoice
		Electric Bass	8	0	17	MegaVoice
		Pick Bass	8	0	18	MegaVoice
		Fretless Bass	8	0	19	MegaVoice
	Strings	Classical Strings	8	1	48	MegaVoice
		Real Strings	8	1	49	MegaVoice
		Large Strings	8	0	49	MegaVoice
		Small Strings	8	0	48	MegaVoice
	Vocal	Gospel Choir	8	0	54	MegaVoice
		Male Voice Choir	8	0	51	MegaVoice
		Pop Haa	8	0	100	MegaVoice
		Pop Daa	8	0	101	MegaVoice
		Pop Baa	8	0	102	MegaVoice
		Pop Hee	8	0	110	MegaVoice
		Pop Bee	8	0	107	MegaVoice
		Pop Hoo	8	0	105	MegaVoice
		Pop Doo	8	0	106	MegaVoice
		Pop Shoo	8	0	103	MegaVoice
		Pop Haa Legato 2	8	0	115	MegaVoice
Pop Hoo Legato 2		8	0	120	MegaVoice	
Pop Hee Legato 2		8	0	125	MegaVoice	

Main Category: OTHERS

Sub Category 1	Sub Category 2	Voice Name	Voice Number			Voice Type
			MSB	LSB	Prg	
MegaVoices	Brass	Pop Horns 1	8	1	56	MegaVoice
		Pop Horns 2	8	2	56	MegaVoice
		Trumpet	8	0	64	MegaVoice
		Brass	8	0	56	MegaVoice
		Woodwind	Tenor Sax	8	0	82

CVP-705

Main Category: PIANO

Sub Category 1	Voice Name	Voice Number			Voice Type	
		MSB	LSB	Prg		
VRM Piano	CFX Grand	108	0	0	VRM	
	Bösendorfer	108	6	0	VRM	
	Pop Grand	108	17	1	VRM	
	Mellow Piano	108	18	0	VRM	
	Studio Grand	108	30	0	VRM	
	Themic Grand	108	6	1	VRM	
	Bright Piano	108	16	1	VRM	
	Ambient Piano	108	27	3	VRM	
	Rock Piano	108	16	2	VRM	
	Stage Piano	108	31	0	VRM	
	Grand Piano 1octave	108	22	1	VRM	
	Grand Piano 2octaves	108	23	1	VRM	
	Cocktail Piano	108	28	3	VRM	
Grand Piano	CFX Grand	0	122	0	Natural!	
	Bösendorfer	104	18	0	Natural!	
	Pop Grand	104	6	0	Natural!	
	Mellow Piano	0	124	0	Natural!	
	Studio Grand	104	19	0	Natural!	
	Themic Grand	104	18	1	Natural!	
	Bright Piano	0	123	0	Natural!	
	Ambient Piano	104	19	3	Natural!	
	Rock Piano	0	124	2	Natural!	
	Stage Piano	104	20	0	Natural!	
	Grand Piano 1octave	0	123	3	Natural!	
	Grand Piano 2octaves	0	124	3	Natural!	
	Cocktail Piano	104	20	3	Natural!	
Upright Piano	Upright Piano	104	13	0	Natural!	
	Pop Upright	104	13	1	Natural!	
	70s Ballad Piano	104	14	0	Natural!	
	Chill Out Piano	104	15	0	Natural!	
	Honky Tonk Upright	104	13	3	Natural!	
	Saloon Upright	104	14	1	Natural!	
	Upright 1octave	104	14	3	Natural!	
	Upright 2octaves	104	15	3	Natural!	
	Piano Layer	Superstar Grand	108	25	4	Natural!
Imperial Ballad		108	26	4	Natural!	
MIDI Grand		104	2	2	Natural!	
MIDI Grand Pad		104	3	2	Natural!	
Bright Grand Pad		104	8	0	Natural!	
Grand Pad Layer		108	32	2	Natural!	
Piano & EP		108	25	2	Natural!	
Grand Piano & Strings		108	23	0	Natural!	
Grand Piano & Orchestra	104	12	0	Natural!		
Electric Piano	Suitcase EP	0	118	4	Cool!	
	Vintage EP	0	116	4	Regular	
	Electric Piano 1	0	119	4	Cool!	
	Electric Piano 2	0	122	4	Natural!	
	Stage EP	0	117	4	Regular	
	Funky EP	0	123	4	Natural!	
	Tremolo Suitcase EP	0	113	4	Cool!	
	Tremolo Stage EP	0	124	4	Natural!	
	Smooth Tine	0	119	5	Regular	
	CP80 Stage	0	113	2	Regular	
	Magnetics	104	0	4	Regular	
	FM E.Piano	Studio Ballad DX	104	9	5	Regular
		Sparkle Stack	0	121	5	Cool!
Sweet DX		104	0	5	Cool!	
Ballad DX		0	124	5	Cool!	
DX Dynamics		0	123	5	Cool!	
Ballad Bells		104	2	5	Cool!	
Galaxy EP		0	114	4	Cool!	
DX7 EP		0	122	5	Natural!	
Dream DX		104	3	5	Cool!	
Midnight DX		104	1	5	Cool!	

Main Category: PIANO

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
FM E.Piano	Piano Sweeper	104	3	99	Regular
	Pianosphere	104	19	88	Regular
Clavi	Clavi Bright	0	112	7	Regular
	Wah Clavi	0	113	7	Regular
	Phase Clavi	0	115	7	Regular
Harpsichord	Harpsichord 1	0	122	6	Natural!
	Harpsichord 2	8	32	112	S.Art!
	Harpsichord Coupler	0	123	6	Natural!
	Grand Harpsichord	0	113	6	Live!
	Harpsichord & Strings	0	124	6	Natural!

Main Category: ORGAN

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
Tonewheel Organ	Whiter Bars	8	32	29	S.Art!
	Curved Bars	0	121	16	Cool!
	All Bars Out	8	32	30	S.Art!
	Even Bars	0	111	16	Cool!
	Jazz Rotary	8	32	113	S.Art!
	Vintage Fast	0	127	16	Cool!
	Classic Bars	8	34	29	S.Art!
	Scanner Jazz	0	118	18	Cool!
	Rock Rotary	8	33	113	S.Art!
	Organ-a-Go-Go	104	0	16	Cool!
	Prog Rock Organ	8	33	29	S.Art!
	Organ Accomp 1	0	108	17	Regular
	R&B Tremolo	0	111	18	Cool!
	Organ Accomp 2	0	107	17	Regular
	Classic Jazz	0	117	16	Cool!
	Organ Accomp 3	0	106	17	Regular
	Hold It Fast	0	111	17	Cool!
	Organ Accomp 4	0	105	17	Regular
	Full Rocker	0	115	18	Cool!
	Organ Accomp 5	0	104	17	Regular
	Whiter Bars Slow	104	1	17	Cool!
	Whiter Bars Fast	104	0	17	Cool!
	Jazz Organ Slow	0	126	17	Cool!
	Jazz Organ Fast	0	127	17	Cool!
	All Bars Out Slow	104	1	18	Cool!
	All Bars Out Fast	104	0	18	Cool!
	All Bars Phase	104	2	18	Cool!
Rotor Organ	0	117	18	Cool!	
Mellow Drawbar	0	115	17	Regular	
Two Channels Organ	0	109	17	Cool!	
Transistor Organ	60s Combo 1	104	32	16	Cool!
	60s Combo 2	104	33	16	Cool!
	60s Combo 3	104	34	16	Cool!
	60s Combo 4	104	35	16	Cool!
Euro Organ	0	118	16	Regular	
Classical Pipe	Pipe Organ Principal	0	123	19	Natural!
	Chapel Organ	0	113	19	Regular
	Full Organ	0	112	19	Regular
	Hymn Organ	0	114	19	Regular
	Pipe Organ Tutti	0	122	19	Natural!
	Church Organ	0	115	19	Regular
Theatre Pipe	Full Theatre	0	127	18	Regular
	Tibia 8'	104	6	17	Regular
	Sweet Theatre	0	126	18	Regular
	Tibia 8'&4'	104	9	16	Regular
	Ballroom Organ	0	115	3	Regular
	Tibia 16'&4'	104	8	16	Regular
	Tibia Chorus	104	5	17	Regular
	Vox Humana 8'	104	7	17	Regular

CVP-705**Main Category: ORGAN**

Sub Category 1	Voice Name	Voice Number			Voice Type	
		MSB	LSB	Prg		
Theatre Pipe	Vox Humana & Tibia	104	10	16	Regular	
	Theatre Trumpet 8'	0	124	16	Regular	
	Theatre Kinura 8'	0	123	16	Regular	
	Theatre Trumpet & Kinura	0	125	17	Regular	
	Theatre Trumpet 16'&8'	0	124	17	Regular	
Organ Flutes	Organ Flutes	10	0	8	OrganFlutes	
	USD Smile	10	1	8	OrganFlutes	
	Reggae Bars	10	2	8	OrganFlutes	
	Warm Theatre	10	3	8	OrganFlutes	
	Organ Pops	10	4	8	OrganFlutes	
	Rock Organ	10	5	8	OrganFlutes	
	Soul Percussion	10	6	8	OrganFlutes	
	Gospel Truth	10	7	8	OrganFlutes	
	Pad Organ	10	8	8	OrganFlutes	
	Full Organ	10	9	8	OrganFlutes	
	String Bars	10	0	9	OrganFlutes	
	Latin Spin	10	1	9	OrganFlutes	
	Shady Bars	10	2	9	OrganFlutes	
	Funk Organ	10	3	9	OrganFlutes	
	Ballad Organ	10	4	9	OrganFlutes	
	Rich Bars	10	5	9	OrganFlutes	
	Trumpet Bars	10	6	9	OrganFlutes	
	Soul Bars	10	7	9	OrganFlutes	
	Clari Bars	10	8	9	OrganFlutes	
	Jazz Squabble	10	9	9	OrganFlutes	
	Euro Perc	10	0	10	OrganFlutes	
	Ballad Euro	10	1	10	OrganFlutes	
	Euro Reeds	10	2	10	OrganFlutes	
	Even Warmth	10	3	10	OrganFlutes	
	Bright Euro	10	4	10	OrganFlutes	
	Euro Accomp 1	10	7	10	OrganFlutes	
	Full Euro	10	6	10	OrganFlutes	
	Euro Accomp 2	10	8	10	OrganFlutes	
	Euro Pops	10	5	10	OrganFlutes	
	Euro Accomp 3	10	9	10	OrganFlutes	
	Harmonica	Harmonica	0	112	22	Sweet!
		Modern Harp	0	113	22	Regular
Blues Harp		0	114	22	Regular	
Accordion	Full Accordion Register	104	2	21	Regular	
	French Musette Acc.	0	119	21	Regular	
	Master Accordion	0	118	21	Regular	
	Steirische	0	117	21	Regular	
	Jazz Accordion	0	120	21	Regular	
	Cassotto	104	0	21	Regular	
	Cajun	104	3	21	Regular	
	Accordion Clarinet	104	1	21	Regular	
	Bandoneon	0	113	23	Regular	
	Tango Accordion	0	114	23	Regular	
	Full Register Bass	104	5	21	Regular	
	Musette Bass	0	123	21	Regular	
	Master Bass	0	122	21	Regular	
	Cajun Bass	104	6	21	Regular	
	Accordion Bass	0	121	21	Regular	
	Tango Bass	0	115	23	Regular	

Main Category: GUITAR&BASS

Sub Category 1	Voice Name	Voice Number			Voice Type	
		MSB	LSB	Prg		
Nylon Acoustic	Concert Guitar	8	32	0	S.Art!	
	Dynamic Nylon	0	116	24	Live!	
	Flamenco Guitar	8	33	0	S.Art!	
	Hard Flamenco	0	118	24	Live!	
	Nylon Guitar	8	34	0	S.Art!	
	Classical Guitar	0	115	24	Live!	
	Slide Nylon	0	117	24	Live!	
	Nylon Mute	0	119	24	Live!	
	Electro Acoustic Guitar	8	35	0	S.Art!	
	Steel Acoustic	Steel Guitar	8	32	1	S.Art!
Slide Steel		0	118	25	Live!	
Folk Guitar Harmonics		8	33	1	S.Art!	
Dynamic Steel		0	116	25	Live!	
Steel Guitar Strum		0	117	25	Live!	
Steel Guitar Mute		0	120	25	Live!	
12String Guitar		0	113	25	Live!	
Clean Solid		Bright Chorus	8	45	3	S.Art!
		Vintage Slap	8	48	3	S.Art!
		Ballad Delay	8	46	3	S.Art!
	Vintage Pure	8	47	3	S.Art!	
	Finger Bright	8	50	3	S.Art!	
	Cool Wah Guitar	104	4	27	Regular	
	Semi Acoustic	8	33	6	S.Art!	
	Jazz Vintage	8	38	6	S.Art!	
	Jazz Artist	8	39	6	S.Art!	
	Smooth Jazz Guitar	8	35	6	S.Art!	
	Shadowed Guitar	8	56	3	S.Art!	
	Finger Chorus	8	42	3	S.Art!	
	Vintage Spring	8	54	3	S.Art!	
	Light Chorus	8	53	3	S.Art!	
	Country Pick	8	44	3	S.Art!	
	Finger Slap Slide	8	51	3	S.Art!	
	Warm Solid	8	33	3	S.Art!	
	Warm Electric	8	32	3	S.Art!	
	Clean Solid	8	34	3	S.Art!	
	Clean Electric	8	35	3	S.Art!	
	Slap Solid	0	108	27	Cool!	
	Lounge Guitar	104	1	26	Regular	
	Funk Slap	8	49	3	S.Art!	
	Single Coil Clean	8	39	3	S.Art!	
	70s Solid Guitar	8	38	3	S.Art!	
	Pure Vintage	8	42	5	S.Art!	
	Vintage Open	0	123	27	Regular	
	Chorus Solid	0	107	27	Cool!	
	Clean Guitar	0	112	27	Cool!	
	Jazz Clean	8	32	6	S.Art!	
	Slide Clean	0	117	28	Cool!	
	Muted Guitar	0	119	28	Cool!	
	Slide Solid	0	110	27	Cool!	
	Dynamic Mute	0	118	28	Cool!	
Slide Pick	104	7	27	Cool!		
Vintage Muted Guitar	104	0	28	Cool!		
Slide Finger	104	5	27	Cool!		
Vintage Muted Echo	0	115	28	Regular		
Slide Warm	104	6	27	Cool!		
Slide Jazz	104	0	26	Cool!		
Funk Guitar	0	116	28	Cool!		
Vintage Strum	0	126	27	Regular		
Tremolo Solid	0	111	27	Cool!		
Ballad Solid	0	109	27	Cool!		
Jazz Guitar	0	115	26	Cool!		
Jazz Solo Guitar	0	116	26	Cool!		
Octave Guitar	0	113	26	Regular		

CVP-705

Main Category: GUITAR&BASS

Sub Category 1	Voice Name	Voice Number			Voice Type	
		MSB	LSB	Prg		
Clean Solid	Electric Guitar	0	114	28	Cool!	
	60s Clean	0	117	27	Regular	
Distortion Solid	Rock Hero	8	35	5	S.Art!	
	Overdrive Wah	8	39	5	S.Art!	
	Vintage Rock	8	36	5	S.Art!	
	Vintage Blues	8	37	5	S.Art!	
	Stage Lead	8	38	5	S.Art!	
	Blues Slap Slide	8	36	4	S.Art!	
	Heavy Rock	8	32	4	S.Art!	
	Blues Bright	8	35	4	S.Art!	
	Classic Stack	8	41	5	S.Art!	
	Blues Warm	8	34	4	S.Art!	
	Guitar Hero	8	32	5	S.Art!	
	Vintage Amp	8	41	3	S.Art!	
	Feedbacker	8	33	4	S.Art!	
	Finger Amp	8	43	3	S.Art!	
	Rock Legend	8	34	5	S.Art!	
	Slide Pick Amp	104	8	27	Cool!	
	Crunch Guitar	8	33	5	S.Art!	
	Bluesy Night	8	55	3	S.Art!	
	Stereo Rock	104	2	30	Cool!	
	Half Drive	8	37	3	S.Art!	
	Blues Guitar	0	117	29	Cool!	
	Grunge Guitar	8	40	5	S.Art!	
	Metal Master	0	120	30	Regular	
	World	Pedal Steel Amp	8	52	3	S.Art!
		Mandolin	0	114	25	Sweet!
		Pedal Steel	8	36	3	S.Art!
Zither 1		104	1	15	Regular	
Banjo		104	0	105	Regular	
Zither 2		104	0	15	Regular	
Shamisen		0	112	106	Regular	
Dulcimer		0	112	15	Regular	
Koto		0	112	107	Regular	
Hackbrett		104	2	46	Regular	
Aloha Guitar		0	118	26	Regular	
Sitar		104	0	104	Regular	
Pedal Steel		0	115	27	Regular	
Bass	Vintage Round Bass	8	32	17	S.Art!	
	Acoustic Bass	8	32	16	S.Art!	
	Vintage Flatwound Bass	8	33	17	S.Art!	
	Soft Acoustic Bass	8	33	16	S.Art!	
	Vintage Mute Bass	8	32	18	S.Art!	
	Fretless Bass	8	32	19	S.Art!	
	Soft Acoustic Bass	104	2	32	Regular	
	Acoustic Bass	104	1	32	Regular	
	Ballroom Bass	104	0	32	Regular	
	Vintage Round Bass	104	1	33	Cool!	
	Vintage Flatwound Bass	104	2	33	Cool!	
	Acoustic Bass & Cymbal	0	114	32	Regular	
	Vintage Mute Bass	104	3	33	Cool!	
	Fusion Bass	0	113	36	Regular	
	Vintage Pick Bass	104	1	34	Regular	
	Vintage Dyno Bass	104	2	34	Cool!	
	Fretless Bass	0	112	35	Cool!	
	Slap Bass	0	112	36	Regular	
	Rock Bass	0	114	34	Regular	
	Mellow Finger Bass	0	112	33	Regular	
	Pick Bass	0	112	34	Regular	
	Pick Dyno Bass	0	113	34	Cool!	
	Electric Bass	0	114	33	Cool!	
	Half Mute Bass	0	115	33	Cool!	
	Super Fretless Bass	0	113	35	Regular	

Main Category: GUITAR&BASS

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
Bass	Vintage Pick Mute Bass	104	0	34	Cool!
	Funk Bass	0	112	37	Regular
Synth Bass	Lo Bass	104	0	39	Regular
	Fat Pulse	104	2	39	Regular
	Dark Bass	104	1	39	Regular
	Wazzo Saw	104	3	80	Regular
	Moon Bass	104	0	38	Regular
	Deep Point	104	3	38	Regular
	Kick Bass	104	1	38	Regular
	Tight Bass	104	3	39	Regular
	Club Bass	104	2	38	Regular
	Competitor	104	4	38	Regular
	1o1 Sub	104	5	38	Regular
	Trance Bass	104	9	38	Regular
	Little Bass Synth	104	6	38	Regular
	Sub Cut Bass	104	5	39	Regular
	Tekno Bass	104	7	38	Regular
	Dyno Acid Bass	104	10	38	Regular
	Perc Punch	104	8	38	Regular
	Mini Sub	104	6	39	Regular
	Square Bass	104	4	39	Regular
	Fat Sine Resonance	104	11	38	Regular
	Ballad Bass	104	7	39	Regular
	House Bass	0	116	38	Regular
	Velo Master	104	17	81	Regular
	Big Drone	0	118	38	Regular
	Sub Bass	0	114	39	Regular
	Hard Bass	0	114	38	Regular
Resonance Bass	0	112	38	Regular	
TB Bass	0	117	39	Regular	

Main Category: STRINGS&VOCAL

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
String Solo	Violin	0	113	40	Sweet!
	Solo Violin	0	112	40	Regular
	Viola	0	112	41	Regular
	Fiddle	0	112	110	Regular
	Cello	0	112	42	Regular
String Ensemble	Contrabass	0	112	43	Regular
	Real Strings	8	33	49	S.Art!
	Classical Strings	8	36	48	S.Art!
	Concert Strings	8	32	49	S.Art!
	Theatre Strings	8	37	48	S.Art!
	Pizzicato	0	113	45	Live!
	Lush Strings	8	41	48	S.Art!
	Real Tremolo Strings	104	0	44	Live!
	Ballroom Strings	8	35	49	S.Art!
	Real Spiccato	104	6	48	Live!
	Studio Strings	8	32	48	S.Art!
	Movie Strings	0	123	48	Live!
	Disco Strings 1	0	123	49	Live!
	Ballad Strings	8	34	49	S.Art!
	Disco Strings 2	0	124	49	Live!
	Warm Strings	8	39	48	S.Art!
	Tremolo Strings	0	113	44	Live!
	Big Strings	8	40	48	S.Art!
	Strings	0	117	49	Live!
	Real Strings f	8	40	49	S.Art!
Allegro	0	122	49	Live!	
Real Strings mf	8	41	49	S.Art!	
Dynamic Strings	0	124	48	Live!	
Real Strings p	8	42	49	S.Art!	

CVP-705**Main Category: STRINGS&VOCAL**

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
String Ensemble	Chamber Strings	0	112	49	Regular
	Real Tremolo Sforzando	104	1	44	Live!
	Tremolo Bowing	8	34	48	S.Art!
	Spiccato	8	33	48	S.Art!
	Spiccato	0	120	48	Live!
	Real Strings f	104	4	49	Live!
	Strings f	0	119	48	Live!
	Real Strings mf	104	5	49	Live!
	Strings mf	0	118	48	Live!
	Real Strings p	104	6	49	Live!
	Strings p	0	117	48	Live!
Orchestral Layers	Tutti	0	120	49	Regular
	Theatre Orchestra	104	1	49	Regular
	Symphonic Unison	104	0	49	Regular
	Pizzicato Glocken	0	115	45	Live!
Choir	Boys Choir Aah	8	33	51	S.Art!
	Boys Choir Ooh	8	32	51	S.Art!
	Boys Choir Aah	104	8	52	Live!
	Boys Choir Ooh	104	8	53	Live!
	Soft Choir Ooh	8	35	51	S.Art!
	Soft Choir Aah	8	36	51	S.Art!
	Boys Choir Oh-Ah (Pedal)	8	34	51	S.Art!
	Boys Choir Oh-Ah	8	49	55	S.Art!
	Gothic Vox	0	113	53	Regular
	Gospel Voices	0	116	52	Live!
	Humming	0	118	52	Live!
	Hah Choir	0	114	52	Regular
	Mmh	0	117	52	Live!

Main Category: BRASS&WOODWIND

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
Brass Solo	Bright Trumpet	8	32	64	S.Art!
	Cornet	0	119	56	Sweet!
	Silver Trumpet	8	33	64	S.Art!
	Muted Trumpet	0	114	59	Sweet!
	Golden Trumpet	8	34	64	S.Art!
	Flugel Horn	0	118	56	Sweet!
	Big Band Trumpet	8	37	64	S.Art!
	Trombone	0	117	57	Sweet!
	Trumpet Fall	8	38	64	S.Art!
	Trumpet	0	115	56	Sweet!
	Trumpet Shake	8	35	64	S.Art!
	Mellow Trumpet	0	120	56	Sweet!
	Silver Trumpet	0	121	56	Sweet!
	Muted Cornet	104	0	59	Sweet!
	Golden Trumpet	0	122	56	Sweet!
	Baritone Horn	0	113	58	Regular
	Tuba	104	0	58	Regular
	Bright Trombone	104	0	57	Sweet!
	Baritone Hit	0	114	58	Regular
	Alp Bass	0	113	33	Regular
Brass Ensemble	Horns	104	0	60	Live!
	Big Band Brass	8	37	56	S.Art!
	Soft Horns	8	32	60	S.Art!
	Smooth Brass	8	36	56	S.Art!
	Symphony Horns 1	104	1	60	Live!
	Dynamic Brass	0	127	61	Live!
	Symphony Horns 2	104	2	60	Live!
	Power Brass	0	121	62	Live!
	Warm Horns	8	33	60	S.Art!
	Accent Brass	0	109	61	Live!
	Stopped Horns	104	3	60	Live!

Main Category: BRASS&WOODWIND

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
Brass Ensemble	Brass Falls f	8	34	56	S.Art!
	Muted Horns	8	34	60	S.Art!
	Brass Falls mf	8	35	56	S.Art!
	Brass f	0	108	61	Live!
	Brass Band	0	123	56	Live!
	Brass mf	0	110	61	Live!
	Soft Horns	0	117	60	Live!
	Brass p	0	111	61	Live!
	Soft Trombones	0	118	60	Live!
	Brass Shake	8	32	56	S.Art!
	Pop Brass	0	117	62	Live!
	Accent Falls	8	38	56	S.Art!
	Hyper Brass	0	118	62	Live!
	Sforzando	0	105	61	Live!
	Small Brass	0	120	60	Live!
	Sforzando Fall	0	107	61	Live!
Ballroom Brass	0	113	59	Regular	
Brass Dynamics	0	106	61	Live!	
Octave Brass	0	116	62	Live!	
Sax Solo	Saxophone	8	32	82	S.Art!
	Alto Sax	8	32	66	S.Art!
	Big Band Sax	8	35	82	S.Art!
	Soft Alto Sax	8	34	66	S.Art!
	Rock Sax	8	33	82	S.Art!
	Growl Sax	0	111	66	Sweet!
	Soprano Sax	0	113	64	Sweet!
	Pop Tenor Sax	0	127	66	Sweet!
	Pop Alto Sax	104	0	65	Sweet!
	Ballad Tenor Sax	0	126	66	Sweet!
	Breathy Tenor Sax	0	117	66	Sweet!
	Jazz Tenor Sax	0	125	66	Sweet!
	Baritone Sax	104	0	67	Regular
	Sax Ensemble	Sax Section	8	36	82
Big Band Octave		0	108	66	Live!
Sax Section Unison		8	38	82	S.Art!
Big Band Unison		0	109	66	Live!
Sax Section Fast Attack		0	116	66	Live!
Big Band Saxes		0	110	66	Live!
Sax Section Octave		8	37	82	S.Art!
Ballad Section		0	119	66	Regular
Soft Saxes		8	39	82	S.Art!
Sax Appeal		0	123	66	Live!
Sax Section Hard		0	122	66	Live!
Moonlight		0	115	71	Regular
Sax Section Soft		0	121	66	Live!
Woodwind Solo	Orchestral Flute	8	32	73	S.Art!
	Jazz Flute	0	114	73	Sweet!
	Orchestral Oboe	8	32	68	S.Art!
	Classical Oboe	0	113	68	Sweet!
	Orchestral Clarinet	104	0	71	Live!
	Jazz Clarinet	0	114	71	Sweet!
	Orchestral Bassoon	104	0	70	Sweet!
	Bassoon	0	112	70	Regular
	German Clarinet	104	2	71	Regular
	Classical Flute	0	115	73	Sweet!
	Piccolo	0	112	72	Regular
	Oboe	0	112	68	Regular
	Clarinet	0	112	71	Regular
English Horn	0	112	69	Regular	
Woodwind Ens	Flutes & Oboes	104	2	73	Regular
	Orchestral Woodwind	104	1	70	Regular
	Clarinet & Flutes	104	1	71	Regular
	Alto Flutes	104	1	73	Regular
	Clarinet & Oboe	104	1	68	Regular

CVP-705**Main Category: BRASS&WOODWIND**

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
Woodwind Ens	Flute Ensemble	0	116	73	Regular
	Oboe & Bassoon	104	2	68	Regular
Woodwind World	Ballad Pan Flute	0	113	75	Sweet!
	Chiff Pan Flute	0	113	73	Regular
	Celtic Duo	0	120	73	Regular
	Ethnic Flute	0	112	75	Regular
	Bagpipe	0	112	109	Regular
	Ocarina	0	112	79	Regular
	Recorder	0	112	74	Regular
	Shakuhachi	0	112	77	Regular
	Whistle	0	112	78	Regular

Main Category: PERC&DRUMS

Sub Category 1	Voice Name	Voice Number			Voice Type	
		MSB	LSB	Prg		
Chromatic Perc	Vibraphone	104	1	11	Sweet!	
	Xylophone	104	0	13	Regular	
	Jazz Vibraphone	0	113	11	Regular	
	Marimba	104	0	12	Regular	
	Tremolo Vibraphone	0	124	11	Natural!	
	Vibraphone	0	122	11	Natural!	
	Vibraphone & JazzGt	8	33	11	S.Art!	
	Glockenspiel	104	0	9	Regular	
	Vibraphone & Flutes	0	114	11	Regular	
	Steel Drums	0	112	114	Regular	
	Music Box	0	112	10	Regular	
	Kalimba	0	112	108	Regular	
	Orchestral Perc	Orchestral Harp	104	1	46	Regular
		Tubular Bells	0	112	14	Regular
Mellow Harp		104	0	46	Regular	
Timpani		0	112	47	Regular	
Orchestra Hit		0	112	55	Regular	
Celesta		0	112	8	Regular	
Drum Kits	Real Drums	127	0	91	Live!Drums	
	Power Kit 1	127	0	87	Live!Drums	
	Real Brushes	127	0	41	Live!Drums	
	Power Kit 2	127	0	88	Live!Drums	
	Acoustic Kit	127	0	89	Live!Drums	
	House Kit	127	0	60	Drums	
	Rock Kit	127	0	90	Live!Drums	
	Drum Machine	127	0	61	Drums	
	Studio Kit	127	0	86	Live!Drums	
	Analog T8 Kit	127	0	58	Drums	
	Analog T9 Kit	127	0	59	Drums	
	Jazz Kit	127	0	32	Drums	
	Break Kit	127	0	57	Drums	
	Hit Kit	127	0	4	Drums	
	Hip Hop Kit	127	0	56	Drums	
	Room Kit	127	0	8	Drums	
	Dance Kit	127	0	27	Drums	
	Electro Kit	127	0	24	Drums	
	Analog Kit	127	0	25	Drums	
	Symphony Kit	127	0	48	Live!Drums	
	Brush Kit	127	0	40	Live!Drums	
	World Perc Kits	Turkish Kit	126	0	67	Live!SFX
Cuban Kit		126	0	40	Live!SFX	
Pop Latin Kit		126	0	43	Live!SFX	
SFX	New SFX Kit 1	126	0	2	Live!SFX	
	Helicopter	104	0	125	Live!	
	New SFX Kit 2	126	0	3	Live!SFX	
	Applause 1	104	0	126	Live!	
	Noises Kit	126	0	8	SFX	
	Applause 2	104	1	126	Live!	

Main Category: PERC&DRUMS

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
SFX	Sea Shore	104	0	122	Live!
	Gun Shot	104	0	127	Live!
	SFX Kit 1	126	0	0	SFX
	SFX Kit 2	126	0	1	SFX
	Magic Bell	8	32	120	S.Art!

Main Category: SYNTH

Sub Category 1	Voice Name	Voice Number			Voice Type	
		MSB	LSB	Prg		
Synth Lead	Sub Lead	104	0	80	Regular	
	Wire Lead	0	120	81	Regular	
	Soft Saw	104	16	81	Regular	
	Soft R&B	0	119	80	Regular	
	Fusion Lead	104	15	81	Regular	
	Early Lead	0	118	81	Regular	
	Oxygen	0	122	81	Regular	
	Soft Square	104	5	80	Regular	
	Matrix	0	123	81	Regular	
	Detuned Vintage	104	1	84	Regular	
	PWM Lead	104	1	81	Regular	
	Hipa Lead	0	118	84	Regular	
	Brassy Lead	104	5	62	Regular	
	Punchy Hook	0	127	81	Regular	
	Punch Lead	104	7	81	Regular	
	Crying Lead	0	114	87	Regular	
	Flange Filter	104	2	81	Regular	
	Hip Lead	0	113	80	Regular	
	Mouth Lead	104	0	81	Regular	
	Hop Lead	0	117	80	Regular	
	Tech Lead	0	117	84	Regular	
	Analogon	0	115	81	Regular	
	Tekkline	0	116	84	Regular	
	Skyline	0	115	84	Regular	
	Soft Mini	0	124	80	Regular	
	Bleep Lead	104	0	84	Regular	
	Fire Wire	0	116	81	Regular	
	Orbit Sine	0	126	80	Regular	
	Synth Perc	New Heaven	104	10	88	Regular
		Heaven Pad	104	3	91	Regular
		Fantasy Bells	104	11	88	Regular
		Breath Bells	104	15	88	Regular
Itopia Bells		104	13	88	Regular	
Next Generation		104	9	51	Regular	
Sinesphere		104	18	88	Regular	
Organ Bells		104	12	88	Regular	
Spectrum Theme		104	14	88	Regular	
Sky Bells		104	16	88	Regular	
Flying Harmonics		104	1	99	Regular	
Nylon Heaven		104	2	99	Regular	
Airy Harp		104	17	88	Regular	
Nylon Pad		104	0	99	Regular	
Simple Comp		104	12	81	Regular	
Bellsphere		104	5	88	Regular	
Ballad Comp		104	6	88	Regular	
Perc Pad		104	0	101	Regular	
Heaven Bell		104	0	100	Regular	
Mediterrain		0	114	99	Regular	
Bright Pad Bell		104	7	88	Regular	
Lektro Codes		104	2	84	Regular	
Wild PWM		104	4	80	Regular	
Resonant Clavi	104	2	90	Regular		
Perc Sequence FM 1	104	7	87	Regular		
Resonance Comp	104	4	62	Regular		

CVP-705**Main Category: SYNTH**

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
Synth Perc	Perc Sequence FM 2	104	8	87	Regular
	Digital Sequenced	104	2	87	Regular
	Synth Sticks	104	0	106	Regular
	Analog Sequenced	104	3	87	Regular
	Saz Feeze	104	0	97	Regular
	Perc Sequence FS	104	6	87	Regular
	Eastern Air	104	1	97	Regular
	Xtune	104	1	87	Regular
	Nomad	104	1	104	Regular
	Perc Sequence Saw	104	11	81	Regular
	Stack Bell	104	8	88	Regular
	Attack	104	4	81	Regular
	Nice Bell	104	9	88	Regular
	PWM Percussion	104	6	81	Regular
Synth Strings	Synth Strings 1	0	112	50	Regular
	Butter Strings	104	2	50	Regular
	Synth Strings 2	0	113	50	Regular
	Bright Saw Pad	0	113	90	Regular
	Light Pad	104	2	51	Regular
	Ober Strings	0	113	51	Regular
	Hipa Strings	0	114	95	Regular
	80s Pad	104	1	51	Regular
	Octave Strings	104	4	50	Regular
	Bright Pop Pad	104	3	50	Regular
	Medium Tune Pad	104	0	50	Regular
	Doux Flange	104	3	95	Regular
	Premium Pad	104	0	51	Regular
	Bright Pad Classic	104	3	90	Regular
Soft Ensemble	104	1	50	Regular	
Synth Brass	Analog Brass	0	112	63	Regular
	1984 Synth	104	20	81	Regular
	Fat Synth Brass	0	116	63	Regular
	80s Brass	0	113	62	Regular
	Thin Brass	104	0	62	Regular
	Funky Analog	0	115	62	Regular
	Brass Profit	104	1	62	Regular
	Techno Brass	0	114	62	Regular
	Ober Brass	0	113	63	Regular
	Ober Horns	0	115	63	Regular
	Slow PWM Brass	104	2	62	Regular
	Soft Velo Brass	0	120	62	Regular
	Fast PWM Brass	104	6	62	Regular
	Soft Analog	0	114	63	Regular
Synth Pad	All or Nothing	104	6	101	Regular
	Whisper Gallery	104	0	92	Regular
	Digisweeper	104	7	101	Regular
	Hybrid Lines	104	4	91	Regular
	Spectrum Pad	104	5	94	Regular
	Midnight Special	104	3	101	Regular
	Hybrid Pad	104	22	88	Regular
	Atmo 5th	104	6	89	Regular
	Deep Motion	104	4	95	Regular
	Pad Voices	104	6	95	Live!
	Skydiver	0	112	101	Regular
	Aerosphere	104	1	94	Regular
	Cross Phase	104	1	101	Regular
	New Atmosphere	104	4	89	Regular
	Galaxy Pad	104	3	88	Regular
	VP Soft	104	0	89	Regular
	Night Motion	104	4	88	Regular
	Hot Swell	104	2	95	Regular
	Morning Dew	104	0	94	Regular
	Dark Fat Saw	104	2	89	Regular
	Vapor Pad	104	1	89	Regular

Main Category: SYNTH

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
Synth Pad	Dark Light	104	3	89	Regular
	Space Rider	104	1	95	Regular
	Ambient Pad	104	0	88	Regular
	Pearls Pad	104	2	88	Regular
	Bright Fat Saw	104	5	90	Regular
	Breath Pad	104	0	91	Regular
	Early Digital	104	0	93	Regular
	Noble Man	104	1	88	Regular
	Super Dark Pad	0	119	89	Regular
	Analog Pad	0	120	89	Regular
	Analog Swell	0	119	95	Regular
	Dark Angel Pad	0	121	89	Regular
	Big Octave Pad	0	115	90	Regular
	Lite Pad	0	122	89	Regular
	Golden Age	0	115	88	Regular
	Pop Pad	0	112	90	Regular
	Solaris	0	114	94	Regular
	Glorious Phase	0	114	90	Regular
	Insomnia	0	113	94	Regular
	Ober Sweep	0	115	95	Regular
	Neo Warm Pad	0	115	89	Regular
	Time Travel	0	116	88	Regular
	Cyber Pad	0	113	99	Regular
	Bubblespace	0	113	101	Regular
	Bright Ober	0	113	95	Regular
	Mellow Pad	0	117	95	Regular
	Dark Pad	0	118	95	Regular
Synth Dance	Ana Dayz	104	3	51	Regular
	HPF Dance	104	0	90	Regular
	Bright Pad Trance	104	4	90	Regular
	Detuned Saw Octave	104	8	81	Regular
	Chillin Chords	104	6	51	Regular
	Dancy Hook	104	9	81	Regular
	Trance (Pedal)	104	0	95	Regular
	Vinalog Saw	104	3	81	Regular
	Club Lead	104	3	62	Regular
	Talk Mod Lead	104	0	87	Regular
	Trance Perc	104	5	81	Regular
	Chorus Saw Lead	104	10	81	Regular
	Chordmaster	104	13	81	Regular
	Faat Comp	104	4	51	Regular
	Trance Sequence 1	104	4	87	Regular
	Fat Saw Hook	104	7	51	Regular
	Trance Sequence 2	104	5	87	Regular
Tech Glide	104	14	81	Regular	
Trance Sequence 3	104	1	90	Regular	
Dance Chords	104	5	51	Regular	
Dance Hook	0	112	86	Regular	
Trance Lead	0	121	80	Regular	
Octave Hook	0	113	86	Regular	
Synth Effects	Water Games	104	4	101	Regular
	Spectralis	104	4	94	Regular
	My Generation	104	5	101	Regular
	Metallic Rain	104	8	101	Regular
	Rainy Day	104	5	89	Regular
	Ambient Theme	104	20	88	Regular
	Warped Waves	104	2	94	Regular
	Reflecting Zone	104	21	88	Regular
	Sound Pictures	104	3	94	Regular
	The Fog	104	9	101	Regular
	Mystic Pad	104	6	94	Regular
	Randomizer	104	10	101	Regular
	Atlantis	104	11	101	Regular
	Tric-Trac	104	2	97	Regular

CVP-705

Main Category: SYNTH

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
Synth Effects	Sixth Sense	104	2	101	Regular
	Perc Sequence Hipa	104	9	87	Regular
	Pitch Fall	104	0	103	Regular

Main Category: OTHERS

Sub Category 1	Sub Category 2	Voice Name	Voice Number			Voice Type	
			MSB	LSB	Prg		
Legacy	Piano	Stage Piano	104	10	0	Natural!	
		Studio Grand	0	115	0	Live!	
		Grand Piano	0	113	0	Live!	
		Rock Piano	104	4	0	Live!	
		Pop Grand	104	5	0	Live!	
		Pop Grand 2	104	11	0	Natural!	
		Warm Grand	0	114	0	Live!	
		Bright Piano	0	112	1	Live!	
		Ambient Piano	104	3	0	Live!	
		Cocktail Piano	104	0	3	Live!	
		Honky Tonk	0	122	3	Natural!	
		Honky Tonk	0	112	3	Regular	
		Grand Piano 1octave	104	2	3	Natural!	
		Grand Piano 2octaves	104	3	3	Natural!	
		Octave Piano 1	0	113	3	Live!	
		Octave Piano 2	0	114	3	Live!	
		Piano Orchestra	104	2	0	Live!	
		MIDI Grand	0	112	2	Regular	
		Harpsichord	0	112	6	Live!	
		E.Piano	Ballad Stack	0	114	2	Regular
			Chorus Bell	0	120	5	Regular
			Funk EP	0	112	4	Regular
			Hyper Tines	0	113	5	Regular
			Jazz Chorus	0	118	5	Regular
			Modern EP	0	115	5	Regular
			New Tines	0	116	5	Regular
			Phase EP	0	120	4	Regular
			DX Modern	0	112	5	Regular
	Polaris EP		0	115	4	Regular	
	Super DX		0	117	5	Regular	
	Venus EP		0	114	5	Regular	
	Stereo Clavi		0	114	7	Regular	
	Organ		Bright Drawbar	0	116	16	Regular
			Click Organ	0	112	17	Regular
			Dance Organ	0	113	17	Regular
			Drawbar Organ 1	0	120	17	Regular
			Drawbar Organ 2	0	115	16	Regular
		Electric Organ	0	118	17	Regular	
		Full Rocker 2	104	3	18	Cool!	
		Gospel Organ	0	119	16	Regular	
		Jazz Organ 1	0	112	16	Regular	
		Jazz Organ 2	0	113	16	Regular	
		Jazz Organ 3	0	120	16	Regular	
		Percussive Organ	0	119	17	Regular	
		Purple Organ	0	114	18	Regular	
		Rock Organ 1	0	112	18	Regular	
		Rock Organ 2	0	119	18	Regular	
		Rock Organ 3	0	113	18	Regular	
		Rotary Drive	0	116	18	Regular	
		Rotary Switch	0	110	17	Cool!	
		60s Organ	0	116	17	Regular	
		Reed Organ	0	112	20	Regular	
		Tibia 8'&4' Accomp	0	122	16	Regular	
		Tibia 16'&4' Accomp	0	114	16	Regular	
		Tibia Full Accomp	0	114	17	Regular	
		Tibia 8' Accomp	0	122	17	Regular	

Main Category: OTHERS

Sub Category 1	Sub Category 2	Voice Name	Voice Number			Voice Type	
			MSB	LSB	Prg		
Legacy	Organ	Vox 8' Accomp	0	123	17	Regular	
		Vox & Tibia Accomp	0	125	16	Regular	
		Classic Jazz	0	126	16	OrganFlutes	
	A.Guitar	Folk Guitar	0	112	25	Regular	
		Campfire Guitar	0	115	25	Regular	
		18String Guitar	0	119	25	Regular	
	E.Guitar	70s Solid Guitar	104	1	27	Cool!	
		Bright Clean	0	116	27	Regular	
		Chorus Guitar	0	124	27	Regular	
		Clean Solid	104	3	27	Cool!	
		Deep Chorus	0	114	27	Regular	
		Electric 12String	0	119	27	Regular	
		Funk Guitar	0	113	28	Regular	
		Muted Guitar	0	112	28	Regular	
		Slapback	104	0	27	Cool!	
		Solid Chord	0	121	27	Regular	
		Solid Guitar	0	118	27	Regular	
		Tremolo Guitar	0	113	27	Regular	
		Vintage Amp	8	40	3	S.Art!	
		Warm Solid	104	2	27	Cool!	
		DX Jazz Guitar	0	117	26	Regular	
		Crunch Guitar	0	113	30	Regular	
		Distortion Guitar	0	112	30	Regular	
		Guitar Hero	104	0	30	Cool!	
		Heavy Rock	104	1	30	Cool!	
		Heavy Stack	0	114	30	Regular	
		Lead Guitar	0	114	29	Regular	
		Power Chord	0	117	30	Regular	
		Power Lead	0	115	30	Cool!	
		Rock Guitar	0	116	29	Regular	
		Feedback Guitar	0	113	29	Regular	
		Half Drive	104	0	29	Cool!	
		Overdrive Guitar	0	112	29	Regular	
		Smooth Lead	0	119	26	Regular	
		Vintage Amp	0	115	29	Regular	
		Vintage Lead	0	125	27	Cool!	
		Vintage Trem	0	120	27	Regular	
		Voodoo Lead	0	116	30	Regular	
		Wah Guitar	0	122	27	Regular	
		Bass	Acoustic Bass	0	112	32	Regular
			80s Synth Bass	0	115	39	Regular
			Analog Bass	0	112	39	Regular
			Click Bass	0	115	38	Regular
			Dry Synth Bass	0	116	39	Regular
			DX Funk Bass	0	113	37	Regular
			HiQ Bass	0	113	38	Regular
			Punchy Bass	0	117	38	Regular
			Accordion	Accordion	0	116	21
	Ballroom Accordion			0	112	23	Regular
	Musette Accordion	0		112	21	Regular	
	Small Accordion	0		115	21	Regular	
	Soft Accordion	0		114	21	Regular	
	Tutti Accordion	0		113	21	Regular	
	Strings	Bow Strings	0	116	48	Regular	
		Concerto Strings	0	115	48	Regular	
		Marcato	0	115	49	Regular	
		Orch Strings	0	113	48	Regular	
		Orchestra Strings	0	116	49	Live!	
		Pizzicato	0	112	45	Regular	
		Slow Strings	0	113	49	Regular	
		String Falls	0	121	48	Live!	
		Strings	0	112	48	Regular	
		Symphonic	0	114	48	Regular	
		Tremolo Strings	0	112	44	Regular	

CVP-705**Main Category: OTHERS**

Sub Category 1	Sub Category 2	Voice Name	Voice Number			Voice Type	
			MSB	LSB	Prg		
Legacy	Strings	Orch & Flute	0	119	49	Regular	
		Orch & Oboe	0	121	49	Regular	
		String Quartet	0	114	49	Regular	
		Orch & Horns	0	118	49	Regular	
		Analog Strings	0	112	51	Regular	
		Harp	0	112	46	Regular	
		Hackbrett 2	0	113	46	Regular	
		Banjo 2	0	112	105	Regular	
		Sitar 2	0	112	104	Regular	
		Brass	Solo Trumpet	0	112	56	Regular
Jazz Trumpet	0		116	56	Regular		
Muted Trumpet	0		112	59	Regular		
Flugel Horn	0		113	56	Regular		
Solo Trombone	0		112	57	Regular		
Trombone	0		116	57	Regular		
Soft Trombone	0		115	57	Regular		
Mellow Trombone	0		114	57	Regular		
Smooth Trombone	0		118	57	Regular		
Tuba 2	0		112	58	Regular		
Big Band Brass	0		113	61	Regular		
Big Brass	0		121	61	Regular		
Brass Combo	0		115	66	Regular		
Brass Hit	0		126	61	Regular		
Brass Section	0		112	61	Regular		
Breath Brass	0		116	60	Regular		
Bright Brass	0		120	61	Regular		
Full Horns	0		114	61	Regular		
High Brass	0		115	61	Regular		
Mellow Brass	0		116	61	Regular		
Natural Brass	0		124	61	Regular		
Storzando	0		125	61	Regular		
Small Brass	0		117	61	Regular		
Soft Brass	0		123	61	Regular		
Symphony Brass	0		119	60	Live!		
Trumpet Ensemble	0		122	61	Regular		
French Horns	0		112	60	Live!		
Mellow Horns	0		119	61	Regular		
Symphony Horns	0		115	60	Live!		
Trombone Section	0		113	57	Regular		
Hybrid Comp	0		119	62	Regular		
Hybrihorn	0		113	60	Regular		
Hybripad	0		114	60	Regular		
Pop Brass	0		118	61	Regular		
Synth Brass	0		112	62	Regular		
Woodwind	Soprano Sax		0	112	64	Regular	
	Alto Sax		0	114	65	Sweet!	
	Alto Sax		0	112	65	Regular	
	Saxophone		104	0	66	Sweet!	
	Tenor Sax		0	112	66	Regular	
	Growl Sax		0	118	66	Regular	
	Baritone Sax		0	112	67	Regular	
	Orch Flute		104	0	73	Sweet!	
	Orch Oboe		104	0	68	Sweet!	
	Flute		0	112	73	Regular	
	Sax Stack		0	124	66	Regular	
	Saxy Mood		0	120	66	Regular	
	Woodwinds Ensemble		0	113	66	Regular	
	Choir		Air Choir	0	112	54	Regular
			Choir	0	112	52	Regular
		Uuh Choir	0	115	52	Regular	
		Voices	0	113	54	Regular	
		Vox Humana	0	112	53	Regular	
Bell Heaven		0	119	88	Regular		
Dream Heaven		0	121	88	Regular		

Main Category: OTHERS

Sub Category 1	Sub Category 2	Voice Name	Voice Number			Voice Type
			MSB	LSB	Prg	
Legacy	Choir	Sweet Heaven	0	118	88	Regular
		Hah Pad	0	116	94	Regular
		Pan Heaven	0	120	88	Regular
		Pro Heaven	0	122	88	Regular
		Sunbeam	0	123	88	Regular
		Percussion	Xylophone	0	112	13
	Marimba		0	112	12	Regular
	Vibraphone		0	112	11	Regular
	Glockenspiel		0	112	9	Regular
	Drum Kit	Standard Kit 1	127	0	0	Live!Drums
Standard Kit 2		127	0	1	Live!Drums	
Rock Kit		127	0	16	Drums	
Arabic Kit		126	0	35	SFX	
Pad	Angel Vibes	0	114	98	Regular	
	Area 51	0	112	89	Regular	
	Atmosphere	0	112	99	Regular	
	Dark Moon	0	113	89	Regular	
	Digital Pad	0	115	93	Regular	
	Disclosure	0	116	89	Regular	
	Dunes	0	114	89	Regular	
	DX Pad	0	112	92	Regular	
	Equinox	0	112	94	Regular	
	Evening Stars	0	117	101	Regular	
	Fantasia	0	112	88	Regular	
	Far East	0	112	97	Regular	
	Glass Pad	0	114	93	Regular	
	Ionosphere	0	115	94	Regular	
	Messenger	0	116	95	Regular	
	Millennium	0	117	88	Regular	
	Mystery	0	113	97	Regular	
	Psycho Pad	0	118	101	Regular	
	S&H Groove	0	115	101	Regular	
	Sirius	0	114	101	Regular	
	Stargate	0	114	88	Regular	
	Symbiont	0	113	88	Regular	
	Velo Ashrami	0	116	101	Regular	
	Wave 2001	0	112	95	Regular	
	Xenon Pad	0	112	91	Regular	
	Synth	Adrenaline	0	113	84	Regular
		Aero Lead	0	112	83	Regular
		Attack Saw	0	126	81	Regular
Big Lead		0	113	81	Regular	
Big Tune		0	118	89	Regular	
Blaster		0	114	81	Regular	
Bright Mini		0	125	80	Regular	
Crystal Eyes		0	125	88	Regular	
Fargo		0	119	81	Regular	
Funky Lead		0	121	81	Regular	
Hi Bias		0	116	80	Regular	
Impact		0	113	87	Regular	
Melody Maker		0	117	89	Regular	
Mini Lead		0	114	80	Regular	
Padbells		0	126	88	Regular	
Pan Lead		0	122	80	Regular	
Paraglide		0	114	84	Regular	
Perc Square		0	123	80	Regular	
Pop Lead		0	120	80	Regular	
Portatone		0	112	84	Regular	
Pro Lead		0	113	83	Regular	
Robolead		0	124	81	Regular	
Saw Lead		0	112	81	Regular	
Square Lead		0	112	80	Regular	
Stardust		0	112	98	Regular	
String Bells		0	124	88	Regular	

CVP-705

Main Category: OTHERS

Sub Category 1	Sub Category 2	Voice Name	Voice Number			Voice Type	
			MSB	LSB	Prg		
Legacy	Synth	Sun Bell	0	113	98	Regular	
		Tiny Lead	0	118	80	Regular	
		Trumpet Saw	0	125	81	Regular	
		Under Heim	0	112	87	Regular	
		Vinyl Lead	0	115	80	Regular	
		Warp	0	117	81	Regular	
MegaVoices	A.Guitar	Nylon Guitar	8	0	0	MegaVoice	
		Steel Guitar	8	0	1	MegaVoice	
		12String Guitar	8	1	2	MegaVoice	
		Hi String Guitar	8	0	2	MegaVoice	
		E.Guitar	Finger Guitar	8	4	3	MegaVoice
	Finger Slap Guitar		8	5	3	MegaVoice	
	Vintage Pick Guitar		8	6	3	MegaVoice	
	Vintage Slap Guitar		8	7	3	MegaVoice	
	Slap Amp Guitar		8	8	3	MegaVoice	
	Single Coil Guitar		8	3	3	MegaVoice	
	Solid Guitar 1		8	1	3	MegaVoice	
	Solid Guitar 2		8	2	3	MegaVoice	
	Clean Guitar		8	0	3	MegaVoice	
	Jazz Guitar		8	0	6	MegaVoice	
	Overdrive Guitar		8	0	4	MegaVoice	
	Distortion Guitar		8	0	5	MegaVoice	
	Bass		Vintage Round	8	1	17	MegaVoice
			Vintage Flat	8	2	17	MegaVoice
			Vintage Pick	8	1	18	MegaVoice
		Electric Bass	8	0	17	MegaVoice	
		Pick Bass	8	0	18	MegaVoice	
		Acoustic Bass	8	0	16	MegaVoice	
		Fretless Bass	8	0	19	MegaVoice	
	Strings	Classical Strings	8	1	48	MegaVoice	
		Real Strings	8	1	49	MegaVoice	
		Large Strings	8	0	49	MegaVoice	
		Small Strings	8	0	48	MegaVoice	
	Brass	Trumpet	8	0	64	MegaVoice	
		Brass	8	0	56	MegaVoice	
	Woodwind	Tenor Sax	8	0	82	MegaVoice	

CVP-709/CVP-705

Main Category: OTHERS

Sub Category 1	Sub Category 2	Voice Name	Voice Number			Voice Type	
			MSB	LSB	Prg		
GM&XG	Piano	GrandPiano	0	0	0	Regular	
		GrndPianoKSP	0	1	0	Regular	
		MellowGrPno	0	18	0	Regular	
		PianoStrings	0	40	0	Regular	
		Dream	0	41	0	Regular	
		BrightPiano	0	0	1	Regular	
		BritePnoKSP	0	1	1	Regular	
		ElecGrandPno	0	0	2	Regular	
		ElecGrPnoKSP	0	1	2	Regular	
		DetunedCP80	0	32	2	Regular	
		LayeredCP1	0	40	2	Regular	
		LayeredCP2	0	41	2	Regular	
		Honkytonk	0	0	3	Regular	
		HonkytonkKSP	0	1	3	Regular	
		EI.Piano1	0	0	4	Regular	
		EI.Piano1KSP	0	1	4	Regular	
		MellowEP1	0	18	4	Regular	
		ChorusEP1	0	32	4	Regular	
		HardEI.Piano	0	40	4	Regular	
		VXfadeEI.P1	0	45	4	Regular	
		60sEI.Piano1	0	64	4	Regular	
		EI.Piano2	0	0	5	Regular	
		EI.Piano2KSP	0	1	5	Regular	
		ChorusEP2	0	32	5	Regular	
		DXEPHard	0	33	5	Regular	
		DXLegend	0	34	5	Regular	
		DXPhaseEP	0	40	5	Regular	
		DX+AnalogEP	0	41	5	Regular	
		DXKotoEP	0	42	5	Regular	
		VXfadeEI.P2	0	45	5	Regular	
		Harpsichord	0	0	6	Regular	
		Harpsi.KSP	0	1	6	Regular	
		Harpsichord2	0	25	6	Regular	
		Harpsichord3	0	35	6	Regular	
		Clavi.	0	0	7	Regular	
		Clavi.KSP	0	1	7	Regular	
		Clavi.Wah	0	27	7	Regular	
		PulseClavi.	0	64	7	Regular	
		PierceClavi.	0	65	7	Regular	
		Chromatic Perc	Celesta	0	0	8	Regular
			Glockenspiel	0	0	9	Regular
			MusicBox	0	0	10	Regular
			Orgel	0	64	10	Regular
			Vibraphone	0	0	11	Regular
			VibesKSP	0	1	11	Regular
			HardVibes	0	45	11	Regular
			Marimba	0	0	12	Regular
			MarimbaKSP	0	1	12	Regular
			SineMarimba	0	64	12	Regular
			Balimba	0	97	12	Regular
			LogDrums	0	98	12	Regular
			Xylophone	0	0	13	Regular
			TubularBells	0	0	14	Regular
			ChurchBells	0	96	14	Regular
			Carillon	0	97	14	Regular
			Dulcimer	0	0	15	Regular
			Dulcimer2	0	35	15	Regular
			Cimbalom	0	96	15	Regular
			Santur	0	97	15	Regular
		Organ	DrawbarOrgan	0	0	16	Regular
			DetDrawOrgan	0	32	16	Regular
			60sDrawOrg1	0	33	16	Regular
60sDrawOrg2	0		34	16	Regular		
70sDrawOrg1	0		35	16	Regular		

CVP-709/CVP-705

Main Category: OTHERS

Sub Category 1	Sub Category 2	Voice Name	Voice Number			Voice Type
			MSB	LSB	Prg	
GM&XG	Organ	DrawbarOrg2	0	36	16	Regular
		60sDrawOrg3	0	37	16	Regular
		EvenBarOrg	0	38	16	Regular
		16+2'2_3Org	0	40	16	Regular
		OrganBass	0	64	16	Regular
		70sDrawOrg2	0	65	16	Regular
		CheezyOrgan	0	66	16	Regular
		DrawbarOrg3	0	67	16	Regular
		Perc.Organ	0	0	17	Regular
		70sPercOrg1	0	24	17	Regular
		DetPercOrgan	0	32	17	Regular
		LightOrgan	0	33	17	Regular
		Perc.Organ2	0	37	17	Regular
		RockOrgan	0	0	18	Regular
		RotaryOrgan	0	64	18	Regular
		SlowRotary	0	65	18	Regular
		FastRotary	0	66	18	Regular
		ChurchOrgan	0	0	19	Regular
		ChurchOrgan3	0	32	19	Regular
		ChurchOrgan2	0	35	19	Regular
		NotreDame	0	40	19	Regular
		OrganFlute	0	64	19	Regular
	Trem.OrganFl	0	65	19	Regular	
	ReedOrgan	0	0	20	Regular	
	PuffOrgan	0	40	20	Regular	
	Accordion	0	0	21	Regular	
	AccordIt	0	32	21	Regular	
	Harmonica	0	0	22	Regular	
	Harmonica2	0	32	22	Regular	
	TangoAccord	0	0	23	Regular	
	TangoAccord2	0	64	23	Regular	
	Guitar	NylonGuitar	0	0	24	Regular
		NylonGuitar2	0	16	24	Regular
		NylonGuitar3	0	25	24	Regular
		VelGtrHarmo	0	43	24	Regular
		Ukulele	0	96	24	Regular
		SteelGuitar	0	0	25	Regular
		SteelGuitar2	0	16	25	Regular
		12StrGuitar	0	35	25	Regular
		Nylon&Steel	0	40	25	Regular
		Steel&Body	0	41	25	Regular
		Mandclin	0	96	25	Regular
		JazzGuitar	0	0	26	Regular
		MellowGuitar	0	18	26	Regular
		JazzAmp	0	32	26	Regular
		CleanGuitar	0	0	27	Regular
		ChorusGuitar	0	32	27	Regular
		MutedGuitar	0	0	28	Regular
		FunkGuitar1	0	40	28	Regular
		MuteSteelGtr	0	41	28	Regular
		FunkGuitar2	0	43	28	Regular
		JazzMan	0	45	28	Regular
		Overdriven	0	0	29	Regular
GuitarPinch		0	43	29	Regular	
Distortion		0	0	30	Regular	
FeedbackGtr		0	40	30	Regular	
FeedbackGtr2		0	41	30	Regular	
GtrHarmonics		0	0	31	Regular	
GtrFeedback		0	65	31	Regular	
GtrHarmonic2	0	66	31	Regular		
Bass	AcousticBass	0	0	32	Regular	
	JazzRhythm	0	40	32	Regular	
	VXUprghtBass	0	45	32	Regular	
	FingerBass	0	0	33	Regular	

Main Category: OTHERS

Sub Category 1	Sub Category 2	Voice Name	Voice Number			Voice Type
			MSB	LSB	Prg	
GM&XG	Bass	FingerDark	0	18	33	Regular
		FlangeBass	0	27	33	Regular
		Bass&DistEG	0	40	33	Regular
		FingerSlap	0	43	33	Regular
		FingerBass2	0	45	33	Regular
		Mod.Bass	0	65	33	Regular
		PickBass	0	0	34	Regular
		MutePickBass	0	28	34	Regular
		FretlessBass	0	0	35	Regular
		Fretless2	0	32	35	Regular
		Fretless3	0	33	35	Regular
		Fretless4	0	34	35	Regular
		Syn.Fretless	0	96	35	Regular
		SmthFretless	0	97	35	Regular
		SlapBass1	0	0	36	Regular
		ResonantSlap	0	27	36	Regular
		PunchThumb	0	32	36	Regular
		SlapBass2	0	0	37	Regular
		Velo.Sw.Slap	0	43	37	Regular
		SynthBass1	0	0	38	Regular
		SynBass1Dark	0	18	38	Regular
		FastResoBass	0	20	38	Regular
		AcidBass	0	24	38	Regular
		ClaviBass	0	35	38	Regular
		TechnoBass	0	40	38	Regular
		Orbiter	0	64	38	Regular
		SquareBass	0	65	38	Regular
		RubberBass	0	66	38	Regular
		Hammer	0	96	38	Regular
		SynthBass2	0	0	39	Regular
		MellowSyBass	0	6	39	Regular
	SequenceBass	0	12	39	Regular	
	ClickSynBass	0	18	39	Regular	
	SynBass2Dark	0	19	39	Regular	
	SmoothSyBass	0	32	39	Regular	
	ModulrSyBass	0	40	39	Regular	
	DXBass	0	41	39	Regular	
	XWireBass	0	64	39	Regular	
	Strings	Violin	0	0	40	Regular
		SlwAtkViolin	0	8	40	Regular
		Viola	0	0	41	Regular
		Cello	0	0	42	Regular
		Contrabass	0	0	43	Regular
		Trem.Strings	0	0	44	Regular
		SlwAtTremStr	0	8	44	Regular
		SuspenseStr	0	40	44	Regular
		PizzicatoStr	0	0	45	Regular
		Orch.Harp	0	0	46	Regular
	YangQin	0	40	46	Regular	
	Timpani	0	0	47	Regular	
	Ensemble	Strings1	0	0	48	Regular
		StereoStrngs	0	3	48	Regular
		SlwAtkStrngs	0	8	48	Regular
		ArcoStrings	0	24	48	Regular
		60'sStrings	0	35	48	Regular
		Orchestra	0	40	48	Regular
		Orchestra2	0	41	48	Regular
		TremOrchestra	0	42	48	Regular
		Velo.Strings	0	45	48	Regular
		Strings2	0	0	49	Regular
	S.SlowStrngs	0	3	49	Regular	
LegatoStrngs	0	8	49	Regular		
WarmStrings	0	40	49	Regular		
Kingdom	0	41	49	Regular		

CVP-709/CVP-705

Main Category: OTHERS

Sub Category 1	Sub Category 2	Voice Name	Voice Number			Voice Type	
			MSB	LSB	Prg		
GM&XG	Ensemble	70'sStrings	0	64	49	Regular	
		Strings3	0	65	49	Regular	
		SynStrings1	0	0	50	Regular	
		ResoStrings	0	27	50	Regular	
		SynStrings4	0	64	50	Regular	
		SynStrings5	0	65	50	Regular	
		SynStrings2	0	0	51	Regular	
		ChoirAahs	0	0	52	Regular	
		StereoChoir	0	3	52	Regular	
		ChoirAahs2	0	16	52	Regular	
		MellowChoir	0	32	52	Regular	
		ChoirStrings	0	40	52	Regular	
		VoiceOohs	0	0	53	Regular	
		SynthVoice	0	0	54	Regular	
		SynthVoice2	0	40	54	Regular	
		Choral	0	41	54	Regular	
		AnalogVoice	0	64	54	Regular	
		OrchestraHit	0	0	55	Regular	
		OrchestrHit2	0	35	55	Regular	
		Impact	0	64	55	Regular	
	Brass	Trumpet	0	0	56	Regular	
		Trumpet2	0	16	56	Regular	
		BriteTrumpet	0	17	56	Regular	
		WarmTrumpet	0	32	56	Regular	
		Trombone	0	0	57	Regular	
		Trombone2	0	18	57	Regular	
		Tuba	0	0	58	Regular	
		Tuba2	0	16	58	Regular	
		MutedTrumpet	0	0	59	Regular	
		FrenchHorn	0	0	60	Regular	
		Fr.HornSolo	0	6	60	Regular	
		FrenchHorn2	0	32	60	Regular	
		HornOrchestr	0	37	60	Regular	
		BrassSection	0	0	61	Regular	
		Tp&TbSection	0	35	61	Regular	
		BrassSect2	0	40	61	Regular	
		HighBrass	0	41	61	Regular	
		MellowBrass	0	42	61	Regular	
		SynthBrass1	0	0	62	Regular	
		QuackBrass	0	12	62	Regular	
		ResoSynBrass	0	20	62	Regular	
		PolyBrass	0	24	62	Regular	
		SynthBrass3	0	27	62	Regular	
		JumpBrass	0	32	62	Regular	
		AnaVelBrass1	0	45	62	Regular	
		AnalogBrass1	0	64	62	Regular	
		SynthBrass2	0	0	63	Regular	
		SoftBrass	0	18	63	Regular	
		SynthBrass4	0	40	63	Regular	
		ChoirBrass	0	41	63	Regular	
		AnaVelBrass2	0	45	63	Regular	
		AnalogBrass2	0	64	63	Regular	
		Reed	SopranoSax	0	0	64	Regular
			AltoSax	0	0	65	Regular
			SaxSection	0	40	65	Regular
			HyperAltoSax	0	43	65	Regular
			TenorSax	0	0	66	Regular
			BreathyTenor	0	40	66	Regular
	SoftTenorSax		0	41	66	Regular	
	TenorSax2		0	64	66	Regular	
	BaritoneSax		0	0	67	Regular	
	Oboe		0	0	68	Regular	
	EnglishHorn		0	0	69	Regular	

Main Category: OTHERS

Sub Category 1	Sub Category 2	Voice Name	Voice Number			Voice Type	
			MSB	LSB	Prg		
GM&XG	Reed	Bassoon	0	0	70	Regular	
		Clarinet	0	0	71	Regular	
	Pipe	Piccolo	0	0	72	Regular	
		Flute	0	0	73	Regular	
		Recorder	0	0	74	Regular	
		PanFlute	0	0	75	Regular	
		BlownBottle	0	0	76	Regular	
		Shakuhachi	0	0	77	Regular	
		Whistle	0	0	78	Regular	
		Ocarina	0	0	79	Regular	
		Synth.Lead	SquareLead	0	0	80	Regular
			SquareLead2	0	6	80	Regular
	LMSquare		0	8	80	Regular	
	Hollow		0	18	80	Regular	
	Shroud		0	19	80	Regular	
	Mellow		0	64	80	Regular	
	SoloSine		0	65	80	Regular	
	SineLead		0	66	80	Regular	
	SawtoothLead		0	0	81	Regular	
	SawtoothLd2		0	6	81	Regular	
	ThickSaw		0	8	81	Regular	
	DynamicSaw		0	18	81	Regular	
	DigitalSaw		0	19	81	Regular	
	BigLead		0	20	81	Regular	
	HeavySynth		0	24	81	Regular	
	WaspySynth		0	25	81	Regular	
	PulseSaw		0	40	81	Regular	
	Dr.Lead		0	41	81	Regular	
	VelocityLead		0	45	81	Regular	
	Seq.Analog		0	96	81	Regular	
	CalliopeLead		0	0	82	Regular	
	PureLead		0	65	82	Regular	
	ChiffLead		0	0	83	Regular	
	Rubby		0	64	83	Regular	
	CharangLead		0	0	84	Regular	
	DistortedLd		0	64	84	Regular	
	WireLead		0	65	84	Regular	
	VoiceLead		0	0	85	Regular	
	SynthAahs		0	24	85	Regular	
	VoxLead		0	64	85	Regular	
	FifthsLead		0	0	86	Regular	
	BigFive		0	35	86	Regular	
	Bass&Lead		0	0	87	Regular	
	Big&Low		0	16	87	Regular	
	Fat&Perky		0	64	87	Regular	
	SoftWhirl		0	65	87	Regular	
	Synth.Pad		NewAgePad	0	0	88	Regular
			Fantasy	0	64	88	Regular
			WarmPad	0	0	89	Regular
			ThickPad	0	16	89	Regular
			SoftPad	0	17	89	Regular
			SinePad	0	18	89	Regular
		HornPad	0	64	89	Regular	
		RotaryStrngs	0	65	89	Regular	
		PolySynthPad	0	0	90	Regular	
		PolyPad80	0	64	90	Regular	
		ClickPad	0	65	90	Regular	
		AnalogPad	0	66	90	Regular	
		SquarePad	0	67	90	Regular	
		ChoirPad	0	0	91	Regular	
		Heaven	0	64	91	Regular	
		Itopia	0	66	91	Regular	
		CCPad	0	67	91	Regular	
		BowedPad	0	0	92	Regular	

CVP-709/CVP-705

Main Category: OTHERS

Sub Category 1	Sub Category 2	Voice Name	Voice Number			Voice Type
			MSB	LSB	Prg	
GM&XG	Synth.Pad	Glacier	0	64	92	Regular
		GlassPad	0	65	92	Regular
		MetallicPad	0	0	93	Regular
		TinePad	0	64	93	Regular
		PanPad	0	65	93	Regular
		HaloPad	0	0	94	Regular
		SweepPad	0	0	95	Regular
		Shwimmer	0	20	95	Regular
		Converge	0	27	95	Regular
		PolarPad	0	64	95	Regular
		Celestial	0	66	95	Regular
	Synth.Effect	Rain	0	0	96	Regular
		ClaviPad	0	45	96	Regular
		HarmoRain	0	64	96	Regular
		AfricanWind	0	65	96	Regular
		Carib	0	66	96	Regular
		SoundTrack	0	0	97	Regular
		Prologue	0	27	97	Regular
		Ancestral	0	64	97	Regular
		Crystal	0	0	98	Regular
		SynthDr.Comp	0	12	98	Regular
		Popcorn	0	14	98	Regular
		TinyBells	0	18	98	Regular
		RoundGlocken	0	35	98	Regular
		GlockenChime	0	40	98	Regular
		ClearBells	0	41	98	Regular
		ChorusBells	0	42	98	Regular
		SynthMallet	0	64	98	Regular
		SoftCrystal	0	65	98	Regular
		LoudGlocken	0	66	98	Regular
		ChristmasBel	0	67	98	Regular
		VibeBells	0	68	98	Regular
		DigitalBells	0	69	98	Regular
		AirBells	0	70	98	Regular
		BellHarp	0	71	98	Regular
		Gamelimba	0	72	98	Regular
		Atmosphere	0	0	99	Regular
		WarmAtmos.	0	18	99	Regular
		HollwRelease	0	19	99	Regular
		NylonEIPiano	0	40	99	Regular
		NylonHarp	0	64	99	Regular
		HarpVox	0	65	99	Regular
		Atmos.Pad	0	66	99	Regular
		Planet	0	67	99	Regular
		Brightness	0	0	100	Regular
		FantasyBells	0	64	100	Regular
		Smokey	0	96	100	Regular
		Goblins	0	0	101	Regular
		GoblinsSynth	0	64	101	Regular
		Creeper	0	65	101	Regular
		RingPad	0	66	101	Regular
		Ritual	0	67	101	Regular
		ToHeaven	0	68	101	Regular
		Night	0	70	101	Regular
Glisten	0	71	101	Regular		
BellChoir	0	96	101	Regular		
Echoes	0	0	102	Regular		
Echoes2	0	8	102	Regular		
EchoPan	0	14	102	Regular		
EchoBells	0	64	102	Regular		
BigPan	0	65	102	Regular		
SynthPiano	0	66	102	Regular		
Creation	0	67	102	Regular		
StarDust	0	68	102	Regular		

Main Category: OTHERS

Sub Category 1	Sub Category 2	Voice Name	Voice Number			Voice Type
			MSB	LSB	Prg	
GM&XG	Synth.Effect	Reso&Panning	0	69	102	Regular
		Sci-Fi	0	0	103	Regular
		Starz	0	64	103	Regular
	Ethnic	Sitar	0	0	104	Regular
		DetunedSitar	0	32	104	Regular
		Sitar2	0	35	104	Regular
		Tambra	0	96	104	Regular
		Tamboura	0	97	104	Regular
		Banjo	0	0	105	Regular
		MutedBanjo	0	28	105	Regular
		Rabab	0	96	105	Regular
		Gopichant	0	97	105	Regular
		Oud	0	98	105	Regular
		Shamisen	0	0	106	Regular
		Koto	0	0	107	Regular
		Taisho-kin	0	96	107	Regular
		Kanoon	0	97	107	Regular
		Kalimba	0	0	108	Regular
		Bagpipe	0	0	109	Regular
		Fiddle	0	0	110	Regular
		Shanai	0	0	111	Regular
		Shanai2	0	64	111	Regular
		Pungi	0	96	111	Regular
		Hichiriki	0	97	111	Regular
	Percussive	TinkleBell	0	0	112	Regular
		Bonang	0	96	112	Regular
		Altair	0	97	112	Regular
		GamelanGongs	0	98	112	Regular
		StereoGamlan	0	99	112	Regular
		RamaCymbal	0	100	112	Regular
		AsianBells	0	101	112	Regular
		Agogo	0	0	113	Regular
		SteelDrums	0	0	114	Regular
		GlassPerc.	0	97	114	Regular
		ThaiBells	0	98	114	Regular
		Woodblock	0	0	115	Regular
		Castanets	0	96	115	Regular
		TaikoDrum	0	0	116	Regular
		GranCassa	0	96	116	Regular
		MelodicTom	0	0	117	Regular
		MelodicTom2	0	64	117	Regular
		RealTom	0	65	117	Regular
		RockTom	0	66	117	Regular
		SynthDrum	0	0	118	Regular
		AnalogTom	0	64	118	Regular
		ElectroPerc.	0	65	118	Regular
		Rev.Cymbal	0	0	119	Regular
	SoundEffect	GtrFretNoise	0	0	120	Regular
		BreathNoise	0	0	121	Regular
		Seashore	0	0	122	Regular
		BirdTweet	0	0	123	Regular
		TelephonRing	0	0	124	Regular
		Helicopter	0	0	125	Regular
		Applause	0	0	126	Regular
Gunshot		0	0	127	Regular	
CuttingNoise		64	0	0	Regular	
CuttingNoiz2		64	0	1	Regular	
StringSlap		64	0	3	Regular	
Fl.KeyClick		64	0	16	Regular	
Shower		64	0	32	Regular	
Thunder		64	0	33	Regular	
Wind		64	0	34	Regular	
Stream		64	0	35	Regular	
Bubble		64	0	36	Regular	

CVP-709/CVP-705

Main Category: OTHERS

Sub Category 1	Sub Category 2	Voice Name	Voice Number			Voice Type		
			MSB	LSB	Prg			
GM&XG	SoundEffect	Feed	64	0	37	Regular		
		Dog	64	0	48	Regular		
		Horse	64	0	49	Regular		
		BirdTweet2	64	0	50	Regular		
		Ghost	64	0	54	Regular		
		Maou	64	0	55	Regular		
		PhoneCall	64	0	64	Regular		
		DoorSqueak	64	0	65	Regular		
		DoorSlam	64	0	66	Regular		
		ScratchCut	64	0	67	Regular		
		ScratchSplit	64	0	68	Regular		
		WindChime	64	0	69	Regular		
		TelphonRing2	64	0	70	Regular		
		CarEngineIgn	64	0	80	Regular		
		CarTiresScqel	64	0	81	Regular		
		CarPassing	64	0	82	Regular		
		CarCrash	64	0	83	Regular		
		Siren	64	0	84	Regular		
		Train	64	0	85	Regular		
		JetPlane	64	0	86	Regular		
		Starship	64	0	87	Regular		
		Burst	64	0	88	Regular		
		RollrCoaster	64	0	89	Regular		
		Submarine	64	0	90	Regular		
		Laugh	64	0	96	Regular		
		Scream	64	0	97	Regular		
		Punch	64	0	98	Regular		
		Heartbeat	64	0	99	Regular		
		FootSteps	64	0	100	Regular		
		MachineGun	64	0	112	Regular		
		LaserGun	64	0	113	Regular		
		Explosion	64	0	114	Regular		
		Firework	64	0	115	Regular		
		GM2	Piano	GrandPiano	121	0	0	Regular
				GrandPianoW	121	1	0	Regular
				GrandPianoD	121	2	0	Regular
				BrightPiano	121	0	1	Regular
				BrightPianoW	121	1	1	Regular
				ElecGrandPno	121	0	2	Regular
				ElecGrandPW	121	1	2	Regular
				Honkytonk	121	0	3	Regular
				HonkytonkW	121	1	3	Regular
				EI.Piano1	121	0	4	Regular
				DetunedEP1	121	1	4	Regular
				EP1VeloMix	121	2	4	Regular
				60'sEI.Piano	121	3	4	Regular
				EI.Piano2	121	0	5	Regular
				DetunedEP2	121	1	5	Regular
EP2VeloMix	121			2	5	Regular		
EPLegend	121			3	5	Regular		
EPPHase	121			4	5	Regular		
Harpsichord	121			0	6	Regular		
Harpsi.OctMx	121			1	6	Regular		
HarpsichordW	121			2	6	Regular		
Harpsi.KOff	121			3	6	Regular		
Clavi.	121			0	7	Regular		
PulseClavi.	121			1	7	Regular		
Chromatic Perc	Celesta			121	0	8	Regular	
	Glockenspiel			121	0	9	Regular	
	MusicBox			121	0	10	Regular	
	Vibraphone			121	0	11	Regular	
	VibraphoneW			121	1	11	Regular	
	Marimba			121	0	12	Regular	
	MarimbaW			121	1	12	Regular	

Main Category: OTHERS

Sub Category 1	Sub Category 2	Voice Name	Voice Number			Voice Type	
			MSB	LSB	Prg		
GM2	Chromatic Perc	Xylophone	121	0	13	Regular	
		TubularBells	121	0	14	Regular	
		ChurchBells	121	1	14	Regular	
		Carillon	121	2	14	Regular	
		Dulcimer	121	0	15	Regular	
	Organ	DrawbarOrgan	121	0	16	Regular	
		DetDrawOrgan	121	1	16	Regular	
		It60'sOrgan	121	2	16	Regular	
		DrawbarOrg2	121	3	16	Regular	
		Perc.Organ	121	0	17	Regular	
		DetPercOrgan	121	1	17	Regular	
		Perc.Organ2	121	2	17	Regular	
		RockOrgan	121	0	18	Regular	
		ChurchOrgan	121	0	19	Regular	
		ChrchOrgOctM	121	1	19	Regular	
		DetChurchOrg	121	2	19	Regular	
		ReedOrgan	121	0	20	Regular	
		PuffOrgan	121	1	20	Regular	
		Accordion	121	0	21	Regular	
		Accordion2	121	1	21	Regular	
		Harmonica	121	0	22	Regular	
		TangoAccord	121	0	23	Regular	
		Guitar	NylonGuitar	121	0	24	Regular
			Ukulele	121	1	24	Regular
			NylonGtrKOff	121	2	24	Regular
			NylonGuitar2	121	3	24	Regular
			SteelGuitar	121	0	25	Regular
			12StrGuitar	121	1	25	Regular
	Mandolin		121	2	25	Regular	
	Steel&Body		121	3	25	Regular	
	JazzGuitar		121	0	26	Regular	
	PedlSteelGtr		121	1	26	Regular	
	CleanGuitar		121	0	27	Regular	
	DetCleanGtr		121	1	27	Regular	
	MidToneGtr		121	2	27	Regular	
	MutedGuitar		121	0	28	Regular	
	FunkGuitar		121	1	28	Regular	
	MutedV-SwGtr		121	2	28	Regular	
	JazzMan		121	3	28	Regular	
	Overdriven		121	0	29	Regular	
	GuitarPinch		121	1	29	Regular	
	Distortion		121	0	30	Regular	
	FeedbackGtr		121	1	30	Regular	
	DstRhythmGtr		121	2	30	Regular	
	GtrHarmonics		121	0	31	Regular	
	GtrFeedback		121	1	31	Regular	
	Bass		AcousticBass	121	0	32	Regular
		FingerBass	121	0	33	Regular	
		FingerSlap	121	1	33	Regular	
		PickBass	121	0	34	Regular	
		FretlessBass	121	0	35	Regular	
		SlapBass1	121	0	36	Regular	
		SlapBass2	121	0	37	Regular	
		SynthBass1	121	0	38	Regular	
		WarmSynhBass	121	1	38	Regular	
		ResoSynhBass	121	2	38	Regular	
		ClaviBass	121	3	38	Regular	
		Hammer	121	4	38	Regular	
		SynthBass2	121	0	39	Regular	
		AttackBass	121	1	39	Regular	
RubberBass		121	2	39	Regular		
AttackPulse	121	3	39	Regular			
Strings	Violin	121	0	40	Regular		
	SlwAtkViolin	121	1	40	Regular		

CVP-709/CVP-705

Main Category: OTHERS

Sub Category 1	Sub Category 2	Voice Name	Voice Number			Voice Type	
			MSB	LSB	Prg		
GM2	Strings	Viola	121	0	41	Regular	
		Cello	121	0	42	Regular	
		Contrabass	121	0	43	Regular	
		Trem.Strings	121	0	44	Regular	
		PizzicatoStr	121	0	45	Regular	
		Orch.Harp	121	0	46	Regular	
		YangQin	121	1	46	Regular	
		Timpani	121	0	47	Regular	
	Ensemble	Strings1	121	0	48	Regular	
		StringsBrass	121	1	48	Regular	
		60'sStrings	121	2	48	Regular	
		Strings2	121	0	49	Regular	
		SynStrings1	121	0	50	Regular	
		SynStrings3	121	1	50	Regular	
		SynStrings2	121	0	51	Regular	
		ChoirAahs	121	0	52	Regular	
		ChoirAahs2	121	1	52	Regular	
		VoiceOohs	121	0	53	Regular	
		Humming	121	1	53	Regular	
		SynthVoice	121	0	54	Regular	
		AnalogVoice	121	1	54	Regular	
		OrchestraHit	121	0	55	Regular	
		BassHitPlus	121	1	55	Regular	
		6thHit	121	2	55	Regular	
		EuroHit	121	3	55	Regular	
		Brass	Trumpet	121	0	56	Regular
			DarkTpSoft	121	1	56	Regular
			Trombone	121	0	57	Regular
	Trombone2		121	1	57	Regular	
	BriteTrombon		121	2	57	Regular	
	Tuba		121	0	58	Regular	
	MutedTrumpet		121	0	59	Regular	
	MuteTrumpet2		121	1	59	Regular	
	FrenchHorn		121	0	60	Regular	
	FrenchHorn2		121	1	60	Regular	
	BrassSection		121	0	61	Regular	
	BrassSect2		121	1	61	Regular	
	SynthBrass1		121	0	62	Regular	
	SynthBrass3		121	1	62	Regular	
	AnaSynBrass1		121	2	62	Regular	
	JumpBrass		121	3	62	Regular	
	SynthBrass2		121	0	63	Regular	
	SynthBrass4		121	1	63	Regular	
	AnaSynBrass2		121	2	63	Regular	
	Reed		SopranoSax	121	0	64	Regular
		AltoSax	121	0	65	Regular	
		TenorSax	121	0	66	Regular	
		BaritoneSax	121	0	67	Regular	
		Oboe	121	0	68	Regular	
		EnglishHorn	121	0	69	Regular	
		Bassoon	121	0	70	Regular	
		Clarinet	121	0	71	Regular	
	Pipe	Piccolo	121	0	72	Regular	
		Flute	121	0	73	Regular	
		Recorder	121	0	74	Regular	
		PanFlute	121	0	75	Regular	
		BlownBottle	121	0	76	Regular	
		Shakuhachi	121	0	77	Regular	
		Whistle	121	0	78	Regular	
	Ocarina	121	0	79	Regular		
	Synth.Lead	SquareLead	121	0	80	Regular	
		SquareLead2	121	1	80	Regular	
		SineLead	121	2	80	Regular	
		SawtoothLead	121	0	81	Regular	

Main Category: OTHERS

Sub Category 1	Sub Category 2	Voice Name	Voice Number			Voice Type	
			MSB	LSB	Prg		
GM2	Synth.Lead	SawtoothLd2	121	1	81	Regular	
		SawPulseLead	121	2	81	Regular	
		DoublSawLead	121	3	81	Regular	
		Seq.Analog	121	4	81	Regular	
		CalliopeLead	121	0	82	Regular	
		ChiffLead	121	0	83	Regular	
		CharangLead	121	0	84	Regular	
		WireLead	121	1	84	Regular	
		VoiceLead	121	0	85	Regular	
		FifthsLead	121	0	86	Regular	
		Bass&Lead	121	0	87	Regular	
		SoftWhirl	121	1	87	Regular	
		Synth.Pad	NewAgePad	121	0	88	Regular
			WarmPad	121	0	89	Regular
			SinePad	121	1	89	Regular
			PolySynthPad	121	0	90	Regular
	ChoirPad		121	0	91	Regular	
	ItopiaPad		121	1	91	Regular	
	BowedPad		121	0	92	Regular	
	MetallicPad		121	0	93	Regular	
	HaloPad		121	0	94	Regular	
	SweepPad		121	0	95	Regular	
	Synth.Effect		Rain	121	0	96	Regular
			SoundTrack	121	0	97	Regular
		Crystal	121	0	98	Regular	
		SynthMallet	121	1	98	Regular	
		Atmosphere	121	0	99	Regular	
		Brightness	121	0	100	Regular	
		Goblins	121	0	101	Regular	
		Echoes	121	0	102	Regular	
		EchoBell	121	1	102	Regular	
		EchoPan	121	2	102	Regular	
		Sci-Fi	121	0	103	Regular	
		Ethnic	Sitar	121	0	104	Regular
			Sitar2	121	1	104	Regular
			Banjo	121	0	105	Regular
	Shamisen		121	0	106	Regular	
	Koto		121	0	107	Regular	
	TaishoKoto		121	1	107	Regular	
	Kalimba		121	0	108	Regular	
	Bagpipe		121	0	109	Regular	
	Fiddle		121	0	110	Regular	
	Shanai		121	0	111	Regular	
	Percussive		TinkleBell	121	0	112	Regular
		Agogo	121	0	113	Regular	
		SteelDrums	121	0	114	Regular	
		Woodblock	121	0	115	Regular	
		Castanets	121	1	115	Regular	
		TaikoDrum	121	0	116	Regular	
		ConcertBD	121	1	116	Regular	
		MelodicTom	121	0	117	Regular	
		MelodicTom2	121	1	117	Regular	
		SynthDrum	121	0	118	Regular	
		RhythmBoxTom	121	1	118	Regular	
		ElectricDrum	121	2	118	Regular	
	Rev.Cymbal	121	0	119	Regular		
	SoundEffect	GtrFretNoise	121	0	120	Regular	
		GtrCutNoise	121	1	120	Regular	
		StringSlap	121	2	120	Regular	
		BreathNoise	121	0	121	Regular	
		Fl.KeyClick	121	1	121	Regular	
		Seashore	121	0	122	Regular	
		Rain	121	1	122	Regular	
		Thunder	121	2	122	Regular	

CVP-709/CVP-705**Main Category: OTHERS**

Sub Category 1	Sub Category 2	Voice Name	Voice Number			Voice Type
			MSB	LSB	Prg	
GM2	SoundEffect	Wind	121	3	122	Regular
		Stream	121	4	122	Regular
		Bubble	121	5	122	Regular
		BirdTweet	121	0	123	Regular
		Dog	121	1	123	Regular
		HorseGallop	121	2	123	Regular
		BirdTweet2	121	3	123	Regular
		TelephonRing	121	0	124	Regular
		TelRing2	121	1	124	Regular
		DoorCreaking	121	2	124	Regular
		Door	121	3	124	Regular
		Scratch	121	4	124	Regular
		WindChime	121	5	124	Regular
		Helicopter	121	0	125	Regular
		CarEngine	121	1	125	Regular
		CarStop	121	2	125	Regular
		CarPass	121	3	125	Regular
		CarCrash	121	4	125	Regular
		Siren	121	5	125	Regular
		Train	121	6	125	Regular
		Jetplane	121	7	125	Regular
		Starship	121	8	125	Regular
		BurstNoise	121	9	125	Regular
		Applause	121	0	126	Regular
		Laughing	121	1	126	Regular
		Screaming	121	2	126	Regular
		Punch	121	3	126	Regular
		HeartBeat	121	4	126	Regular
		Footsteps	121	5	126	Regular
		Gunshot	121	0	127	Regular
		MachineGun	121	1	127	Regular
		Lasergun	121	2	127	Regular
		Explosion	121	3	127	Regular
	Drum	StandardSet	120	0	0	Drums
		RoomSet	120	0	8	Drums
		PowerSet	120	0	16	Drums
		ElectroSet	120	0	24	Drums
		AnalogSet	120	0	25	Drums
		JazzSet	120	0	32	Drums
		BrushSet	120	0	40	Drums
		OrchestraSet	120	0	48	Drums
	SFXSet	120	0	56	SFX	

CVP-709	CVP-705	MSB	LSB	PC#	Voice Name	Velocity Switch Points (under B5)												above C6	above C8
						1-20	21-40	41-60	61-75	76-90	91-105	106-120	121-127	1-20	21-40	41-60	61-75		
		0	0	6	Mega JazzGuitar	open soft	open med	open hard	dead soft	dead hard	hammer	slide	pick harmonics	1-127	strum noise	1-127	fret noise		
		0	0	16	Mega AcousticBass	1-60	open soft	open hard	61-80	open hard	81-120	dead	harmonics	1-127	EFX				
		0	0	17	Mega ElectricBass	1-60	open soft	open hard	61-80	open hard	81-120	dead	slap	1-127	EFX				
		0	1	17	Mega VintageRound	1-60	open soft	open hard	61-80	open hard	81-120	dead	harmonics	1-127	EFX				
		0	2	17	Mega VintageFlat	1-60	open soft	open hard	61-80	open hard	81-120	dead	harmonics	1-127	EFX				
		0	0	18	Mega PickBass	1-40	open	41-80	41-80	open hard	81-120	dead	harmonics	1-127	EFX				
		0	1	18	Mega VintagePick	1-40	open	41-80	41-80	open	81-120	dead	harmonics	1-127	EFX				
		0	0	19	Mega FretlessBass	1-80	open	open	1-80	open	81-120	dead	harmonics	1-127	EFX				
		0	0	48	Mega SmallStrings	1-20	mf	f	61-80	legato	81-95	spicato f	tremolo	111-120	96-110	spicato ff	glissando down		
		0	1	48	Mega ClassicalStrings	1-20	mf	f	61-80	legato	81-95	spicato f	tremolo	111-120	96-110	spicato ff	glissando down		
		0	0	49	Mega LargeStrings	1-20	mf	f	61-80	legato	81-95	spicato f	tremolo	111-120	96-110	spicato ff	glissando down		
		0	1	49	Mega RealStrings	1-20	mf	f	61-80	legato	81-95	spicato f	tremolo	111-120	96-110	spicato ff	glissando down		
		0	0	51	Mega MaleVoiceChoir	1-15	Ooh p	Ooh mf	31-45	Ooh mf	46-60	Ooh mf	legato	76-90	91-105	Aah mf	106-127		
		0	0	54	Mega GospelChoir	1-15	Himm	Hmm legato	Wow	Wow legato	46-60	Wow	Wow legato	76-90	91-105	Aaa	106-127		
		0	0	56	Mega Brass	1-20	p	f	61-80	attack	81-90	scoops	falls fast	101-110	101-110	falls fast	111-120		
		0	0	64	Mega Trumpet	1-20	mf	f	61-80	legato	81-100	straight	shake	101-110	101-110	shake	111-120		
																	1-127		
																	valve noise		
																	glissando up		
																	breath noise		

CVP-709	CVP-705	MSB	LSB	PC#	Voice Name	Velocity Switch Points (under B5)										above C6	above C8
						1-20	21-40	41-60	61-80	81-100	101-127	1-127					
○	○	8	0	82	Mega TenorSax	mp	mff	f	legato	growl	falls	1-127	1-127	valve noise (C6 - B6 key on noise C7 - B7 key off noise)	1-127	breath noise	
○	—	8	0	100	PopHaa	1-10 Haa p legato	21-30 Haa vib p	41-50 Haa f legato	61-70 Haa vib f legato	81-90 Waa p	101-110 Waa vib p	110-127	110-127	C6 - D#6: 1-60, 61-127 E6 - B6: 1-30, 31-60, 61-90, 91-127		breath noise	
○	—	8	0	101	PopDaa	1-10 Daa p legato	21-30 Daa vib p	41-50 Daa f legato	61-70 Daa vib f legato	81-90 Waa p	101-110 Waa vib p	110-127	110-127	C6 - D#6: 1-60, 61-127 E6 - B6: 1-30, 31-60, 61-90, 91-127		breath noise	
○	—	8	0	102	PopBaa	1-10 Baa p legato	21-30 Baa vib p	41-50 Baa f legato	61-70 Baa vib f legato	81-90 Yaa p	101-110 Yaa vib p	110-127	110-127	C6 - D#6: 1-60, 61-127 E6 - B6: 1-30, 31-60, 61-90, 91-127		breath noise	
○	—	8	0	105	PopHoo	1-10 Hoo p legato	21-30 Hoo vib p	41-50 Hoo f legato	61-70 Hoo vib f legato	81-90 Yoo p	101-110 Yoo vib p	110-127	110-127	C6 - D#6: 1-60, 61-127 E6 - B6: 1-30, 31-60, 61-90, 91-127		breath noise	
○	—	8	0	106	PopDoo	1-10 Doo p legato	21-30 Doo vib p	41-50 Doo f legato	61-70 Doo vib f legato	81-90 Yoo p	101-110 Yoo vib p	110-127	110-127	C6 - D#6: 1-60, 61-127 E6 - B6: 1-30, 31-60, 61-90, 91-127		breath noise	
○	—	8	0	103	PopShoo	1-10 Shoo p legato	21-30 Shoo vib p	41-50 Shoo f legato	61-70 Shoo vib f legato	81-90 Yoo p	101-110 Yoo vib p	110-127	110-127	C6 - D#6: 1-60, 61-127 E6 - B6: 1-30, 31-60, 61-90, 91-127		breath noise	
○	—	8	0	110	PopHee	1-10 Hee vib p legato	21-30 Hee vib p	41-50 Hee vib p	61-70 Hee vib p	81-90 Wee vib p	101-110 Wee vib p	110-127	110-127	C6 - D#6: 1-60, 61-127 E6 - B6: 1-30, 31-60, 61-90, 91-127		vocal breath	

CVP-709	CVP-705	MSB	LSB	PC#	Voice Name	Velocity Switch Points (under B5)												above C6	above C8
						1-10	11-20	21-30	31-40	41-50	51-60	61-70	71-80	81-90	91-100	101-110	110-127		
O	—	8	0	107	PopBee	Bee vib p	Ee vib p legato	Bee vib p	Ee vib p legato	Bee vib p	Ee vib p legato	Bee vib p	Ee vib p legato	Bee vib p	Wee vib p	110-127	C6 - D#6: 1-60, 61-127 E6 - B6: 1-30, 31-60, 61-90, 91-127		
						1-10	11-20	21-30	31-40	41-50	51-60	61-70	71-80	81-90	91-100	101-110	Wee vib p	breath noise	
O	—	8	0	115	PopHaa L2	Haa p	Aa p legato2	Haa vib p	Aa vib p legato2	Haa f	Aa f legato2	Haa vib f	Aa vib f legato2	Waa p	110-127	C6 - D#6: 1-60, 61-127 E6 - B6: 1-30, 31-60, 61-90, 91-127			
						1-10	11-20	21-30	31-40	41-50	51-60	61-70	71-80	81-90	91-100	101-110	Waa vib f	breath noise	
O	—	8	0	120	PopHoo L2	Hoo p	Oo p legato2	Hoo vib p	Oo vib p legato2	Hoo f	Oo f legato2	Hoo vib f	Oo vib f legato2	Yoo p	110-127	C6 - D#6: 1-60, 61-127 E6 - B6: 1-30, 31-60, 61-90, 91-127			
						1-10	11-20	21-30	31-40	41-50	51-60	61-70	71-80	81-90	91-100	101-110	Yoo vib f	breath noise	
O	—	8	0	125	PopHee L2	Hee vib p	Ee vib p legato2	Hee vib p	Ee vib p legato2	Hee vib p	Ee vib p legato2	Hee vib p	Ee vib p legato2	Wee vib p	110-127	C6 - D#6: 1-60, 61-127 E6 - B6: 1-30, 31-60, 61-90, 91-127			
						1-10	11-20	21-30	31-40	41-50	51-60	61-70	71-80	81-90	91-100	101-110	Wee vib p	breath noise	
O	—	8	1	1	SteelAcoustic	pick p	pick mf	pick p	pick f	pick f	pick f	dead p	dead f	mute soft	121-127	1-127			
						1-20	21-40	21-40	41-60	41-60	61-87	68-75	76-83	84-90	91-105	106-120	121-127	pick noise	
O	—	8	2	1	SteelAcGtrSlap	pick p	pick mf	pick mf	slap soft	slap hard	slap hard	dead p	dead f	mute hard	121-127	1-127			
						1-20	21-40	21-40	41-50	51-60	61-87	68-75	76-83	84-90	91-105	106-120	121-127	pick noise	
O	—	8	3	0	FlamencoGuitar	finger soft	finger soft/med	finger soft/med	finger med	finger med	finger hard	finger hard	finger hard	mute	121-127	1-45 46-90 91-127			
						1-20	21-40	21-40	41-60	41-60	61-75	68-75	76-90	81-90	91-100	101-110	111-120	121-127	noise noise 2
O	—	8	4	0	SpanishMedium	finger soft	finger soft/med	finger soft/med	finger med	finger med	finger med	finger med	finger med	mute	121-127	1-127			
						1-20	21-40	21-40	41-60	41-60	61-75	68-75	76-90	81-90	91-105	106-120	121-127	strum noise	
O	—	8	5	0	SpanishHard	finger soft/med	finger med	finger med	finger hard	finger hard	finger hard	finger hard	finger hard	mute	121-127	1-127			
						1-20	21-40	21-40	41-60	41-60	61-87	68-75	76-90	84-90	91-105	106-120	121-127	strum noise	
O	—	8	5	1	SteelGtrTwin1	pick p	pick mf	pick mf	pick f	pick f	pick f	pick f	pick f	mute hard	121-127	1-127			
						1-20	21-40	21-40	41-60	41-60	61-75	68-75	76-90	84-90	91-105	106-120	121-127	pick noise	
O	—	8	6	1	SteelGtrTwin2	soft	med	med	hard	hard	hard	dead	dead	mute	121-127	1-127			
						1-20	21-40	21-40	41-60	41-60	61-87	68-75	76-90	84-90	91-105	106-120	121-127	SFX	
O	—	8	6	1	Element1	pick p	pick mf	pick mf	pick f	pick f	pick f	pick f	pick f	mute hard	121-127	1-127			
						1-20	21-40	21-40	41-60	41-60	61-75	68-75	76-90	84-90	91-105	106-120	121-127	pick noise	
O	—	8	6	1	Element2	soft	med	med	hard	hard	hard	dead	dead	mute	121-127	1-127			
						1-20	21-40	21-40	41-60	41-60	61-75	68-75	76-90	84-90	91-105	106-120	121-127	SFX	

CVP-709	CVP-705	MSB	PC#	Voice Name	Velocity Switch Points (under B5)																above C6	above C8						
					1-20	21-40	41-60	61-67	68-75	76-83	84-90	91-105	106-120	121-127	1-20	21-40	41-60	61-67	68-75	76-83			84-90	91-105	106-120	121-127		
○	—	8	7	12StringTwin1	pick p	pick mf	pick f	dead p	dead f	mute soft	mute hard	hammer	slide	harmonics	1-127	pick noise	above C6	above C8										
																			1-20	21-40	41-60	61-67	68-75	76-83	84-90	91-105	106-120	121-127
○	—	8	8	12StringTwin2	pick p	pick mf	pick f	dead p	dead f	mute soft	mute hard	hammer	slide	harmonics	pick noise	above C6	above C8											
																		1-20	21-40	41-60	61-67	68-75	76-83	84-90	91-105	106-120	121-127	
																												pick p
○	—	8	1	PopHorns1	soft	med	hard	6+80	attack	scoops	81-90	hammer	slide	harmonics	SFX	above C6	above C8											
																		1-20	21-40	41-60	61-70	71-80	76-90	81-90	91-100	101-110	111-120	
																												pick p
○	—	8	2	PopHorns2	p	mp	mf	sus ff	legato p	legato mp	81-90	legato mf	shake	falls	doit	above C6	above C8											
																		1-20	21-40	41-60	61-70	71-80	76-90	81-90	91-100	101-110	111-120	
																												pick p

Drum/key Assignment List / Liste der Tastenzuordnungen der Schlaginstrumente / Liste des affectations d'instrument de batterie/touche de clavier / Lista de asignación de teclas/batería / Lista de atribuições de bateria/tecla

CVP-709			○ (Live!)	○ (Live!)	○	○	○										
CVP-705			○ (Live!)	○ (Live!)	○	○	○										
Kit Name			Standard Kit 1			Standard Kit 2			Hit Kit			Room Kit			Rock Kit		
MSB-LSB-PC#			127-0-0			127-0-1			127-0-4			127-0-8			127-0-16		
Note#	MIDI Note	Keyboard Note	Full Name	Key Off (*1)	Alt Grp (*2)	Full Name	Key Off	Alt Grp	Full Name	Key Off	Alt Grp	Full Name	Key Off	Alt Grp	Full Name	Key Off	Alt Grp
13	C#-1	C#1	Surdo Mute		3												
14	D-1	D1	Surdo Open		3												
15	D#-1	D#1	Hi Q														
16	E-1	E1	Whip Slap														
17	F-1	F1	Scratch H		4												
18	F#-1	F#1	Scratch L		4												
19	G-1	G1	Finger Snap														
20	G#-1	G#1	Click Noise														
21	A-1	A1	Metronome Click														
22	A#-1	A#1	Metronome Bell														
23	B-1	B1	Seq Click L														
24	C0	C2	Seq Click H														
25	C#0	C#2	Brush Tap														
26	D0	D2	Brush Swirl	●													
27	D#0	D#2	Brush Slap														
28	E0	E2	Brush Tap Swirl	●													
29	F0	F2	Snare Roll	●													
30	F#0	F#2	Castanet														
31	G0	G2	Snare Soft			Snare Soft 2			Snare Electro						Snare Noisy		
32	G#0	G#2	Sticks														
33	A0	A2	Kick Soft						Kick Tight L								
34	A#0	A#2	Open Rim Shot			Open Rim Shot H Short			Snare Pitched								
35	B0	B2	Kick Tight						Kick Wet						Kick 2		
36	C1	C3	Kick			Kick Short			Kick Tight H						Kick Gate		
37	C#1	C#3	Side Stick			Side Stick Light			Stick Ambient								
38	D1	D3	Snare			Snare Short			Snare Ambient			Snare Snappy			Snare Rock		
39	D#1	D#3	Hand Clap														
40	E1	E3	Snare Tight			Snare Tight H			Snare Tight 2			Snare Tight Snappy			Snare Rock Tight		
41	F1	F3	Floor Tom L						Hybrid Tom 1			Tom Room 1			Tom Rock 1		
42	F#1	F#3	Hi-Hat Closed		1				Hi-Hat Closed 2		1						
43	G1	G3	Floor Tom H						Hybrid Tom 2			Tom Room 2			Tom Rock 2		
44	G#1	G#3	Hi-Hat Pedal		1				Hi-Hat Pedal 2		1						
45	A1	A3	Low Tom						Hybrid Tom 3			Tom Room 3			Tom Rock 3		
46	A#1	A#3	Hi-Hat Open		1				Hi-Hat Open 2		1						
47	B1	B3	Mid Tom L						Hybrid Tom 4			Tom Room 4			Tom Rock 4		
48	C2	C4	Mid Tom H						Hybrid Tom 5			Tom Room 5			Tom Rock 5		
49	C#2	C#4	Crash Cymbal 1														
50	D2	D4	High Tom						Hybrid Tom 6			Tom Room 6			Tom Rock 6		
51	D#2	D#4	Ride Cymbal 1														
52	E2	E4	Chinese Cymbal														
53	F2	F4	Ride Cymbal Cup														
54	F#2	F#4	Tambourine						Tambourine Light								
55	G2	G4	Splash Cymbal														
56	G#2	G#4	Cowbell														
57	A2	A4	Crash Cymbal 2														
58	A#2	A#4	Vibrastap														
59	B2	B4	Ride Cymbal 2														
60	C3	C5	Bongo H														
61	C#3	C#5	Bongo L														
62	D3	D5	Conga H Mute														
63	D#3	D#5	Conga H Open														
64	E3	E5	Conga L														
65	F3	F5	Timbale H														
66	F#3	F#5	Timbale L														
67	G3	G5	Agogo H														
68	G#3	G#5	Agogo L														
69	A3	A5	Cabasa														
70	A#3	A#5	Maracas														
71	B3	B5	Samba Whistle H	●													
72	C4	C6	Samba Whistle L	●													
73	C#4	C#6	Guero Short														
74	D4	D6	Guero Long	●													
75	D#4	D#6	Claves														
76	E4	E6	Wood Block H														
77	F4	F6	Wood Block L														
78	F#4	F#6	Cuica Mute														
79	G4	G6	Cuica Open														
80	G#4	G#6	Triangle Mute		2												
81	A4	A6	Triangle Open		2												
82	A#4	A#6	Shaker														
83	B4	B6	Jingle Bells														
84	C5	C7	Bell Tree														
85	C#5	(C#7)															
86	D5	(D7)															
87	D#5	(D#7)															
88	E5	(E7)															
89	F5	(F7)															
90	F#5	(F#7)															
91	G5	(G7)															

Same as Standard Kit 1

*1 Key Off: Keys marked "●" stop sounding the instant they are released.

*2 Alternate Group: Playing any instrument within a numbered group will immediately stop the sound of any other instrument in the same group of the same number.

No Sound

CVP-709			○	○	○	○	○ (Live!)										
CVP-705			○	○	○	○	○ (Live!)										
Kit Name			Electro Kit			Analog Kit			Dance Kit			Jazz Kit			Brush Kit		
MSB-LSB-PC#			127-0-24			127-0-25			127-0-27			127-0-32			127-0-40		
Note#	MIDI Note	Keyboard Note	Full Name	Key Off (*1)	Alt Grp (*2)	Full Name	Key Off	Alt Grp	Full Name	Key Off	Alt Grp	Full Name	Key Off	Alt Grp	Full Name	Key Off	Alt Grp
13	C#-1	C#1							Kick Dance 1								
14	D-1	D1							Kick Dance 2								
15	D#-1	D#1															
16	E-1	E1															
17	F-1	F1							Scratch Dance 1	●							
18	F#-1	F#1							Scratch Dance 2	●							
19	G-1	G1															
20	G#-1	G#1															
21	A-1	A1							Dance Perc 1								
22	A#-1	A#1							Reverse Dance 1								
23	B-1	B1							Dance Perc 2								
24	C0	C2							Hi Q Dance 1								
25	C#0	C#2							Snare Analog 3								
26	D0	D2							Vinyl Noise	●							
27	D#0	D#2							Snare Analog 4								
28	E0	E2	Reverse Cymbal	●		Reverse Cymbal	●		Reverse Cymbal	●							
29	F0	F2							Reverse Dance 2	●							
30	F#0	F#2	Hi Q 2			Hi Q 2			Hi Q 2								
31	G0	G2	Snare Snappy Electro			Snare Noisy 4			Snare Techno			Snare Jazz H			Brush Slap 2		
32	G#0	G#2							Snare Dance 1								
33	A0	A2	Kick 3			Kick 3			Kick Techno Q								
34	A#0	A#2							Rim Gate								
35	B0	B2	Kick Gate			Kick Analog Short			Kick Techno L								
36	C1	C3	Kick Gate Heavy			Kick Analog			Kick Techno			Kick Jazz			Kick Jazz		
37	C#1	C#3				Side Stick Analog			Side Stick Analog			Side Stick Light			Side Stick Light		
38	D1	D3	Snare Noisy 2			Snare Analog			Snare Clap			Snare Jazz L			Brush Slap 3		
39	D#1	D#3							Dance Clap								
40	E1	E3	Snare Noisy 3			Snare Analog 2			Snare Dry			Snare Jazz M			Brush Tap 2		
41	F1	F3	Tom Electro 1			Tom Analog 1			Tom Dance 1						Tom Brush 1		
42	F#1	F#3				Hi-Hat Closed Analog	1		Hi-Hat Closed 3	1							
43	G1	G3	Tom Electro 2			Tom Analog 2			Tom Dance 2						Tom Brush 2		
44	G#1	G#3				Hi-Hat Closed Analog 2	1		Hi-Hat Closed Analog 3	1							
45	A1	A3	Tom Electro 3			Tom Analog 3			Tom Dance 3						Tom Brush 3		
46	A#1	A#3				Hi-Hat Open Analog	1		Hi-Hat Open 3	1							
47	B1	B3	Tom Electro 4			Tom Analog 4			Tom Dance 4						Tom Brush 4		
48	C2	C4	Tom Electro 5			Tom Analog 5			Tom Dance 5						Tom Brush 5		
49	C#2	C#4				Crash Analog			Crash Analog								
50	D2	D4	Tom Electro 6			Tom Analog 6			Tom Dance 6						Tom Brush 6		
51	D#2	D#4															
52	E2	E4															
53	F2	F4															
54	F#2	F#4							Tambourine Analog								
55	G2	G4															
56	G#2	G#4				Cowbell Analog			Cowbell Dance								
57	A2	A4															
58	A#2	A#4							Vibraslap Analog								
59	B2	B4							Ride Analog								
60	C3	C5							Bongo Analog H								
61	C#3	C#5							Bongo Analog L								
62	D3	D5				Conga Analog H			Conga Analog H								
63	D#3	D#5				Conga Analog M			Conga Analog M								
64	E3	E5				Conga Analog L			Conga Analog L								
65	F3	F5															
66	F#3	F#5															
67	G3	G5															
68	G#3	G#5															
69	A3	A5															
70	A#3	A#5				Maracas 2			Maracas 2								
71	B3	B5															
72	C4	C6															
73	C#4	C#6															
74	D4	D6															
75	D#4	D#6				Claves 2			Claves 2								
76	E4	E6							Dance Perc 3								
77	F4	F6							Dance Perc 4	●							
78	F#4	F#6	Scratch H 2			Scratch H 2			Dance Breath 1								
79	G4	G6	Scratch L 2			Scratch L 2			Dance Breath 2	●							
80	G#4	G#6															
81	A4	A6															
82	A#4	A#6															
83	B4	B6															
84	C5	C7															
85	C#5	(C#7)															
86	D5	(D7)															
87	D#5	(D#7)															
88	E5	(E7)															
89	F5	(F7)															
90	F#5	(F#7)															
91	G5	(G7)															

Same as Standard Kit 1

*1 Key Off: Keys marked "●" stop sounding the instant they are released.

*2 Alternate Group: Playing any instrument within a numbered group will immediately stop the sound of any other instrument in the same group of the same number.

No Sound

CVP-709	○ (Live!)	○ (Live!)	○	○	○
CVP-705	○ (Live!)	○ (Live!)	○	○	○

Kit Name			Real Brushes			Symphony Kit			Hip Hop Kit			Break Kit			Analog T8 Kit		
MSB-LSB-PC#			127-0-41			127-0-48			127-0-56			127-0-57			127-0-58		
Note#	MIDI Note	Keyboard Note	Full Name	Key Off (*1)	Alt Grp (*2)	Full Name	Key Off	Alt Grp	Full Name	Key Off	Alt Grp	Full Name	Key Off	Alt Grp	Full Name	Key Off	Alt Grp
13	C#-1	C#1															
14	D-1	D1															
15	D#-1	D#1															
16	E-1	E1															
17	F-1	F1															
18	F#-1	F#1															
19	G-1	G1															
20	G#-1	G#1															
21	A-1	A1															
22	A#-1	A#1															
23	B-1	B1	Vintage Tip														
24	C0	C2	Vintage Swirl 1	●													
25	C#0	C#2	Vintage Slap 1														
26	D0	D2	Vintage Swirl 2	●													
27	D#0	D#2	Vintage Slap 2														
28	E0	E2	Vintage Tap Swirl	●													
29	F0	F2	Vintage Slap Swirl	●													
30	F#0	F#2	Vintage Swirl 3	●													
31	G0	G2	Vintage Slap 3														
32	G#0	G#2															
33	A0	A2	Kick Soft L			Kick Soft 2											
34	A#0	A#2	Open Rim Shot Real Brushes														
35	B0	B2	Kick Soft H			Gran Cassa											
36	C1	C3	Kick Jazz Ambience			Gran Cassa Mute											
37	C#1	C#3	Side Stick Real Brushes														
38	D1	D3	Vintage Slap 4			Band Snare											
39	D#1	D#3	Clap Power														
40	E1	E3	Vintage Slap 5			Band Snare 2											
41	F1	F3	Tom Real Brushes 1														
42	F#1	F#3	Hi-Hat Closed Real Brushes		1												
43	G1	G3	Tom Real Brushes 2														
44	G#1	G#3	Hi-Hat Pedal Real Brushes		1												
45	A1	A3	Tom Real Brushes 3														
46	A#1	A#3	Hi-Hat Open Real Brushes		1												
47	B1	B3	Tom Real Brushes 4														
48	C2	C4	Tom Real Brushes 5														
49	C#2	C#4	Crash Cymbal Real Brushes 1			Hand Cymbal											
50	D2	D4	Tom Real Brushes 6														
51	D#2	D#4	Ride Cymbal Real Brushes			Hand Cymbal Short											
52	E2	E4	China Cymbal Real Brushes														
53	F2	F4	Ride Cup Real Brushes 1														
54	F#2	F#4															
55	G2	G4	Splash Cymbal Real Brushes														
56	G#2	G#4															
57	A2	A4	Crash Cymbal Real Brushes 2			Hand Cymbal 2											
58	A#2	A#4															
59	B2	B4	Ride Cup Real Brushes 2			Hand Cymbal Short 2											
60	C3	C5															
61	C#3	C#5															
62	D3	D5															
63	D#3	D#5															
64	E3	E5															
65	F3	F5															
66	F#3	F#5															
67	G3	G5															
68	G#3	G#5															
69	A3	A5															
70	A#3	A#5															
71	B3	B5															
72	C4	C6															
73	C#4	C#6															
74	D4	D6															
75	D#4	D#6															
76	E4	E6															
77	F4	F6															
78	F#4	F#6															
79	G4	G6															
80	G#4	G#6															
81	A4	A6															
82	A#4	A#6															
83	B4	B6															
84	C5	C7	Wind Chime														
85	C#5	(C#7)															
86	D5	(D7)															
87	D#5	(D#7)															
88	E5	(E7)															
89	F5	(F7)															
90	F#5	(F#7)															
91	G5	(G7)															

Same as Standard Kit 1

*1 Key Off: Keys marked "●" stop sounding the instant they are released.

*2 Alternate Group: Playing any instrument within a numbered group will immediately stop the sound of any other instrument in the same group of the same number.

No Sound

CVP-709			○	○	○	○ (Live!)	○ (Live!)										
CVP-705			○	○	○	○ (Live!)	○ (Live!)										
Kit Name			Analog T9 Kit			House Kit			Drum Machine			Studio Kit			Power Kit 1		
MSB-LSB-PC#			127-0-59			127-0-60			127-0-61			127-0-86			127-0-87		
Note#	MIDI Note	Keyboard Note	Full Name	Key Off (*1)	Alt Grp (*2)	Full Name	Key Off	Alt Grp	Full Name	Key Off	Alt Grp	Full Name	Key Off	Alt Grp	Full Name	Key Off	Alt Grp
13	C#-1	C#1				W Kick	●										
14	D-1	D1				Disco Fx	●										
15	D#-1	D#1				White Noise Down 1	●										
16	E-1	E1				Pink Noise Down 1	●										
17	F-1	F1				White Noise Down 2	●	4									
18	F#-1	F#1				Pink Noise Down 2	●	4									
19	G-1	G1	Snare Drum&Bass 1			White Noise Up 2	●		Snare Drum&Bass 1								
20	G#-1	G#1	Kick Break 2			White Noise Up 1	●		Kick Break 2								
21	A-1	A1	Snare Distortion			Pink Noise Up	●		Snare Distortion								
22	A#-1	A#1	Kick Tek Power			White Noise Up Release	●		Kick Tek Power								
23	B-1	B1	Kick Distortion RM			Pink Noise Up Release	●		Kick Distortion RM								
24	C0	C2	Kick T9 2			Kick T9 4			Bass Drum Hard Long								
25	C#0	C#2	Snare Analog CR			Snare T8 Rim			Bass Drum Tek Power								
26	D0	D2	Snare T9 5			Snare T8 5			Bass Drum Distortion 5								
27	D#0	D#2	Clap Analog Sm			Hand Clap			Bass Drum Distortion 3								
28	E0	E2	Snare T9 Gate 1			Snare Garg L			Bass Drum Distortion 1	●							
29	F0	F2	Snare Rock Roll	●					Bass Drum Drum&Bass 1								
30	F#0	F#2	Snare T9 3			Snare T9 3			Bass Drum Blip								
31	G0	G2	Snare T9 4			Snare T8 1			Bass Drum Analog Sm			Snare Studio 2			Snare Soft Power 1		
32	G#0	G#2	Snare T9 Gate 2			Snare T9 5			Kick T8 2								
33	A0	A2	Kick T9 4			Kick T9 1			Kick T8 3			Kick Ambience H			Kick Ambient+		
34	A#0	A#2	Snare T9 6			Snare T9 Gate			Kick T9 HD 3						Open Rim Power 1		
35	B0	B2	Kick T9 1			Kick T9 2			Kick T9 2			Kick Ambience L			Kick Power Open		
36	C1	C3	Kick T9 3			Kick T9 5			Kick T9 4			Kick Studio			Kick Power Mute		
37	C#1	C#3	Snare T9 Rim			Snare T9 Rim			Snare T9 Rim						Side Stick Power		
38	D1	D3	Snare T9 1			Snare T9 1			Snare T9 1			Snare Studio M			Snare Power 1		
39	D#1	D#3	Clap T9			Clap T9			Clap T9						Hand Clap Power		
40	E1	E3	Snare T9 2			Snare T9 2			Snare T9 4			Snare Studio L			Snare Rough		
41	F1	F3	Tom T9 1			Tom T9 1			Tom T9 1						Tom Power 1		
42	F#1	F#3	Hi-Hat Closed T9		1	Hi-Hat Closed T8		1	Hi-Hat Closed T9		1				Hi-Hat Closed Power		1
43	G1	G3	Tom T9 2			Tom T9 2			Tom T9 2						Tom Power 2		
44	G#1	G#3	Hi-Hat Pedal T9		1	Hi-Hat Pedal T9		1	Hi-Hat Pedal T9		1				Hi-Hat Pedal Power		1
45	A1	A3	Tom T9 3			Tom T9 3			Tom T9 3						Tom Power 3		
46	A#1	A#3	Hi-Hat Open T9		1	Hi-Hat Open T9		1	Hi-Hat Open T9		1				Hi-Hat Open Power		1
47	B1	B3	Tom T9 4			Tom T9 4			Tom T9 4						Tom Power 4		
48	C2	C4	Tom T9 5			Tom T9 5			Tom T9 5						Tom Power 5		
49	C#2	C#4	Crash Cymbal T9			Crash Cymbal T9			Crash Cymbal T9						Crash Cymbal Acoustic 1		
50	D2	D4	Tom T9 6			Tom T9 6			Conga T8 1						Tom Power 6		
51	D#2	D#4	Ride Cymbal T9			Ride Cymbal T9			Ride Cymbal T9						Ride Cymbal Acoustic 1		
52	E2	E4	China Cymbal 2			Crash Cymbal 4			Conga T8 2						China Cymbal Acoustic		
53	F2	F4	Ride Cymbal Cup 2			Ride Cymbal Cup 2			Analog Click						Ride Cymbal Cup Acoustic		
54	F#2	F#4	Tambourine RX5			Tambourine Hit			Claves T8 1								
55	G2	G4	Splash Cymbal 2			Splash Cymbal 2			Maracas T8						Splash Cymbal Acoustic		
56	G#2	G#4	Cowbell 1			Cowbell 1			Tambourine Analog CR								
57	A2	A4	Crash Cymbal 4						Analog Shaker						Crash Cymbal Acoustic 2		
58	A#2	A#4	Cowbell T8			Cowbell T8			Cowbell T8								
59	B2	B4	Ride Cymbal 3			Ride Cymbal 3			Cowbell Analog CR						Ride Cymbal Acoustic 2		
60	C3	C5	Conga T8 5			Bongo H Open One Finger			Snare T8 1								
61	C#3	C#5	Conga T8 4			Bongo L Open Three Finger			Snare T8 2								
62	D3	D5	Conga Tip			Conga H Tip			Snare T8 3								
63	D#3	D#5	Conga Open Slap			Conga H Slap Open			Snare Analog CR								
64	E3	E5	Conga Open			Conga H Open 2			Snare Jungle 1								
65	F3	F5							Snare Drum&Bass 2								
66	F#3	F#5							Snare Hip 1								
67	G3	G5	Analog Click						Snare R&B 1								
68	G#3	G#5	Conga T8 1						Snare R&B 2								
69	A3	A5							Snare Hip 1								
70	A#3	A#5	Maracas Slur 2			Maracas Slur 2			Snare Wood								
71	B3	B5	Fx Gun 2	●		Vox Drum L			Snare Timbre								
72	C4	C6	Fx Gun 1	●		Vox Drum H			Hi-Hat Closed T8 1		5						
73	C#4	C#6	Scratch H 3	●					Hi-Hat Open T8 1		5						
74	D4	D6	Scratch Down	●					Hi-Hat Closed T8 2		6						
75	D#4	D#6	Hi Q 3						Hi-Hat Open T8 2		6						
76	E4	E6	Hi Q 1						Hi-Hat Pedal Acoustic		7						
77	F4	F6	Hi Q 2						Hi-Hat Closed Acoustic		7						
78	F#4	F#6	Scratch H 2			Cuica H			Hi-Hat Open Acoustic		7						
79	G4	G6	Scratch L 2			Cuica L			Hi-Hat Closed Lo-Fi		2						
80	G#4	G#6							Hi-Hat Open Lo-Fi		2						
81	A4	A6							Hi-Hat Closed Syn		8						
82	A#4	A#6	Analog Shaker			Analog Shaker			Hi-Hat Open Syn		8						
83	B4	B6							Analog Shaker 2								
84	C5	C7	Wind Chime			Wind Chime			Tambourine RX5 2						Wind Chime		
85	C#5	(C#7)	Snare Piccolo			Snare Break Roll			Tambourine 1 Hit								
86	D5	(D7)	Snare T8 7			Noise Burst			Electric Cowbell								
87	D#5	(D#7)	SnareRckRollDist			Vox Bell			Conga T8 3								
88	E5	(E7)	Snare Brush Mute			Snare R&B 1			ElectricTriangle								
89	F5	(F7)	Kick Blip Hard			Vox Alk			Claves T8 2								
90	F#5	(F#7)	Snare Jungle 1			Udu High			Analog Shaker 3								
91	G5	(G7)	Kick Sustain			Filter Kick			Electric Clap 1								

No Sound

*1 Key Off: Keys marked "●" stop sounding the instant they are released.

*2 Alternate Group: Playing any instrument within a numbered group will immediately stop the sound of any other instrument in the same group of the same number.

CVP-709	○ (Live!)	○ (Live!)	○ (Live!)	○ (Live!)
CVP-705	○ (Live!)	○ (Live!)	○ (Live!)	○ (Live!)

Kit Name			Power Kit 2			Acoustic Kit			Rock Kit			Real Drums		
MSB-LSB-PC#			127-0-88			127-0-89			127-0-90			127-0-91		
Note#	MIDI Note	Keyboard Note	Full Name	Key Off (*1)	Alt Grp (*2)	Full Name	Key Off	Alt Grp	Full Name	Key Off	Alt Grp	Full Name	Key Off	Alt Grp
13	C#-1	C#1												
14	D-1	D1												
15	D#-1	D#1												
16	E-1	E1												
17	F-1	F1												
18	F#-1	F#1												
19	G-1	G1												
20	G#-1	G#1												
21	A-1	A1												
22	A#-1	A#1												
23	B-1	B1												
24	C0	C2												
25	C#0	C#2												
26	D0	D2										Brush Tap Swirl	●	
27	D#0	D#2												
28	E0	E2												
29	F0	F2												
30	F#0	F#2				Snare Roll Acoustic	●		Snare Roll Rock	●		Snare Roll Rock	●	
31	G0	G2	Snare Soft Power 2			Snare Soft Acoustic			Snare Soft Rock			Snare Tight		
32	G#0	G#2												
33	A0	A2	Kick Ambient+			Kick Soft Acoustic			Kick Soft Rock			Kick Genuine		
34	A#0	A#2	Open Rim Power 2			Rim Acoustic			Rim Rock			Rim Real		
35	B0	B2	Kick Power Open			Kick Mute Acoustic			Kick Rock Heavy			Kick Real 1		
36	C1	C3	Kick Power Mute			Kick Open Acoustic			Kick Rock			Kick Real 2		
37	C#1	C#3	Side Stick Power			Stick Acoustic			Stick Rock			Stick Real		
38	D1	D3	Snare Power 2			Snare Acoustic			Snare Rock			Snare Real 1		
39	D#1	D#3	Hand Clap Power			Hand Clap Power			Hand Clap Power			Clap Power		
40	E1	E3	Snare Loose			Snare Rough Acoustic			Snare Dry Rock			Snare Real 2		
41	F1	F3	Tom Power 1			Tom Acoustic 1			Tom Rock 1			Tom Real 1		
42	F#1	F#3	Hi-Hat Closed Power+Edge		1	Hi-Hat Closed Acoustic		1	Hi-Hat Closed Rock		1	Hi-Hat Closed Real		1
43	G1	G3	Tom Power 2			Tom Acoustic 2			Tom Rock 2			Tom Real 2		
44	G#1	G#3	Hi-Hat Pedal Power		1	Hi-Hat Pedal Acoustic		1	Hi-Hat Pedal Rock		1	Hi-Hat Pedal Real		1
45	A1	A3	Tom Power 3			Tom Acoustic 3			Tom Rock 3			Tom Real 3		
46	A#1	A#3	Hi-Hat Open Power		1	Hi-Hat Open Acoustic		1	Hi-Hat Open Rock		1	Hi-Hat Open Real		1
47	B1	B3	Tom Power 4			Tom Acoustic 4			Tom Rock 4			Tom Real 4		
48	C2	C4	Tom Power 5			Tom Acoustic 5			Tom Rock 5			Tom Real 5		
49	C#2	C#4	Crash Cymbal Acoustic 1			Crash Cymbal Acoustic 1			Crash Cymbal Acoustic 1			Crash Cymbal Real 1		
50	D2	D4	Tom Power 6			Tom Acoustic 6			Tom Rock 6			Tom Real 6		
51	D#2	D#4	Ride Cymbal Acoustic 1			Ride Cymbal Acoustic 1			Ride Cymbal Acoustic 1			Ride Cymbal Real 1		
52	E2	E4	China Cymbal Acoustic			China Cymbal Acoustic			China Cymbal Acoustic			China Cymbal Real		
53	F2	F4	Ride Cymbal Cup Acoustic			Ride Cymbal Cup Acoustic			Ride Cymbal Cup Acoustic			Ride Cymbal Cup Real		
54	F#2	F#4												
55	G2	G4	Splash Cymbal Acoustic			Splash Cymbal Acoustic			Splash Cymbal Acoustic			Splash Cymbal Real		
56	G#2	G#4												
57	A2	A4	Crash Cymbal Acoustic 2			Crash Cymbal Acoustic 2			Crash Cymbal Acoustic 2			Crash Cymbal Real 2		
58	A#2	A#4												
59	B2	B4	Ride Cymbal Acoustic 2			Ride Cymbal Acoustic 2			Ride Cymbal Acoustic 2			Ride Cymbal Real 2		
60	C3	C5												
61	C#3	C#5												
62	D3	D5												
63	D#3	D#5												
64	E3	E5												
65	F3	F5												
66	F#3	F#5												
67	G3	G5												
68	G#3	G#5												
69	A3	A5												
70	A#3	A#5												
71	B3	B5												
72	C4	C6												
73	C#4	C#6												
74	D4	D6												
75	D#4	D#6												
76	E4	E6												
77	F4	F6												
78	F#4	F#6												
79	G4	G6												
80	G#4	G#6												
81	A4	A6												
82	A#4	A#6												
83	B4	B6												
84	C5	C7	Wind Chime			Wind Chime			Wind Chime			Wind Chime		
85	C#5	(C#7)												
86	D5	(D7)												
87	D#5	(D#7)												
88	E5	(E7)												
89	F5	(F7)												
90	F#5	(F#7)												
91	G5	(G7)												

Same as Standard Kit 1

*1 Key Off: Keys marked "●" stop sounding the instant they are released.

*2 Alternate Group: Playing any instrument within a numbered group will immediately stop the sound of any other instrument in the same group of the same number.

No Sound

CVP-709			○	○	○ (Live!)	○ (Live!)	○										
CVP-705			○	○	○ (Live!)	○ (Live!)	○										
Kit Name			SFX Kit 1 (*)			SFX Kit 2 (*)			New SFX Kit 1 (*)			New SFX Kit 2 (*)			Noises Kit (*)		
MSB-LSB-PC#			126-0-0			126-0-1			126-0-2			126-0-3			126-0-8		
Note#	MIDI Note	Keyboard Note	Full Name	Key Off (*1)	Alt Grp (*2)	Full Name	Key Off	Alt Grp	Full Name	Key Off	Alt Grp	Full Name	Key Off	Alt Grp	Full Name	Key Off	Alt Grp
13	C#-1	C#1															
14	D-1	D1															
15	D#-1	D#1															
16	E-1	E1															
17	F-1	F1															
18	F#-1	F#1															
19	G-1	G1															
20	G#-1	G#1															
21	A-1	A1															
22	A#-1	A#1															
23	B-1	B1															
24	C0	C2															
25	C#0	C#2															
26	D0	D2															
27	D#0	D#2															
28	E0	E2															
29	F0	F2															
30	F#0	F#2															
31	G0	G2															
32	G#0	G#2															
33	A0	A2															
34	A#0	A#2															
35	B0	B2															
36	C1	C3	Cutting Noise 1	●		Phone Call	●		Cutting Noise 1	●		Phone Call 2	●		White Noise	●	
37	C#1	C#3	Cutting Noise 2	●		Door Squeak	●		Cutting Noise 2	●		Door Squeak 2	●		Pink Noise	●	
38	D1	D3				Door Slam	●					Door Slam 2	●		White Noise Down 1	●	
39	D#1	D#3	String Slap	●		Scratch Cut	●		String Slap	●		Scratch Cut	●		Pink Noise Down 1	●	
40	E1	E3				Scratch Split	●					Scratch Split	●		White Noise Down 2	●	
41	F1	F3				Wind Chime	●					Wind Chime	●		Pink Noise Down 2	●	
42	F#1	F#3				Telephone Ring	●					Telephone Ring 2	●		White Noise Up 2	●	
43	G1	G3													White Noise Up 1	●	
44	G#1	G#3													Pink Noise Up	●	
45	A1	A3													White Noise Up Release	●	
46	A#1	A#3													Pink Noise Up Release	●	
47	B1	B3													White Noise Up LFO	●	
48	C2	C4													Pink Noise Up LFO	●	
49	C#2	C#4															
50	D2	D4															
51	D#2	D#4															
52	E2	E4	Flute Key Click	●		Car Engine Ignition	●		Flute Key Click	●		Car Engine Ignition	●				
53	F2	F4				Car Tires Squeal	●					Car Tires Squeal	●				
54	F#2	F#4				Car Passing	●					Car Passing	●				
55	G2	G4				Car Crash	●					Car Crash	●				
56	G#2	G#4				Siren	●					Siren 2	●				
57	A2	A4				Train	●					Train 2	●				
58	A#2	A#4				Jet Plane	●					Jet Plane 2	●				
59	B2	B4				Starship	●					Starship	●				
60	C3	C5				Burst	●					Burst	●				
61	C#3	C#5				Roller Coaster	●					Roller Coaster	●				
62	D3	D5				Submarine	●					Submarine	●				
63	D#3	D#5															
64	E3	E5															
65	F3	F5															
66	F#3	F#5															
67	G3	G5															
68	G#3	G#5	Shower	●		Laugh	●		Shower 2	●		Laugh	●				
69	A3	A5	Thunder	●		Scream	●		Thunder 2	●		Scream 2	●				
70	A#3	A#5	Wind	●		Punch	●		Wind 2	●		Punch 2	●				
71	B3	B5	Stream	●		Heart Beat	●		Stream 2	●		Heart Beat	●				
72	C4	C6	Bubble	●		Foot Steps	●		Bubble 2	●		Foot Steps 2	●				
73	C#4	C#6	Feed	●					Feed	●							
74	D4	D6															
75	D#4	D#6															
76	E4	E6															
77	F4	F6															
78	F#4	F#6															
79	G4	G6															
80	G#4	G#6															
81	A4	A6															
82	A#4	A#6															
83	B4	B6															
84	C5	C7	Dog	●		Machine Gun	●		Dog	●		Machine Gun 2	●				
85	C#5	(C#7)	Horse	●		Laser Gun	●		Horse	●		Laser Gun	●				
86	D5	(D7)	Bird Tweet	●		Explosion	●		Bird Tweet	●		Explosion 2	●				
87	D#5	(D#7)				Firework	●					Firework	●				
88	E5	(E7)															
89	F5	(F7)															
90	F#5	(F#7)	Ghost	●					Ghost	●							
91	G5	(G7)	Maou	●					Maou	●							

■ No Sound

*Actual Keyboard Notes are one octave lower than the ones described in the above list.

*1 Key Off: Keys marked "●" stop sounding the instant they are released.

*2 Alternate Group: Playing any instrument within a numbered group will immediately stop the sound of any other instrument in the same group of the same number.

CVP-709			○	○ (Live!)	○ (Live!)	○ (Live!)	○ (Live!)										
CVP-705			○	○ (Live!)	○ (Live!)	—	—										
Kit Name			Arabic Kit			Cuban Kit			Pop Latin Kit			Pop Latin Kit 2			Cymbal Kit		
MSB-LSB-PC#			126-0-35			126-0-40			126-0-43			126-0-44			126-0-49		
Note#	MIDI Note	Keyboard Note	Full Name	Key Off (*1)	Alt Grp (*2)	Full Name	Key Off	Alt Grp	Full Name	Key Off	Alt Grp	Full Name	Key Off	Alt Grp	Full Name	Key Off	Alt Grp
13	C#-1	C#1							Cajon Low			Cajon Low					
14	D-1	D1							Cajon Slap			Cajon Slap					
15	D#-1	D#1							Cajon Tip			Cajon Tip					
16	E-1	E1							Claves High			Claves High					
17	F-1	F1							Claves Low			Claves Low					
18	F#-1	F#1							Hand Clap			Hand Clap					
19	G-1	G1															
20	G#-1	G#1							Finger Snap			Finger Snap					
21	A-1	A1							Castanet			Castanet					
22	A#-1	A#1							Conga H Tip			Conga H Tip					
23	B-1	B1							Conga H Heel			Conga H Heel					
24	C0	C2	Nakarazan Dom						Conga H Open			Conga H Open					
25	C#0	C#2	Cabasa						Conga H Mute			Conga H Mute					
26	D0	D2	Nakarazan Edge						Conga H Slap Open			Conga H Slap Open					
27	D#0	D#2	Hager Dom						Conga H Slap			Conga H Slap					
28	E0	E2	Hager Edge						Conga H Slap Mute			Conga H Slap Mute					
29	F0	F2	Bongo H						Conga L Tip			Conga L Tip					
30	F#0	F#2	Bongo L						Conga L Heel			Conga L Heel					
31	G0	G2	Conga H Mute						Conga L Open			Conga L Open					
32	G#0	G#2	Conga H Open						Conga L Mute			Conga L Mute					
33	A0	A2	Conga L						Conga L Slap Open			Conga L Slap Open					
34	A#0	A#2	Zagrouda H						Conga L Slap			Conga L Slap					
35	B0	B2	Zagrouda L	●					Conga L Slide	●		Conga L Slide	●				
36	C1	C3	Kick Soft						Bongo H Open One Finger			Bongo H Open One Finger					Kick A
37	C#1	C#3	Side Stick						Bongo H Open Three Finger			Bongo H Open Three Finger					Timbale A
38	D1	D3	Snare Soft						Bongo H Rim			Bongo H Rim					China Cymbal A
39	D#1	D#3	Arabic Hand Clap						Bongo H Tip			Bongo H Tip					Crash Cymbal A
40	E1	E3	Snare Drum						Bongo H Heel			Bongo H Heel					Ride Cymbal A
41	F1	F3	Floor Tom L						Bongo H Slap			Bongo H Slap					Splash Cymbal A
42	F#1	F#3	Hi-Hat Closed		1				Bongo L Open One Finger			Bongo L Open One Finger					
43	G1	G3	Floor Tom H						Bongo L Open Three Finger			Bongo L Open Three Finger					
44	G#1	G#3	Hi-Hat Pedal		1				Bongo L Rim			Bongo L Rim					Crash Cymbal B1
45	A1	A3	Low Tom						Bongo L Tip			Bongo L Tip					Crash Cymbal B2
46	A#1	A#3	Hi-Hat Open		1				Bongo L Heel			Bongo L Heel					Ride Cymbal B
47	B1	B3	Mid Tom L						Bongo L Slap			Bongo L Slap					
48	C2	C4	Mid Tom H						Timbale L			Timbale L					
49	C#2	C#4	Crash Cymbal 1														Crash Cymbal C
50	D2	D4	High Tom														Ride Cymbal C
51	D#2	D#4	Ride Cymbal 1														Brush Ride Cymbal C
52	E2	E4	Crash Cymbal 2														Brush Sizzle Cymbal C
53	F2	F4	Duhulla Dom						Paila L			Paila L					
54	F#2	F#4	Tambourine						Timbale H			Timbale H					
55	G2	G4	Duhulla Tak														Crash Cymbal D1
56	G#2	G#4	Cowbell														Crash Cymbal D2
57	A2	A4	Duhulla Sak														Crash Cymbal D3
58	A#2	A#4	Claves														Ride Cymbal D
59	B2	B4	Doff Dom						Paila H			Paila H					Splash Cymbal D
60	C3	C5	Katemb Dom						Cowbell Top			Cowbell Top					
61	C#3	C#5	Katemb Tak						Cowbell 1			Cowbell 1					
62	D3	D5	Katemb Sak						Cowbell 2			Cowbell 2					Crash Cymbal E1
63	D#3	D#5	Katemb Tak						Cowbell 3			Cowbell 3					Crash Cymbal E2
64	E3	E5	Doff Tak						Guiro Short			Guiro Short					Ride Cymbal E
65	F3	F5	Tabla Dom						Guiro Long	●		Guiro Long	●				Hi-Hat Half Open E
66	F#3	F#5	Tabla Tak 1														
67	G3	G5	Tabla Tik						Metal Guiro Short			Metal Guiro Short					
68	G#3	G#5	Tabla Tak 2						Metal Guiro Long	●		Metal Guiro Long	●				
69	A3	A5	Tabla Sak						Tambourine			Tambourine					
70	A#3	A#5	Tabla Roll Edge	●					Tambourim Open			Tambourim Open					
71	B3	B5	Tabla Flam						Tambourim Mute			Tambourim Mute					
72	C4	C6	Sagat 1						Tambourim Tip			Tambourim Tip					
73	C#4	C#6	Tabel Dom						Maracas			Maracas					Crash Cymbal F1
74	D4	D6	Sagat 3						Shaker			Shaker					Brush Crash Cymbal F1
75	D#4	D#6	Tabel Tak						Cabasa			Cabasa					Crash Cymbal F2
76	E4	E6	Sagat 2						Cuica Mute			Cuica Mute					Jazz Ride Cymbal F1
77	F4	F6	Rik Dom						Cuica Open			Cuica Open					Crash Cymbal F3
78	F#4	F#6	Rik Tak 2						Cowbell High 1			Cowbell High 1					Hi-Hat Splash F
79	G4	G6	Rik Finger 1						Cowbell High 2			Cowbell High 2					Ride Cymbal F1
80	G#4	G#6	Rik Tak 1						Shekere			Shekere					Crash Cymbal F4
81	A4	A6	Rik Finger 2						Shekere Tone			Shekere Tone					Ride Cymbal F2
82	A#4	A#6	Rik Brass Tremolo	●					Triangle Mute		1	Triangle Mute		1			Brush Crash Cymbal F2
83	B4	B6	Rik Sak						Triangle Open		1	Triangle Open		1			Jazz Ride Cymbal F2
84	C5	C7	Rik Tik														Crash Cymbal F5
85	C#5	(C#7)							Wind Chime			Wind Chime					
86	D5	(D7)															
87	D#5	(D#7)															
88	E5	(E7)															
89	F5	(F7)															
90	F#5	(F#7)															
91	G5	(G7)															

■ No Sound

*1 Key Off: Keys marked "●" stop sounding the instant they are released.

*2 Alternate Group: Playing any instrument within a numbered group will immediately stop the sound of any other instrument in the same group of the same number.

CVP-709			○ (Live!)			○ (Live!)			○ (Live!)		
CVP-705			○ (Live!)			—			—		
Kit Name			Turkish Kit			Vocal Effects Kit (*)			Gospel Ad Libs (*)		
MSB-LSB-PC#			126-0-67			126-0-109			126-0-110		
Note#	MIDI Note	Keyboard Note	Full Name	Key Off (*1)	Alt Grp (*2)	Full Name	Key Off	Alt Grp	Full Name	Key Off	Alt Grp
13	C#-1	C#1	Asma Davul Left Side								
14	D-1	D1	Asma Davul Right Side								
15	D#-1	D#1	Asma Davul Side Body								
16	E-1	E1	Asma Davul Both Sides								
17	F-1	F1	Koltuk Davul Flam								
18	F#-1	F#1	Koltuk Davul Teke								
19	G-1	G1	Koltuk Davul Tek								
20	G#-1	G#1	Koltuk Davul Dum								
21	A-1	A1	Bendir Teke Flam								
22	A#-1	A#1	Bendir Teke Dead								
23	B-1	B1	Bendir Tek Dead								
24	C0	C2	Bendir Teke								
25	C#0	C#2	Bendir Tek								
26	D0	D2	Bendir Slap		2						
27	D#0	D#2	Bendir Dum		2						
28	E0	E2	Zil Right Close		3						
29	F0	F2	Zil Right Open		3						
30	F#0	F#2	Zil Left Close		4						
31	G0	G2	Zil Left Open		4						
32	G#0	G#2	Tef Teke Flam		5						
33	A0	A2	Tef Tek Mute		5						
34	A#0	A#2	Tef Teke Damped								
35	B0	B2	Tef Tek Mute Medium								
36	C1	C3	Tef Dum Mute			Male "Ha" 1	●				
37	C#1	C#3	Tef Cymbal		9	Female "Ha" 1	●				
38	D1	D3	Tef Cymbal Mute		9	Male "Ha" 2	●				
39	D#1	D#3	Tef Tremolo	●		Male "Ha" 3	●				
40	E1	E3	Tef Shake 1			Male "Bh" 1	●				
41	F1	F3	Tef Shake 2			Female "Bh" 1	●				
42	F#1	F#3	Tef Tek Flam			Male "Kh" 1	●				
43	G1	G3	Tef Full Open			Female "Kh" 1	●				
44	G#1	G#3	Tef Teke Open Short			Male "Ph" 1	●				
45	A1	A3	Tef Tek Open Short			Female "Ph" 1	●				
46	A#1	A#3	Tef Tek Open			Male "Th" 1	●				
47	B1	B3	Tef Dum Open			Female "Th" 1	●				
48	C2	C4	Hollo Finger Dead			Male "Bh" 2	●	C'mon	●		
49	C#2	C#4	Hollo Slap			Female "Bh" 2	●	Hoo!	●		
50	D2	D4	Hollo Dum			Male "Kh" 2	●	Aha!	●		
51	D#2	D#4	Kasik		1	Female "Kh" 2	●	Oh Yeah	●		
52	E2	E4	Kasik Flam		1	Male "Ph" 2	●	Yayayayah	●		
53	F2	F4	Bass Darbuka Tek Dead			Female "Ph" 2	●	Put Your Hands Together	●		
54	F#2	F#4	Bass Darbuka Tek Flam			Male "Th" 2	●	C'mon Now	●		
55	G2	G4	Bass Darbuka Teke			Female "Th" 2	●	Heeey	●		
56	G#2	G#4	Bass Darbuka Teke Other Finger			Male "Ha" 4	●	Everybody Now	●		
57	A2	A4	Bass Darbuka Teke Index Finger			Female "Ha" 2	●	Clap Your Hands, Everybody C'mon	●		
58	A#2	A#4	Bass Darbuka Tek			Male "Ha" 5	●	With All Your Soul	●		
59	B2	B4	Bass Darbuka Slap			Male "Ha" 6	●	Stand Up On Your Feet	●		
60	C3	C5	Bass Darbuka Slap Medium		7	Male "Bh" 3	●	Uhh Yeah	●		
61	C#3	C#5	Bass Darbuka Dum		7	Female "Bh" 3	●	Aaah	●		
62	D3	D5	Darbuka Roll Close	●	6	Male "Kh" 3	●	Come On!	●		
63	D#3	D#5	Darbuka Roll Open	●	6	Female "Kh" 3	●	Yeah!	●		
64	E3	E5	Darbuka Teke Damped Flam			Male "Ph" 3	●	Alright Now!	●		
65	F3	F5	Darbuka Tek Dead			Female "Ph" 3	●	One	●		
66	F#3	F#5	Darbuka Tek Damped			Male "Th" 3	●	Two	●		
67	G3	G5	Darbuka Teke Open Flam			Female "Th" 3	●	Three	●		
68	G#3	G#5	Darbuka Teke Open			Male "Bh" 4	●	Four	●		
69	A3	A5	Darbuka Teke Other Finger 1			Female "Bh" 4	●	One!	●		
70	A#3	A#5	Darbuka Teke Index Finger 1			Male "Kh" 4	●	Two!	●		
71	B3	B5	Darbuka Tek 1			Female "Kh" 4	●	Three!	●		
72	C4	C6	Darbuka Teke Other Finger 2			Male "Ph" 4	●	Four!	●		
73	C#4	C#6	Darbuka Teke Index Finger 2			Female "Ph" 4	●	Five!	●		
74	D4	D6	Darbuka Tek 2			Male "Th" 4	●	Six!	●		
75	D#4	D#6	Darbuka Slap Medium			Female "Th" 4	●	Seven!	●		
76	E4	E6	Darbuka Slap		8			Eight!	●		
77	F4	F6	Darbuka Dum		8			Clap!	●		
78	F#4	F#6	Bongo Tek Roll	●				Gospel Clap 1	●		
79	G4	G6	Bongo Flam					Gospel Clap 2	●		
80	G#4	G#6	Bongo Tek Flam								
81	A4	A6	Bongo Tek								
82	A#4	A#6	Bongo Slap								
83	B4	B6	Bongo Flam Hi								
84	C5	C7	Bongo Dum								
85	C#5	(C#7)									
86	D5	(D7)									
87	D#5	(D#7)									
88	E5	(E7)									
89	F5	(F7)									
90	F#5	(F#7)									
91	G5	(G7)									

■ No Sound

*Actual Keyboard Notes are one octave lower than the ones described in the above list.

*1 Key Off: Keys marked "●" stop sounding the instant they are released.

*2 Alternate Group: Playing any instrument within a numbered group will immediately stop the sound of any other instrument in the same group of the same number.

Style List / Liste der Styles / Liste des styles / Lista de estilos / Lista de estilos

CVP-709

Category	Sub Category	Style Name				
Pop&Rock	Pop	Contemp Gtr Pop				
		Standard 8Beat				
		West Coast Beat				
		Cool 8Beat				
		80s American Pop				
		Live 8Beat				
		80s Guitar Pop				
		Classic 8Beat				
		80s Pop				
		80s 8Beat				
		Pop Evergreen				
		Chart Piano Shuffle				
		00s Boy Band				
		Chart Rock Shuffle				
		80s Boy Band				
		Chart Guitar Pop				
		90s Pop Shuffle				
		Contemp Pop				
		90s Guitar Pop				
		Jersey Pop				
		Easy Pop				
		Chart Pop				
		Pop Shuffle				
		Straight 8 Pop				
		Scand Pop Shuffle				
		Uptempo 8Beat				
		Brit Pop				
		8Beat Modern				
		Brit Pop Swing				
		West Coast Pop				
		Unplugged				
		8Beat Guitar Pop				
		Classic 16Beat				
		8Beat				
		Rock	Rock	Stadium Rock		
				Standard Rock		
				80s Power Rock		
				Contemp Rock		
				80s Pop Rock		
				Funk Pop Rock		
				80s Synth Rock		
				Acoustic Rock		
				Brit Rock Pop		
				Soft Rock		
				Slow Rock		
				70s Pop&Rock	70s Pop&Rock	70s Piano Hit
						70s Pop Duo 1
						70s Piano Rock
						70s Pop Duo 2
		70s Glam Piano				
	70s Cool Ballad					
	70s Swing Piano					
	70s Easy Pop					
	Glam Piano Rock					
	70s 8Beat					
	70s Rock					
	Croco Twist					
	70s Rock Shuffle					
	Vintage Guitar Pop					
	70s Rock Bros					
	60s Pop&Rock	60s Pop&Rock	60s Big Hit			
			Surf Rock			
			60s Underground			
			Beach Rock			
			60s Rising Pop			
			Bubblegum Pop			
			60s Vintage Pop			
			60s Guitar Pop			
			60s Piano Pop			

Category	Sub Category	Style Name			
Pop&Rock	60s Pop&Rock	60s Chart Swing			
		60s Pop Rock			
		60s Rock & Roll			
		60s Vintage Rock			
		60s 8Beat			
		50s Rock&Roll	50s Rock&Roll	Vintage R&R	
				Rock & Roll 1	
				50s Rock & Roll	
				Rock & Roll 2	
				Oldies R&R	
	Rock & Roll Shfl				
	Skiffle				
	Piano R&R				
	Pop&Rock Ballad			Pop&Rock Ballad	Easy 8Beat 1
					6-8 Soul Ballad
		Easy 8Beat 2			
		6-8 Ballad Rock			
		90s Piano Ballad			
		Standard Piano Bld			
		Smooth Ballad			
		70s Piano Pop Bld			
		Mod 6-8 Piano Bld			
		70s R&B Pop Bld			
		Acoustic 8Bt Bld			
		Light Ballad			
		Orch Rock Ballad			
		Pop Ballad			
		Vocal Pop Ballad			
		Pop Guitar Ballad			
		Mod Orch Ballad			
		Epic Ballad			
		Boy Band Ballad			
		Modern Pop Ballad			
		70s Chart Ballad			
		80s Movie Ballad			
		80s Piano Ballad			
		80s Synth Piano			
		80s Smooth Ballad			
		90s Cool Ballad			
		80s Analog Ballad			
		90s Rock Ballad			
		80s EP Ballad			
		MOR 16Beat			
		8Beat Ballad 1			
		Power Ballad 1			
		8Beat Ballad 2			
		Power Ballad 2			
		Acoustic Gtr Ballad			
		Guitar Ballad			
		Easy Acoustic Bld			
		Organ Ballad			
		Pop Piano Ballad			
		EP Ballad			
		16Beat Pop			
		Contemp Rock Bld			
		16Beat Ballad			
		Chart Ballad			
		Modern 16Bt Ballad			
	Slow & Easy				
	Contemp Pop Bld				
	Acoustic Ballad				
	6-8 Modern				
	Love Song				
	Pop Waltz				
	Slow Orch Ballad				
	Piano Ballad				
	8Beat Piano Ballad				
	Worship	Worship	Worship Slow		
			Worship 6-8		

Category	Sub Category	Style Name			
Pop&Rock	Worship	Worship Medium			
		Worship Irish Rock			
		Worship Fast			
		Worship Power Bld			
		Soul	Soul	Funky Shuffle	
	Detroit Pop 1				
	70s Cool Shuffle				
	Detroit Pop 2				
	70s Chart Soul				
	Motor City				
	Soul Brothers				
	Frankly Soul				
	Live Soul Band				
	Kool Funk				
	Soul				
	Kool Shuffle				
	Soul Shuffle				
	Lovely Shuffle				
	Soul Beat				
	UK Soul Pop				
	Disco	Disco	Funk Disco		
			80s Disco		
			70s Disco 1		
			90s Disco		
			70s Disco 2		
			Disco Philly		
			70s Disco Funk		
			Disco House		
			Saturday Night		
			Pop Legend		
			Synth Pop		
			Disco Fox Rock		
			80s Synth Disco		
			Mallorca Disco		
			Movie Disco		
	Disco Chocolate				
	Dance	Dance	Global DJ's		
			Clubdance 1		
			Ibiza 2010		
			Clubdance 2		
			Club House		
			Dream Dance		
			Electronica		
			Retro Pop		
			Funky House		
			Dancefloor		
			Dancehall		
			Modern R&B	Modern R&B	Cool R&B
					Modern Hip Hop
					R&B Soul Ballad
					Euro Hip Hop
	New R&B Ballad				
	US Hip Hop				
	Soul R&B				
	Classic Hip Hop				
	Chart R&B				
	New Hip Hop				
	Pop R&B				
	Trip Hop				
	New R&B				
	Groundbeat				
	Modern R&B				
	Analog Ballad				
	Chill Out	Chill Out	Chill Performer		
			Chillout 1		
			Coudy Bay		
			Chillout 2		
			Night Walk		
	Chillout Cafe				

CVP-709

Category	Sub Category	Style Name	
Pop&Rock	Chill Out	Play 4 Sofa	
		Ethereal Synth	
		Angel Sun	
	Trance	Celtic Trance	
		6-8 Trance	
		Euro Trance	
		Trance Pop	
Country&Blues	Modern Country	Easy Country Pop	
		70s Country Pop	
		Country Blues	
		70s Chart Country	
		Modern Pickin'	
		New Country	
		Calif Country	
		Country Strum	
		Country Straits	
		Modern Bluegrass	
		Country Hits	
		Country Brothers	
		Country 8Beat	
		Modern Cntry Pop	
		Country Pop	
		Singer Song Writer	
		Country Rock	
		Hully Gully	
		Trad Country	70s Country Swing
			Country Swing 1
	Pickin' Swing		
	Country Swing 2		
	Easy Country		
	Country Shuffle		
	Bluegrass		
	Country Sing-along		
	Hoedown		
	Standard Swing		
	Country 2-4		
	Finger Pickin'		
	Country Two Step		
	Folk Pop		
	Country Ballad		Slow Country Pop
		Country Ballad	
		Mod Country Bld 1	
		Country Rock Bld	
		Mod Country Bld 2	
	Blues	Country Waltz	
		Country Pop Ballad	
		The Blues	
		Modern Shuffle	
		Slow Blues	
		Let's Funk	
		Shuffle Blues	
		6-8 Rock	
Blueberry Blues			
6-8 Soul			
Blues Rock			
Soul Swing			
Piano Blues 1			
Piano Blues 2			
Gospel	Hollywood Gospel		
	Gospel Funk		
	Amazing Gospel		
	Gospel Brothers		
	Gospel Ballad		
	Gospel Sisters		
	Gospel Party		
	Gospel Swing		
	Southern Gospel		
Standards & Jazz	Jazz Combo	Cool Jazz Club	
		Jazz Guitar Club	

Category	Sub Category	Style Name	
Standards & Jazz	Jazz Combo	Slow Jazz Ballad	
		Instrumental Jazz	
		Swing Medium	
		Manhattan Swing	
		Fast Jazz	
		Trad Piano Jazz	
		Acoustic Jazz	
		Trad Piano Ballad	
		Cool Piano Jazz	
		French Jazz	
		Modern Jazz Bld 1	
		Organ Combo	
		Modern Jazz Bld 2	
		Piano Boogie	
		Jazz Club	
		Boogie Fast	
		Bebop	
		Boogie Woogie	
		Piano Swing 1	
		Jazz Ballad	
		Piano Swing 2	
		2Beat Swing	
		Big Band	Big Band Jazz
			The Jazz Singers
			Modern Big Band
			40s Swing Ballad
			Mod Big Band Shfl
			Classic Big Band
			Mod Big Band Bld
			Jump Jive
			Afro Cuban
			'Swingin' Boogie
			Orch Big Band 1
			Big Band Medium 1
			Orch Big Band 2
	Big Band Medium 2		
	30s Big Band		
	Big Band Fast 1		
	40s Big Band		
	Big Band Fast 2		
	'Swingin' Big Band		
	Moonlight Ballad		
	Orchestra Swing	Easy Swing	
		Orchestra Swing 1	
		MOR Swing	
		Orchestra Swing 2	
		Dreamy Ballad	
		Easy Listening	
		Cool Jazz Ballad	
		Orchestral Ballad	
LA Cool Swing			
Midnight Swing			
Organ Groove			
Jazz Waltz	Cool Jazz Waltz		
	Easy Waltz		
	Jazz Waltz Slow		
	MOR Waltz		
	Jazz Waltz Medium		
	Five-Four		
	Jazz Waltz Fast 1		
Jazz Waltz			
Jazz Waltz Fast 2			
Dixie&Trad Jazz	Ragtime 1		
	Piano Rag 1		
	Ragtime 2		
	Piano Rag 2		
	Dixieland 1		
	Stride 1		
	Dixieland 2		

Category	Sub Category	Style Name	
Standards & Jazz	Dixie&Trad Jazz	Stride 2	
		Charleston	
		Saloon Piano	
		Fusion	70s Scat Legend
			Jazz Pop
	Fusion Shuffle		
	Entertainment	Movie&Show	Jazz Funk
			Movie Soundtrack
			Mod Broadway Bld
			Ethereal Movie
Broadway Ballad			
On Broadway			
Movie Swing 1			
Cartoon Ballad			
Movie Swing 2			
Animation Ballad			
Tap Dance Swing			
Sci-fi March			
70s TV Theme			
Blockbuster			
Big Screen Classic			
Secret Service			
Movie Ballad			
Wild West			
Showtune			
Choir Soundtrack			
Animation Fantasy			
Movie Panther			
Musical			
Easy Listening		Classic Piano Bld	
		Easy Ballad	
		Romantic Ballad	
		Guitar Serenade	
		Romantic Waltz	
		Piano Orch Ballad	
		6-8 Slow Rock 1	
		6-8 Orchestral	
		6-8 Slow Rock 2	
		12-8 Ballad	
Tijuana			
French 50s			
Pub Piano			
Pop Classics			
Sing-a-long Piano			
Ballroom	Viennese Waltz 1		
	Slowfox		
	Viennese Waltz 2		
	Foxtrot		
	English Waltz		
	Swingfox		
	Slow Waltz		
	Vocal Foxtrot		
	Vocal Waltz		
	Quickstep		
	Tango 1		
	Cha Cha Cha		
	Tango 2		
	Jive		
	Pasodoble		
Beguine			
Samba			
Twist			
Rumba			
Swing Waltz			
9-8 Waltz			
Piano Rumba			
Standard Waltz			
Piano Cha Cha			

CVP-709

Category	Sub Category	Style Name	
Entertainment	Ballroom	Standard Rumba	
		Piano Beguine	
	Organ	Toccata	
		Elec Organ Ballad	
		Choral Hymn	
		Euro Pop Organ	
		Theatre Foxtrot	
		Organ Bossa	
		Theatre Quickstep	
		Organ Samba	
		Theatre March	
		Organ Cha Cha	
		Organ Swing	
		Organ Quickstep	
		Organ Rumba	
		Holiday	Christmas Swing 1
	Celtic Xmas		
	Christmas Swing 2		
	Christmas Ballad		
	Christmas Shuffle		
	Schlager	Christmas Waltz	
		Modern Schlager	
		Schlager Fever	
		Young Fox	
		Schlager Palace	
		Young Ballad	
		Party Arena	
		Hello Shuffle	
		Mallorca Party	
		Apres Ski Hit	
		Alpen Schlager	
		Disco Fox	
		Soft Schlager	
		German Rock	
		Schlager Fox	
		Synth Pop Duo	
		Schlager Italia	
		Alp Rock	
		Schlager Shuffle	
		70s French Hit	
		Schlager Waltz	
		Alp Ballad 1	
		Schlager Pop	
		Alp Ballad 2	
		Schlager Beat	
		Schlager Samba	
		Schlager Alp	
		Schlager Polka	
		Schlager Rumba	
		Schlager Rock	
		Schlager 6-8	
		Scand Bugg	
		Scand Shuffle	
		Scand Slow Rock	
		Party Polka	
	Scand Country 1		
	Polka Pop		
	Scand Country 2		
	8Beat Adria		
	Latin&World	Brazil	Brazilian Bossa
			Jazz Samba
			Cool Bossa
			Bossa Brazil
			Bossa Slow
			Lounge Bossa
			Bossa Fast
			Slow Bar Bossa
Samba Fast			
Orchestral Bossa			

Category	Sub Category	Style Name	
Latin&World	Brazil	Brazilian Samba	
		Bossa Nova	
		Big Band Samba	
		Slow Bossa	
		Piano Samba	
		Fast Bossa	
		Piano Bossa	
		Cuba	Rumba Bolero
			Salsa
			Guajira
			Big Band Salsa
			Danzon
			Big Band Mambo
			Guaguanco
	Guitar Rumba		
	Cuban Son		
	Mexico		Mariachi Waltz
		Banda Polka	
		Norteno	
		Banda Vals	
		Mexican Dance	
		Bolero Lento	
	Caribbean	Sheriff Reggae	
		Merengue	
		Happy Reggae	
		Cumbia	
		Calypso	
		Bomba	
		Caribbean	
		Bachata	
		Zouk	
		Vallenato 4-4	
	Rumba Island		
	European	Flamenco	
		Sirtaki	
		Pop Flamenco	
		Tarantella	
		Spanish Paso	
		Italian Mazurka	
		Rumba Flamenco	
		Italian Tango	
		Latin Pop	Latin Party Pop
			Pop Bossa 1
	Pop Latin		
	Pop Bossa 2		
	Pop Latin Ballad		
	Latin Disco 1		
	Rock Cha Cha		
	Latin Disco 2		
	Celtic	Celtic Dance 3-4	
		Jig	
		Celtic Dance	
		Reel	
		Irish Dance	
		Scottish Polka	
		Irish Hymn 1	
		Strathspey	
		Irish Hymn 2	
		Scand Schottis	
		World	Turkish Euro 1
	J-Pop Hit 1		
	Turkish Euro 2		
	J-Pop Hit 2		
	Oriental Pop		
	Hawaiian		
	Classic	Contemp Horns	
		Choral Symphony	
Proms March			
Ethereal Hymn			

Category	Sub Category	Style Name	
Latin&World	Classic	Romantic Ballet	
		Ethereal Voices	
		Green Fantasia	
		Baroque Air	
		String Adagio	
		Classical Menuet	
		Baroque Concerto	
		Moonlight 6-8	
		Classical Serenad	
		Nocturne	
		String Concerto	
		Traditional 1	
		Orchestral March	
		Traditional 2	
		Orchestral Bolero	
		Traditional 3	
		Arpeggio 1	
		Arpeggio 3	
		Arpeggio 2	
		Learning 2-4	
		Trad Waltz	Highland Waltz
			Scand Waltz
			French Waltz
			Ober Walzer 1
			Italian Waltz
			Ober Walzer 2
			German Waltz
			French Musette
			Bohemian Waltz
			Alpen Land 3-4
			Waltz
		Scand Hambo	
		Piano Slow Waltz	
	March&Polka	US March	
		Ober Polka 1	
		German March 1	
		Ober Polka 2	
		German March 2	
		Italian Polka	
		6-8 March	
		Zither Polka	
		Brass Band Hymn	
		Brass Band	
		Piano March 1	
		Orchestral Polka	
		Piano March 2	
	4 Stroke		
	6-8 Piano March		
	Alpen Land 4-4		

CVP-705

Category	Sub Category	Style Name			
Pop&Rock	Pop	Contemp Gtr Pop			
		Standard 8Beat			
		West Coast Beat			
		Cool 8Beat			
		80s American Pop			
		Live 8Beat			
		80s Guitar Pop			
		Classic 8Beat			
		80s Pop			
		Chart Piano Shuffle			
		Chart Rock Shuffle			
		80s Boy Band			
		Chart Guitar Pop			
		90s Guitar Pop			
		Easy Pop			
		Chart Pop			
		Straight 8 Pop			
		Scand Pop Shuffle			
		Uptempo 8Beat			
		Brit Pop			
		8Beat Modern			
		Brit Pop Swing			
		West Coast Pop			
		8Beat Guitar Pop			
		Classic 16Beat			
		8Beat			
		Rock	Rock	Standard Rock	
				80s Power Rock	
				Contemp Rock	
				80s Pop Rock	
				Funk Pop Rock	
				80s Synth Rock	
				Acoustic Rock	
				Brit Rock Pop	
				Soft Rock	
				Slow Rock	
		70s Pop&Rock	70s Pop&Rock	70s Piano Hit	
				70s Piano Rock	
				70s Pop Duo	
				70s Glam Piano	
				70s Swing Piano	
				Glam Piano Rock	
				70s 8Beat	
	70s Rock				
	Vintage Guitar Pop				
	60s Pop&Rock			60s Pop&Rock	60s Big Hit
					60s Rising Pop
					60s Guitar Pop
					60s Vintage Pop
		60s Chart Swing			
		60s Piano Pop			
		60s Rock & Roll			
		60s Pop Rock			
		Bubblegum Pop			
		60s Vintage Rock			
		60s 8Beat			
		50s Rock&Roll	50s Rock&Roll		Vintage R&R
					Oldies R&R
	Rock & Roll 1				
	Skiffle				
	Rock & Roll 2				
	Piano R&R				
	Rock & Roll Shfl				
	Pop&Rock Ballad			Pop&Rock Ballad	Easy 8Beat 1
		6-8 Soul Ballad			

Category	Sub Category	Style Name		
Pop&Rock	Pop&Rock Ballad	Easy 8Beat 2		
		6-8 Ballad Rock		
		90s Piano Ballad		
		Standard Piano Bld		
		Smooth Ballad		
		70s Piano Pop Bld		
		Mod 6-8 Piano Bld		
		Orch Rock Ballad		
		Pop Ballad		
		Pop Guitar Ballad		
		Epic Ballad		
		Modern Pop Ballad		
		70s Chart Ballad		
		80s Movie Ballad		
		80s Synth Piano		
		80s Smooth Ballad		
		90s Cool Ballad		
		80s Analog Ballad		
		90s Rock Ballad		
		80s EP Ballad		
		Power Ballad 1		
		8Beat Ballad 1		
		Power Ballad 2		
		8Beat Ballad 2		
		MOR 16Beat		
		Acoustic Gtr Ballad		
		Easy Acoustic Bld		
		Organ Ballad		
		Pop Piano Ballad		
		EP Ballad		
		16Beat Pop		
		Contemp Rock Bld		
		16Beat Ballad		
		Modern 16Bt Ballad		
		Contemp Pop Bld		
		Acoustic Ballad		
		6-8 Modern		
		Love Song		
		Pop Waltz		
		Slow Orch Ballad		
		Piano Ballad		
		8Beat Piano Ballad		
		Worship	Worship	Worship Slow
				Worship 6-8
				Worship Medium
				Worship Fast
				Worship Power Bld
				Soul
		Detroit Pop 1		
		70s Cool Shuffle		
		Detroit Pop 2		
		70s Chart Soul		
		Motor City		
		Frankly Soul		
		Live Soul Band		
		Kool Funk		
		Soul		
		Disco	Disco	Kool Shuffle
				Soul Shuffle
				Lovely Shuffle
	Soul Beat			
	Funk Disco			
	80s Disco			
	70s Disco 1			
	90s Disco			

Category	Sub Category	Style Name			
Pop&Rock	Disco	70s Disco 2			
		Disco Philly			
		70s Disco Funk			
		Disco House			
		Saturday Night			
		Synth Pop			
		Disco Fox Rock			
		80s Synth Disco			
		Movie Disco			
		Disco Chocolate			
		Dance	Dance	Global DJ's	
				Clubdance 1	
				Ibiza 2010	
				Clubdance 2	
				Club House	
				Dream Dance	
				Electronica	
				Retro Pop	
				Funky House	
				Dancefloor	
	Modern R&B			Modern R&B	Modern Hip Hop
					R&B Soul Ballad
					Euro Hip Hop
					New R&B Ballad
					Soul R&B
		Classic Hip Hop			
		Chart R&B			
		New R&B			
		Analog Ballad			
		Chill Out	Chill Out		Chillout 1
	Coudy Bay				
	Chillout 2				
	Night Walk				
	Chillout Cafe				
	Play 4 Sofa				
	Ethereal Synth				
	Angel Sun				
	Trance	Trance	Celtic Trance		
			6-8 Trance		
			Euro Trance		
	Country&Blues	Modern Country	Easy Country Pop		
			70s Country Pop		
			Country Blues		
			70s Chart Country		
			Modern Pickin'		
			New Country		
			Country Strum		
			Modern Bluegrass		
			Country Hits		
			Country Brothers		
			Country 8Beat		
			Modern Cntry Pop		
			Country Pop		
			Country Rock		
			Hully Gully		
		Trad Country	Trad Country	70s Country Swing	
				Country Swing	
				Pickin' Swing	
				Easy Country	
				Country Shuffle	
	Country&Blues	Country&Blues	Bluegrass		
			Country Sing-along		
			Hoedown		
			Standard Swing		
			Country 2-4		

CVP-705

Category	Sub Category	Style Name	
Country&Blues	Trad Country	Country Two Step	
		Folk Pop	
	Country Ballad	Slow Country Pop	
		Mod Country Bld 1	
		Country Rock Bld	
		Mod Country Bld 2	
		Country Waltz	
		Country Pop Ballad	
		Blues	The Blues
	Modern Shuffle		
	Slow Blues		
	Shuffle Blues		
	6-8 Rock		
	Blueberry Blues		
	6-8 Soul		
	Blues Rock		
	Piano Blues 1		
	Piano Blues 2		
	Gospel		Gospel Funk
			Gospel Brothers
			Gospel Sisters
		Gospel Swing	
		Southern Gospel	
	Standards & Jazz	Jazz Combo	Cool Jazz Club
			Jazz Guitar Club
			Slow Jazz Ballad
			Instrumental Jazz
			Swing Medium
			Fast Jazz
			Trad Piano Jazz
Acoustic Jazz			
Trad Piano Ballad			
Cool Piano Jazz			
French Jazz			
Modern Jazz Bld 1			
Organ Combo			
Modern Jazz Bld 2			
Piano Boogie			
Jazz Club			
Bebop			
Boogie Woogie			
Piano Swing 1			
Piano Swing 2			
Jazz Ballad			
2Beat Swing			
Big Band			Big Band Jazz
			Orch Big Band 1
			Modern Big Band
			Orch Big Band 2
			Mod Big Band Shfl
			Big Band Fast 1
		Mod Big Band Bld	
		Big Band Fast 2	
		Classic Big Band	
		Afro Cuban	
		Jump Jive	
		40s Big Band	
Moonlight Ballad			
Orchestra Swing		Easy Swing	
		Orchestra Swing 1	
		MOR Swing	
		Orchestra Swing 2	
		Easy Listening	
	Cool Jazz Ballad		

Category	Sub Category	Style Name	
Standards & Jazz	Orchestra Swing	Midnight Swing	
		Organ Groove	
	Jazz Waltz	Cool Jazz Waltz	
		Easy Waltz	
		Jazz Waltz Slow	
		MOR Waltz	
		Jazz Waltz Medium	
		Five-Four	
		Jazz Waltz Fast 1	
		Jazz Waltz	
		Jazz Waltz Fast 2	
		Dixie&Trad Jazz	Ragtime 1
			Piano Rag 1
			Ragtime 2
			Piano Rag 2
	Dixieland 1		
	Stride 1		
	Dixieland 2		
	Stride 2		
	Charleston		
	Saloon Piano		
	Fusion	Jazz Pop	
		Fusion Shuffle	
	Entertainment	Movie&Show	Movie Soundtrack
			Mod Broadway Bld
			Broadway Ballad
			On Broadway
			Movie Swing 1
			Cartoon Ballad
			Movie Swing 2
Animation Ballad			
Tap Dance Swing			
Sci-fi March			
70s TV Theme			
Blockbuster			
Big Screen Classic			
Secret Service			
Movie Ballad			
Wild West			
Showtune			
Choir Soundtrack			
Animation Fantasy			
Musical			
Easy Listening			Classic Piano Bld
			Easy Ballad
			Romantic Ballad
			Guitar Serenade
			Romantic Waltz
			Piano Orch Ballad
			6-8 Slow Rock
			6-8 Orchestral
		12-8 Ballad	
		Tijuana	
		French 50s	
		Pub Piano	
Pop Classics			
Ballroom		Viennese Waltz	
		Quickstep	
		English Waltz	
		Tango	
		Slow Waltz	
		Pasodoble	
		Slowfox	
	Samba		
Foxtrot			


Category	Sub Category	Style Name	
Entertainment	Ballroom	Rumba	
		Cha Cha Cha	
		Standard Waltz	
		Jive	
		Standard Rumba	
		Swingfox	
		Piano Rumba	
		Beguine	
		Piano Cha Cha	
		Twist	
		Piano Beguine	
		Swing Waltz	
		9-8 Waltz	
		Organ	Euro Pop Organ
			Organ Bossa
			Organ Samba
	Organ Cha Cha		
	Organ Swing		
	Organ Quickstep		
	Organ Rumba		
	Organ Rumba		
	Holiday	Christmas Swing	
		Christmas Ballad	
		Christmas Shuffle	
		Christmas Waltz	
	Schlager	Schlager Fever	
		Schlager Palace	
		Party Arena	
		Mallorca Party	
		Apres Ski Hit	
		Alpen Schlager	
		Disco Fox	
		Soft Schlager	
		German Rock	
		Schlager Fox	
		Schlager Italia	
		Schlager Shuffle	
		70s French Hit	
		Schlager Waltz	
		Alp Ballad 1	
Schlager Pop			
Alp Ballad 2			
Schlager Beat			
Schlager Samba			
Schlager Alp			
Schlager Polka			
Schlager Rumba			
Schlager Rock			
Schlager 6-8			
Scand Bugg			
Scand Shuffle			
Scand Slow Rock			
Party Polka			
8Beat Adria			
Polka Pop			
Scand Country 1			
Scand Country 2			
Latin&World	Brazil	Brazilian Bossa	
		Cool Bossa	
		Bossa Slow	
		Bossa Fast	
		Slow Bar Bossa	
		Samba Fast	
		Orchestral Bossa	
		Brazilian Samba	
		Bossa Nova	

CVP-705

Category	Sub Category	Style Name	
Latin&World	Brazil	Piano Samba	
		Piano Bossa	
	Cuba	Rumba Bolero	
		Salsa	
		Guajira	
		Danzon	
		Guitar Rumba	
		Cuban Son	
		Mexico	Mariachi Waltz
		Norteno	
		Bolero Lento	
	Caribbean	Sheriff Reggae	
		Merengue	
		Happy Reggae	
		Cumbia	
		Bomba	
		Bachata	
		Zouk	
		Rumba Island	
		European	Flamenco
			Sirtaki
	Pop Flamenco		
	Tarantella		
	Spanish Paso		
	Italian Mazurka		
	Rumba Flamenco		
	Latin Pop	Latin Party Pop	
		Pop Bossa	
		Pop Latin	
		Pop Latin Ballad	
		Latin Disco	
	Celtic	Rock Cha Cha	
		Jig	
		Celtic Dance	
		Reel	
		Irish Dance	
	World	Irish Hymn 1	
		Irish Hymn 2	
		Turkish Euro	
		J-Pop Hit 1	
		Oriental Pop	
	Classic	J-Pop Hit 2	
		Hawaiian	
		Choral Symphony	
		Ethereal Hymn	
		Romantic Ballet	
		Ethereal Voices	
		Green Fantasia	
		Baroque Air	
		String Adagio	
		Moonlight 6-8	
		Nocturne	
		Learning 2-4	
		Orchestral March	
		Orchestral Bolero	
		Traditional 1	
		Arpeggio 1	
		Traditional 2	
		Arpeggio 2	
		Traditional 3	
		Arpeggio 3	
	Trad Waltz	Highland Waltz	
		Scand Waltz	
		French Waltz	
		Ober Walzer	

Category	Sub Category	Style Name
Latin&World	Trad Waltz	Italian Waltz
		German Waltz
		French Musette
		Bohemian Waltz
		Waltz
		Piano Slow Waltz
		March&Polka
	Ober Polka	
	German March	
	Italian Polka	
	6-8 March	
	Zither Polka	
	Piano March 1	
	Piano March 2	
	4 Stroke	
	6-8 Piano March	

Chord Types Recognized in the Fingered Mode / Im Fingered-Modus erkannte Akkordarten / Types d'accords reconnus en mode Fingered / Tipos de acordes reconocidos en el modo Fingered (digitado) / Tipos de acorde reconhecidos no modo dedilhado



Chord Name [Abbreviation]	Normal Voicing	Display for root "C"
1+8	1+8	C1+8
1+5	1+5	C1+5
Major [M]	1+3+5	C
Sixth [6]	1+(3)+5+6	C6
Major seventh [M7]	1+3+(5)+7	CM7
Major seventh flatted fifth [M7 ♭5]	1+3+ ♭5+7	CM7(♭5)
Major seventh add sharp eleventh [M7(# 11)]	1+(2)+3+ # 4+5+7	CM7(# 11)
Add ninth [(add9)]	1+2+3+5	Cadd9
Major seventh ninth [M7_9]	1+2+3+(5)+7	CM7(9)
Sixth ninth [6_9]	1+2+3+(5)+6	C6(9)
Flatted fifth [(♭5)]	1+3+ ♭5	C ♭5
Augmented [aug]	1+3+ #5	Caug
Seventh augmented [7aug]	1+3+ #5+ ♭7	C7aug
Major seventh augmented [M7aug]	1+(3)+ #5+7	CM7aug
Minor [m]	1+ ♭3+5	Cm
Minor sixth [m6]	1+ ♭3+5+6	Cm6
Minor seventh [m7]	1+ ♭3+(5)+ ♭7	Cm7
Minor seventh flatted fifth [m7 ♭5]	1+ ♭3+ ♭5+ ♭7	Cm7(♭5)
Minor add ninth [m(add9)]	1+2+ ♭3+5	Cm add9
Minor seventh ninth [m7(9)]	1+2+ ♭3+(5)+ ♭7	Cm7(9)
Minor seventh eleventh [m7(11)]	1+(2)+ ♭3+4+5+(♭7)	Cm7(11)
Minor major seventh flatted fifth [mM7 ♭5]	1+ ♭3+ ♭5+7	CmM7(♭5)
Minor major seventh [mM7]	1+ ♭3+(5)+7	CmM7
Minor major seventh ninth [mM7(9)]	1+2+ ♭3+(5)+7	CmM7(9)
Diminished [dim]	1+ ♭3+ ♭5	Cdim
Diminished seventh [dim7]	1+ ♭3+ ♭5+6	Cdim7
Seventh [7]	1+3+(5)+ ♭7	C7
Seventh suspended fourth [7sus4]	1+4+5+ ♭7	C7sus4
Seventh ninth [7(9)]	1+2+3+(5)+ ♭7	C7(9)
Seventh add sharp eleventh [7(# 11)]	1+(2)+3+ # 4+5+ ♭7	C7(# 11)
Seventh add thirteenth [7(13)]	1+3+(5)+6+ ♭7	C7(13)
Seventh flatted fifth [7 ♭5]	1+3+ ♭5+ ♭7	C7(♭5)
Seventh flatted ninth [7(♭9)]	1+ ♭2+3+(5)+ ♭7	C7(♭9)
Seventh add flatted thirteenth [7(♭13)]	1+3+5+ ♭6+ ♭7	C7(♭13)
Seventh sharp ninth [7(#9)]	1+ #2+3+(5)+ ♭7	C7(#9)
Suspended fourth [sus4]	1+4+5	Csus4
One plus two plus five [sus2]	1+2+5	Csus2
cancel	1+ ♭2+2	Cancel

* Notes in parentheses can be omitted.

Effect Type List / Liste der Effekttypen / Liste des types d'effet / Lista de tipos de efecto / Lista de tipos de efeito

Reverb Block

Category	Type Name	Description	MSB	LSB
Reverb	Real Large Hall	Real reverb simulating the acoustics of a large sized hall.	1	32
	Real Medium Hall	Real reverb simulating the acoustics of a medium sized hall.	1	33
	Real Bright Hall	Real reverb simulating the acoustics of a bright sounding hall.	1	34
	Basic Hall	Reverb simulating the acoustics of a hall. Standard setting.	1	21
	Light Hall	Reverb simulating the acoustics of a hall. Light setting.	1	22
	Ballad Hall	Reverb simulating the acoustics of a hall. For ballad type music.	1	19
	Piano Hall	Reverb simulating the acoustics of a hall. For piano sound.	1	20
	Hall 1	Reverb simulating the acoustics of a hall.	1	0
	Hall 2		1	16
	Hall 3		1	17
	Hall 4		1	18
	Hall 5		1	1
	Vocal Hall 1	Reverb suitable for vocals.	1	27
	Vocal Hall 2		1	28
	Piano Recital Hall	Reverb simulating the acoustics of a medium sized recital hall. For piano sound.	1	24
	Piano Concert Hall	Reverb simulating the acoustics of a large sized hall. For piano sound.	1	4
	Piano Cathedral	Reverb simulating the acoustics of a cathedral. For piano sound.	1	5
	Real Room	Real reverb simulating the acoustics of a room.	2	32
	Real Power Room	Real reverb simulating the acoustics of a room with powerful room reflections.	2	33
	Acoustic Room	Reverb simulating the acoustics of a room. Standard setting.	2	20
	Drums Room	Reverb simulating the acoustics of a room. For drum sounds.	2	21
	Piano Chamber	Reverb simulating the acoustics of a chamber. For piano sound.	2	24
	Stage	Reverb suitable for a solo instrument.	3	16
	Piano Club	Reverb simulating the acoustics of a club. For piano sound.	3	24
	Real Large Plate	Real reverb simulating a large plate reverb unit.	4	32
	Real Medium Plate	Real reverb simulating a medium sized plate reverb unit.	4	33
	Real Rattle Plate	Real reverb simulating a plate reverb unit with spring rattle.	4	34
	Plate	Reverb simulating a plate reverb unit.	4	16
	Piano Plate	Reverb simulating a plate reverb unit. For piano sound.	4	24
	Hall M	Reverb simulating the acoustics of a hall.	1	6
	Hall L		1	7
	Atmosphere Hall	A unique long reverb with atmosphere.	1	23
	Large Hall	Reverb simulating the acoustics of a hall.	1	2
	Medium Hall		1	3
	Percussion Room	Reverb simulating the acoustics of a room. For percussion sounds.	2	22
	Room 1	Reverb simulating the acoustics of a room.	2	16
	Room 2		2	17
	Room 3		2	18
	Room 4		2	19
	Room 5		2	0
	Room 6		2	1
	Room 7		2	2
	Room S		2	5
	Room M		2	6
	Room L		2	7
	Warm Room		Reverb simulating the acoustics of a warm room.	2
	White Room	A unique short reverb with a bit of initial delay.	16	0
	Woody Room	Reverb simulating the acoustics of a wood-built room.	2	4
	Stage 2	Reverb suitable for a solo instrument.	3	17
	Stage 3		3	0
	Stage 4		3	1
	Plate 2	Reverb simulating a plate reverb unit.	4	17
	Plate 3		4	0
	GM Plate		4	7
	Rich Plate	Reverb simulating a rich plate reverb unit.	4	1
	Tunnel	Simulates a cylindrical space expanding to left and right.	17	0
	Canyon	A hypothetical acoustic space which extends without limit.	18	0
Basement	A bit of initial delay followed by reverb with a unique resonance.	19	0	
---	No Effect	No effect.	0	0

Chorus Block

Category	Type Name	Description	MSB	LSB
Reverb	Hall 1	Reverb simulating the acoustics of a hall.	1	0
	Hall 2		1	16
	Hall 3		1	17
	Hall 4		1	18
	Hall 5		1	1
	Acoustic Room	Reverb simulating the acoustics of a room. Standard setting.	2	20
	Drums Room	Reverb simulating the acoustics of a room. For drum sounds.	2	21
	Stage	Reverb suitable for a solo instrument.	3	16
	Plate	Reverb simulating a plate reverb unit.	4	16
Delay	Tempo Delay 1	Tempo-synchronized delay.	21	0
	Tempo Delay 2		21	16
	Tempo Echo	Tempo-synchronized echo.	21	8
	Tempo Cross 1	Tempo-synchronized cross delay.	22	0
	Tempo Cross 2		22	16
	Tempo Cross 3		22	17
	Tempo Cross 4		22	18
Modulation	Chorus 1	Conventional chorus program with rich, warm chorusing.	66	17
	Chorus 2		66	8
	Symphonic	Adds more stages to the modulation of Celeste.	68	16
	Flanger	Creates a sound similar to that of a jet airplane.	67	8
	Tempo Flanger	Tempo-synchronized flanger.	107	0
	Phaser	Cyclically modulates the phase to add modulation to the sound.	72	0
	Tempo Phaser	Tempo-synchronized phaser.	108	0
	E-Piano Phaser	Cyclically modulates the phase to add modulation to the sound. For electric piano.	72	17
	Dual Rotary Speaker Bright	Simulates a rotary speaker.	99	16
	Dual Rotary Speaker Warm		99	17
	Rotary Speaker		69	16
	Tremolo	Rich Tremolo effect with both volume and pitch modulation.	70	16
	E-Piano Tremolo		70	18
	Tempo Tremolo	Tempo-synchronized rich Tremolo effect with both volume and pitch modulation.	120	0
	Auto Pan	Several panning effects that automatically shift the sound position (left, right, front, back).	71	16
Tempo Auto Pan	Tempo-synchronized auto pan.	121	0	
Legacy	Hall M	Reverb simulating the acoustics of a hall.	1	6
	Hall L		1	7
	Atmosphere Hall	A unique long reverb with atmosphere.	1	23
	Percussion Room	Reverb simulating the acoustics of a room. For percussion sounds.	2	22
	Room 1	Reverb simulating the acoustics of a room.	2	16
	Room 2		2	17
	Room 3		2	18
	Room 4		2	19
	Room 5		2	0
	Room 6		2	1
	Room 7		2	2
	Room S		2	5
	Room M		2	6
	Room L		2	7
	Stage 2		Reverb suitable for a solo instrument.	3
	Stage 3	3		0
	Stage 4	3		1
	Plate 2	Reverb simulating a plate reverb unit.	4	17
	Plate 3		4	0
	GM Plate		4	7
	Karaoke 1	Echo for karaoke.	20	0
	Karaoke 2		20	1
	Karaoke 3		20	2
	Early Reflection 1	This effect isolates only the early reflection components of the reverb.	9	0
	Early Reflection 2		9	1
	Chorus 3	Conventional chorus program with rich, warm chorusing.	66	16
	Chorus 4		66	1
	Chorus 5		65	2
	Chorus 6		65	0
	Chorus 7		65	1
	Chorus 8		65	8

Chorus Block

Category	Type Name	Description	MSB	LSB	
Legacy	Chorus Fast	Conventional chorus program with rich, warm chorusing.	65	16	
	Chorus Lite		65	17	
	GM Chorus 1		65	3	
	GM Chorus 2		65	4	
	GM Chorus 3		65	5	
	GM Chorus 4		65	6	
	Feedback Chorus		65	7	
	Celeste 1	A 3-phase LFO adds modulation and spaciousness to the sound.	66	0	
	Celeste 2		66	2	
	Symphonic 2	Adds more stages to the modulation of Celeste.	68	0	
	Ensemble Detune 1	Chorus effect without modulation, created by adding a slightly pitch-shifted sound.	87	0	
	Ensemble Detune 2		87	16	
	Flanger 2	Creates a sound similar to that of a jet airplane.	67	16	
	Flanger 3		67	17	
	Flanger 4		67	1	
	Flanger 5		67	0	
	GM Flanger		67	7	
	Phaser 2		Cyclically modulates the phase to add modulation to the sound.	72	8
	Phaser 3	72		19	
	Tempo Phaser 2	Tempo-synchronized phaser.	108	16	
	E-Piano Phaser 2	Cyclically modulates the phase to add modulation to the sound. For electric piano.	72	18	
	E-Piano Phaser 3		72	16	
	Dual Rotary Speaker 1	Simulates a rotary speaker.	99	0	
	Dual Rotary Speaker 2		99	1	
	Rotary Speaker 2		71	17	
	Rotary Speaker 3		71	18	
	Rotary Speaker 4		70	17	
	Rotary Speaker 5		66	18	
	Rotary Speaker 6		69	0	
	Rotary Speaker 7		71	22	
	2way Rotary Speaker	86	0		
	Tremolo 2	Rich Tremolo effect with both volume and pitch modulation.	71	19	
	Tremolo 3		70	0	
	Guitar Tremolo 1		71	20	
	Guitar Tremolo 2		70	19	
	Vibraphone Rotor	Vibraphone effect.	119	0	
	Auto Pan 2	Several panning effects that automatically shift the sound position (left, right, front, back).	71	0	
	Auto Pan 3		71	1	
	E-Piano Auto Pan		71	21	
	Tempo Auto Pan 2	Tempo-synchronized auto pan.	121	1	
	Pitch Change 1	Changes the pitch of the input signal.	80	16	
	Pitch Change 2		80	0	
	Pitch Change 3		80	1	
	---	No Effect	No effect.	0	0

Effect Block

CVP-709	CVP-705	XG Block Name
●	●	XG Variation Block
●	●	XG Insertion1 Block
●	●	XG Insertion2 Block
●	●	XG Insertion3 Block
●		XG Insertion4 Block
●		XG Insertion5 Block
●		XG Insertion6 Block (only for MIC & Song)
●		XG Insertion7 Block (only for Style)
●		XG Insertion8 Block (only for Style)

Category	Type Name	Description	MSB	LSB
Reverb	Hall 1	Reverb simulating the acoustics of a hall.	1	0
	Hall 2		1	16
	Hall 3		1	17
	Hall 4		1	18
	Hall 5		1	1
	Acoustic Room	Reverb simulating the acoustics of a room. Standard setting.	2	20
	Drums Room	Reverb simulating the acoustics of a room. For drum sounds.	2	21
	Stage	Reverb suitable for a solo instrument.	3	16
	Plate	Reverb simulating a plate reverb unit.	4	16
Delay	Delay LCR 1	Produces three delayed sounds: L, R and C (center).	5	16
	Delay LCR 2		5	0
	Delay LR	Produces two delayed sounds: L and R. Two feedback delays are provided.	6	0
	Echo	Two delayed sounds (L and R), and independent feedback delays for L and R.	7	0
	Cross Delay 1	The feedback of the two delayed sounds is crossed.	8	0
	Cross Delay 2		8	16
	Tempo Delay 1	Tempo-synchronized delay.	21	0
	Tempo Delay 2		21	16
	Tempo Echo	Tempo-synchronized echo.	21	8
	Tempo Cross 1	Tempo-synchronized cross delay.	22	0
	Tempo Cross 2		22	16
	Tempo Cross 3		22	17
	Tempo Cross 4		22	18
Distortion	US Combo Twin	American combo amp simulator. Setting for typical sound.	99	32
	US Combo Rich Clean	American combo amp simulator. Setting for rich clean sound.	99	33
	US Combo Thin Clean	American combo amp simulator. Setting for thin clean sound.	99	34
	US Combo Crunch	American combo amp simulator. Setting for crunch sound.	99	35
	Jazz Combo Basic	Jazz combo amp simulator. Setting for basic sound.	100	32
	Jazz Combo Warm Chorus	Jazz combo amp simulator. Setting for warm chorus sound.	100	33
	US High Gain Dirty	American high gain amp simulator. Setting for dirty sound.	101	32
	US High Gain Riff	American high gain amp simulator. Setting for guitar riffs.	101	33
	US High Gain Burn	American high gain amp simulator. Setting for burn sound.	101	34
	US High Gain Solo	American high gain amp simulator. Setting for guitar solos.	101	35
	British Lead Dirty	British stack amp simulator. Setting for dirty sound.	102	32
	British Lead Drive	British stack amp simulator. Setting for overdrive sound.	102	33
	British Lead Gainer	British stack amp simulator. Setting for gainer sound.	102	34
	British Lead Hard	British stack amp simulator. Setting for hard sound.	102	35
	Multi FX Distortion Solo	Multi effector for guitar. Setting for guitar solo.	95	32
	Multi FX Distortion Basic	Multi effector for guitar. Setting for basic distortion.	95	33
	Multi FX Overdrive Chorus	Multi effector for guitar. Setting for overdrive & chorus.	95	34
	Multi FX Crunch Wah	Multi effector for guitar. Setting for crunch & wah.	95	35
	Multi FX Oldies Delay	Multi effector for guitar. Setting for vintage delay.	95	36
	Multi FX Vintage Echo	Multi effector for guitar. Setting for vintage echo.	95	37
	Small Stereo Distortion	Stereo distortion for guitar. Setting for distortion sound.	96	32
	Small Stereo Overdrive	Stereo distortion for guitar. Setting for overdrive sound.	96	33
	Small Stereo Vintage Amp	Stereo distortion for guitar. Setting for vintage sound.	96	34
	Small Stereo Heavy Dist	Stereo distortion for guitar. Setting for heavy sound.	96	35
	British Combo Classic	British combo amp simulator. Setting for classic sound.	97	32
	British Combo Top Boost	British combo amp simulator. Setting for "TOP BOOST" sound.	97	33
	British Combo Custom	British combo amp simulator. Setting for custom sound.	97	34
	British Combo Heavy	British combo amp simulator. Setting for heavy sound.	97	35
	British Legend Blues	British stack amp simulator. Setting for blues sound.	98	32

Effect Block

Category	Type Name	Description	MSB	LSB
Distortion	British Legend Heavy1	British stack amp simulator. Setting for heavy sound 1.	98	33
	British Legend Heavy2	British stack amp simulator. Setting for heavy sound 2.	98	34
	British Legend Clean	British stack amp simulator. Setting for clean sound.	98	35
	British Legend Dirty Clean	British stack amp simulator. Setting for crunch sound.	98	36
	V Distortion Crunch	Distortion which simulates the sound of a vintage tube, fuzz effect, etc.	98	18
	V Distortion Blues		98	21
	Stereo Amp Sim Solid	Stereo amp simulator.	75	29
	Stereo Amp Sim Crunch		75	30
	Stereo Amp Sim Blues		75	28
V Distortion Hard + Delay	V Distortion Hard and Delay are connected in series.	98	1	
EQ & Comp	Vintage Compressor	This simulates an analog compressor, giving a vintage flavor to the sound.	124	4
	Compressor Medium	Compressor with medium setting.	83	16
	Compressor Heavy	Compressor with heavy setting.	83	17
	Compressor Melody	Compressor for the Melody part.	105	16
	Compressor Bass	Compressor for the Bass part.	105	17
	EQ Telephone	Equalizer effect that cuts both high and low frequencies, to simulate the sound heard through a telephone receiver.	76	17
	3Band EQ	A mono EQ with adjustable LOW, MID, and HIGH equalization.	76	0
	Loop FX 1	Degrades the audio quality of the input signal.	94	16
	Loop FX 2		94	17
	Lo-Fi Drum 1	Degrades the audio quality of the input signal. Ideal for drum sounds.	94	18
	Lo-Fi Drum 2		94	19
	Lo-Fi Drum 3		76	19
Lo-Fi Drum 4	76		20	
Modulation	Chorus 1	Conventional chorus program with rich, warm chorusing.	66	17
	Chorus 2		66	8
	Symphonic	Adds more stages to the modulation of Celeste.	68	16
	Vintage Flanger	This simulates an analog flanger, giving a strong vintage flavor to the sound.	124	1
	Flanger	Creates a sound similar to that of a jet airplane.	67	8
	V Flanger	A simulation of an analog flanger effect. The LFO has a random setting.	104	0
	Tempo Flanger	Tempo-synchronized flanger.	107	0
	Vintage Phaser	This simulates an analog phaser, giving a strong vintage flavor to the sound. It is effective in mono.	124	2
	Vintage Phaser Stereo	This simulates an analog phaser, giving a strong vintage flavor to the sound. It is effective in stereo.	124	3
	Phaser	Cyclically modulates the phase to add modulation to the sound.	72	0
	Tempo Phaser	Tempo-synchronized phaser.	108	0
	E-Piano Phaser	Cyclically modulates the phase to add modulation to the sound. For electric piano.	72	17
	Vintage Auto Wah	This simulates an analog wah pedal effect, giving a strong vintage flavor to the sound. It cyclically changes the central frequency of the wah filter.	124	5
	Auto Wah	Cyclically modulates the center frequency of a wah filter.	78	16
	Auto Wah + Distortion	Distortion can be applied to the output of Auto Wah.	78	17
	Tempo Auto Wah	Tempo-synchronized Auto Wah.	79	0
	Vintage Touch Wah	This simulates an analog wah pedal effect, giving a strong vintage flavor to the sound. It changes the central frequency of the wah filter according to the input level.	125	2
	Touch Wah	Changes the center frequency of a wah filter according to the input level.	82	0
	Touch Wah + Distortion	Distortion can be applied to the output of Touch Wah.	82	16
	Vintage Pedal Wah Basic	Vintage Wah which can be controlled by "Pedal Control" parameter. (See Effect Parameter List.)	125	1
	Vintage Pedal Wah Disco		125	16
	Pedal Wah	Changes the center frequency of a wah filter according to "Pedal Control" parameter. (See Effect Parameter List.)	122	0
	Pedal Wah + Distortion	Distortion can be applied to the output of Pedal Wah.	122	1
	Dual Rotary Speaker Bright	Simulates a rotary speaker.	99	16
	Dual Rotary Speaker Warm		99	17
	Rotary Speaker		69	16
	Tremolo	Rich Tremolo effect with both volume and pitch modulation.	70	16
	E-Piano Tremolo		70	18
	Tempo Tremolo	Tempo-synchronized rich Tremolo effect with both volume and pitch modulation.	120	0
	Auto Pan	Several panning effects that automatically shift the sound position (left, right, front, back).	71	16
	Tempo Auto Pan	Tempo-synchronized auto pan.	121	0
	Legacy	Hall M	Reverb simulating the acoustics of a hall.	1
Hall L		1		7
Atmosphere Hall		A unique long reverb with atmosphere.	1	23
Percussion Room		Reverb simulating the acoustics of a room. For percussion sounds.	2	22

Effect Block

Category	Type Name	Description	MSB	LSB	
Legacy	Room 1	Reverb simulating the acoustics of a room.	2	16	
	Room 2		2	17	
	Room 3		2	18	
	Room 4		2	19	
	Room 5		2	0	
	Room 6		2	1	
	Room 7		2	2	
	Room S		2	5	
	Room M		2	6	
	Room L		2	7	
	White Room		A unique short reverb with a bit of initial delay.	16	0
	Stage 2	Reverb suitable for a solo instrument.	3	17	
	Stage 3		3	0	
	Stage 4		3	1	
	Plate 2	Reverb simulating a plate reverb unit.	4	17	
	Plate 3		4	0	
	GM Plate		4	7	
	Tunnel	Simulates a cylindrical space expanding to left and right.	17	0	
	Canyon	A hypothetical acoustic space which extends without limit.	18	0	
	Basement	A bit of initial delay followed by reverb with a unique resonance.	19	0	
	Karaoke 1	Echo for karaoke.	20	0	
	Karaoke 2		20	1	
	Karaoke 3		20	2	
	Early Reflection 1	This effect isolates only the early reflection components of the reverb.	9	0	
	Early Reflection 2		9	1	
	Gate Reverb 1	Simulation of gated reverb.	10	0	
	Gate Reverb 2		10	16	
	Reverse Gate	Simulation of gated reverb played back in reverse.	11	0	
	V Distortion Warm	Distortion which simulates the sound of a vintage tube, fuzz effect, etc.	98	22	
	V Distortion Classic Hard		98	23	
	V Distortion Classic Soft		98	20	
	V Distortion Metal		98	24	
	V Distortion Edgy		98	19	
	V Distortion Solid		98	25	
	V Distortion Clean 1		98	17	
	V Distortion Clean 2		98	26	
	V Distortion Twin		98	16	
	V Distortion Rockabilly		103	18	
	V Distortion Jazz Clean		98	27	
	V Distortion Fusion		103	19	
	V Distortion Hard		98	0	
	V Distortion Soft		98	2	
	Stereo Amp Sim Clean		Stereo amp simulator.	75	27
	Stereo Amp Sim BluesHarp			75	31
	Distortion Hard 1	Hard-edge distortion.	75	16	
	Distortion Hard 2		75	22	
	Distortion Soft 1	Soft, warm distortion.	75	17	
	Distortion Soft 2		75	23	
	Distortion Heavy	Heavy distortion.	73	0	
	Overdrive	Adds mild distortion to the sound.	74	0	
	Stereo Distortion	Stereo distortion.	73	8	
	Stereo Overdrive	Stereo overdrive.	74	8	
Stereo Distortion Hard	Hard-edge stereo distortion.	75	18		
Stereo Distortion Soft	Soft, warm soft distortion.	75	19		
Amp Simulator 1	A simulation of a guitar amp.	75	0		
Amp Simulator 2		75	1		
Stereo Amp Simulator 1	Stereo amp simulator.	75	20		
Stereo Amp Simulator 2		75	21		
Stereo Amp Simulator 3		75	8		
Stereo Amp Simulator 4		75	24		
Stereo Amp Simulator 5		75	25		
Stereo Amp Simulator 6		75	26		

Effect Block

Category	Type Name	Description	MSB	LSB	
Legacy	Distortion + Delay 1	Distortion and Delay are connected in series.	95	16	
	Distortion + Delay 2		95	0	
	Overdrive + Delay 1	Overdrive and Delay are connected in series.	95	17	
	Overdrive + Delay 2		95	1	
	Comp + Dist + Delay 1	Compressor, Distortion and Delay are connected in series.	96	16	
	Comp + Dist + Delay 2		96	0	
	Comp + OD + Delay 1	Compressor, Overdrive and Delay are connected in series.	96	17	
	Comp + OD + Delay 2		96	1	
	V Distortion Soft + Delay	V Distortion Soft and Delay are connected in series.	98	3	
	V Dist Hard + Tmp Delay 1	V Distortion Hard and Tempo Delay are connected in series.	103	0	
	V Dist Hard + Tmp Delay 2		103	17	
	V Dist Soft + Tmp Delay 1	V Distortion Soft and Tempo Delay are connected in series.	103	1	
	V Dist Soft + Tmp Delay 2		103	16	
	Distortion + Tempo Delay	Distortion and Tempo Delay are connected in series.	100	0	
	Overdrive + Tempo Delay	Overdrive and Tempo Delay are connected in series.	100	1	
	Comp + Distortion 1	Since a Compressor is included in the first stage, steady distortion can be produced regardless of changes in input level.	73	16	
	Comp + Distortion 2		73	1	
	Comp + Dist + Tmp Delay	Compressor, Distortion and Tempo Delay are connected in series.	101	0	
	Comp + OD + Tmp Delay 1	Compressor, Overdrive and Tempo Delay are connected in series.	101	1	
	Comp + OD + Tmp Delay 2		101	16	
	Comp + OD + Tmp Delay 3		101	17	
	Comp + OD + Tmp Delay 4		101	18	
	Comp + OD + Tmp Delay 5		101	19	
	Comp + OD + Tmp Delay 6		101	20	
	Multiband Compressor		Multi-band compressor that allows you to adjust the compression effect for individual frequency bands.	105	0
	Compressor	Holds down the output level when a specified input level is exceeded. A sense of attack can also be added to the sound.	83	0	
	Noise Gate	Gates the input when the input signal falls below a specified level.	84	0	
	EQ Disco	Equalizer effect that boosts both high and low frequencies, as is typical in most disco music.	76	16	
	2Band EQ	A stereo EQ with adjustable LOW and HIGH. Ideal for drum Parts.	77	0	
	Stereo 3Band EQ	A stereo EQ with adjustable LOW, MID, and HIGH equalization.	76	18	
	Harmonic Enhancer 1	Adds new harmonics to the input signal to make the sound stand out.	81	16	
	Harmonic Enhancer 2		81	0	
	Isolator	Controls the level of a specified frequency band of the input signal.	115	0	
	Chorus 3	Conventional chorus program with rich, warm chorusing.	66	16	
	Chorus 4		66	1	
	Chorus 5		65	2	
	Chorus 6		65	0	
	Chorus 7		65	1	
	Chorus 8		65	8	
	Chorus Fast		65	16	
	Chorus Lite		65	17	
	GM Chorus 1		65	3	
	GM Chorus 2		65	4	
	GM Chorus 3		65	5	
	GM Chorus 4		65	6	
	Feedback Chorus		65	7	
	Celeste 1		A 3-phase LFO adds modulation and spaciousness to the sound.	66	0
	Celeste 2			66	2
	Symphonic 2		Adds more stages to the modulation of Celeste.	68	0
	Ensemble Detune 1		Chorus effect without modulation, created by adding a slightly pitch-shifted sound.	87	0
	Ensemble Detune 2	87		16	
	Ambience Chorus	Chorus which added early reflection sound.	65	9	
Ambience Celeste	Celeste which added early reflection sound.	66	9		
Ambience Symphonic	Symphonic which added early reflection sound.	68	9		
Vintage Flanger 2	This simulates an analog flanger, giving a strong vintage flavor to the sound.	124	16		
Flanger 2	Creates a sound similar to that of a jet airplane.	67	16		
Flanger 3		67	17		
Flanger 4		67	1		
Flanger 5		67	0		
GM Flanger		67	7		
Dynamic Flanger		Dynamically controlled flanger.	110	0	

Effect Block

Category	Type Name	Description	MSB	LSB
Legacy	Ambience Flanger	Flanger which added early reflection sound.	67	9
	Vintage Phaser 2	This simulates an analog phaser, giving a strong vintage flavor to the sound. It is effective in mono.	124	17
	Vintage Phaser Stereo 2	This simulates an analog phaser, giving a strong vintage flavor to the sound. It is effective in stereo.	124	18
	Vintage Phaser Stereo 3		124	19
	Vintage Phaser Stereo 4		124	20
	Phaser 2		72	8
	Phaser 3	Cyclically modulates the phase to add modulation to the sound.	72	19
	Tempo Phaser 2	Tempo-synchronized phaser.	108	16
	E-Piano Phaser 2	Cyclically modulates the phase to add modulation to the sound. For electric piano.	72	18
	E-Piano Phaser 3		72	16
	Dynamic Phaser	Dynamically controlled phaser.	111	0
	Auto Wah 2	Cyclically modulates the center frequency of a wah filter.	78	0
	Auto Wah + Distortion 2	Distortion can be applied to the output of Auto Wah.	78	1
	Auto Wah + Dist Hard		78	21
	Auto Wah + Dist Heavy		78	23
	Auto Wah + Dist Lite		78	25
	Auto Wah + Overdrive 1	Overdrive distortion can be applied to the output of Auto Wah.	78	18
	Auto Wah + Overdrive 2		78	2
	Auto Wah + OD Hard		78	22
	Auto Wah + OD Heavy		78	24
	Auto Wah + OD Lite		78	26
	Tmp AutoWah + Dist	Tempo-synchronized Auto Wah. Distortion can be applied to the output.	79	1
	Tmp AutoWah + Dist Hard		79	21
	Tmp AutoWah + Dist Heavy		79	23
	Tmp AutoWah + Dist Lite		79	25
	Tmp AutoWah + OD	Tempo-synchronized Auto Wah. Overdrive distortion can be applied to the output.	79	2
	Tmp AutoWah + OD Hard		79	22
	Tmp AutoWah + OD Heavy		79	24
	Tmp AutoWah + OD Lite		79	26
	Touch Wah 2	Changes the center frequency of a wah filter according to the input level.	82	8
	Touch Wah 3		82	20
	Touch Wah + Distortion 2	Distortion can be applied to the output of Touch Wah.	82	1
	Touch Wah + Dist Hard		82	21
	Touch Wah + Dist Heavy		82	23
	Touch Wah + Dist Lite		82	25
	Touch Wah + Overdrive 1	Overdrive distortion can be applied to the output of Touch Wah.	82	17
	Touch Wah + Overdrive 2		82	2
	Touch Wah + OD Hard		82	22
	Touch Wah + OD Heavy		82	24
	Touch Wah + OD Lite		82	26
	Wah + Dist + Delay 1	Wah, Distortion and Delay are connected in series.	97	16
	Wah + Dist + Delay 2		97	0
	Wah + Dist + Tmp Delay	Wah, Distortion and Tempo Delay are connected in series.	102	0
	Wah + Overdrive + Delay 1	Wah, Overdrive and Delay are connected in series.	97	17
	Wah + Overdrive + Delay 2		97	1
	Wah + OD + Tmp Delay 1	Wah, Overdrive and Tempo Delay are connected in series.	102	1
	Wah + OD + Tmp Delay 2		102	16
	Clavi Touch Wah	Clavinet Touch Wah	82	18
	EP Touch Wah	EP Touch Wah	82	19
	Pedal Wah + Dist Hard	Distortion can be applied to the output of Pedal Wah.	122	21
	Pedal Wah + Dist Heavy		122	23
	Pedal Wah + Dist Lite		122	25
	Pedal Wah + Overdrive	Overdrive distortion can be applied to the output of Pedal Wah.	122	2
	Pedal Wah + OD Hard		122	22
Pedal Wah + OD Heavy	122		24	
Pedal Wah + OD Lite	122		26	
Dual Rotary Speaker 1	Simulates a rotary speaker.	99	0	
Dual Rotary Speaker 2		99	1	
Rotary Speaker 2		71	17	
Rotary Speaker 3		71	18	
Rotary Speaker 4		70	17	
Rotary Speaker 5		66	18	

Category	Type Name	Description	MSB	LSB	
Legacy	Rotary Speaker 6	Simulates a rotary speaker.	69	0	
	Rotary Speaker 7		71	22	
	2way Rotary Speaker		86	0	
	Dist + Rotary SP	Distortion and rotary speaker connected in series.	69	1	
	Dist + 2way Rotary SP	Distortion and 2-way rotary speaker connected in series.	86	1	
	OD + Rotary SP	Overdrive and rotary speaker connected in series.	69	2	
	OD + 2way Rotary SP	Overdrive and 2-way rotary speaker connected in series.	86	2	
	Amp Sim + Rotary SP	Amp simulator and rotary speaker connected in series.	69	3	
	Amp Sim + 2way Rotary SP	Amp simulator and 2-way rotary speaker connected in series.	86	3	
	Tremolo 2	Rich Tremolo effect with both volume and pitch modulation.	71	19	
	Tremolo 3		70	0	
	Guitar Tremolo 1		71	20	
	Guitar Tremolo 2		70	19	
	Vibraphone Rotor	Vibraphone effect.	119	0	
	Auto Pan 2	Several panning effects that automatically shift the sound position (left, right, front, back).	71	0	
	Auto Pan 3		71	1	
	E-Piano Auto Pan		71	21	
	Tempo Auto Pan 2	Tempo-synchronized auto pan.	121	1	
	Pitch Change 1	Changes the pitch of the input signal.	80	16	
	Pitch Change 2		80	0	
	Pitch Change 3		80	1	
	Voice Cancel	Attenuates the vocal part of a CD or other source.	85	0	
	Ambience	Blurs the stereo positioning of the sound to add spatial width.	88	0	
	Talking Modulation	Adds a vowel sound to the input signal.	93	0	
	Lo-Fi	Degrades the audio quality of the input signal.	94	0	
	Dynamic Filter	Dynamically controlled filter.	109	0	
	Dynamic Ring Modulator	Dynamically controlled Ring Modulator.	112	0	
	Ring Modulator	An effect that modifies the pitch by applying amplitude modulation to the frequency of the input.	113	0	
	---	No Effect	No effect.	0	0
	---	Through	Bypass without applying an effect.	64	0

Vocal Harmony Type List / Liste der Vocal-Harmony-Typen / Liste des types d'harmonies vocales / Lista de tipos de armonías vocales / Lista de tipos de harmonia vocal

Type Name	MSB	LSB	Vocal Harmony	Vocal Effect	Description
StandardDuet	12	0	On	Off	Standard setting for lead vocal plus 1 harmony part. Useful for many music genres.
StandardTrio	12	1	On	Off	Standard setting for lead vocal plus 2 harmony parts. Useful for many music genres.
StandardQuartet	12	2	On	Off	Standard setting for lead vocal plus 3 harmony parts. Useful for many music genres.
StudioVocals	12	33	On	On	Good for studio productions with suitable EQ setting and less Reverb.
JazzyQuartet	12	3	On	Off	Good for Bass, Tenor and Alto singers; for Jazz repertoire. You will hear additional 6th notes.
SchlagerTrio	12	4	On	On	Good for standard Schlager repertoire with simple harmony chords.
Destiny'sPop	12	5	On	On	Good for female singers with lead vocal plus 2 harmony parts above; for female Pop and R&B repertoire.
VocalDoublor	12	34	Off	On	Use this preset to overdub your singing in real time. Turn the "Harmony" on the Vocal Harmony display on to add harmony parts with Vocal Doublor effect.
VocoderVH	12	6	On	Off	Standard vocoder setting; ideal for controlling with "UPPER" part.
VocoderMONO	12	7	On	Off	Standard vocoder setting; ideal for controlling with "UPPER" part. You can play mono (single-note) melodies.
Rock&Roll	12	35	Off	On	Good for Rock&Roll songs from the 50's and 60's with typical delay sound. Turn the "Harmony" on the Vocal Harmony display on to add harmony parts with Blues chords.
TempoCross	12	36	Off	On	Tempo Cross Delay on lead vocal. Turn the "Harmony" on the Vocal Harmony display on to add harmony parts; good for Pop songs or special show effects.
HeavyVoice	12	37	Off	On	Good for Rock and Pop with overdriven vocal. Turn the "Harmony" on the Vocal Harmony display on to add Harm.1 with 1 octave down.
TelephoneChoir	12	38	On	On	Typical Lo-Fi vocal ensemble; use as old fashioned ensemble sound or exciting effect in Rock, Pop and Jazz.
LikeThe80s	12	39	On	On	Good for 80's Pop with typical reverb image.
Gramophone	12	40	On	On	Typical 30's vocal ensemble; use as old fashioned gramophone sound.
PokerPhaser	12	41	On	On	Good for modern Pop songs using phaser effect for lead vocal.
DetuneVoice	12	8	On	Off	Lead vocal plus two additional detuned harmony parts for exciting detuned sound.
PerfectFourth	12	9	On	On	Quartet singing only perfect fourths; parallel movement of all parts.
SingCMajorScale	12	10	On	Off	Sing C major scale and the harmony parts will create suitable chord notes based on the C major scale. You can edit the key root and type by "Harmony Assign" setting  on the Vocal Harmony display.
BalladChoir	12	11	On	On	Good for Ballad backing vocals with long reverb.
ChurchChoir	12	12	On	On	Good for standard church songs and Christmas songs with long reverb; recommended for Bass, Tenor and Alto voice.
GregorianChoir	12	13	On	On	Good for rubato Gregorian-chant-type monophonic songs with large reverb; parallel movement of all parts.
GospelChoir	12	14	On	On	Good for Gospel songs with long reverb on harmony parts and minor 7th feel.
CosmicChoir	12	42	On	On	Extreme phasing vocals; useful for exciting effects in Dance and Modern Music.
AlpenGirls	12	15	On	On	Good for male singer with 2 female harmony parts above lead vocal.
CountryRock	12	16	On	On	Typical Country Rock quartet; recommended range is tenor/alto.
R&BDiva	12	17	On	On	Good for female alto singer for R&B repertoire; also usable with Tenor lead vocal.
ClosedPopChicks	12	18	On	On	Good for female singers with two harmony parts below. Change volume of Harm.3 for an additional (3rd) part below.
QueenOfPop	12	43	Off	On	Good for Pop and R&B songs using Tempo Delay. Turn the "Harmony" on the Vocal Harmony display on to add 2nd Voice.
Bob->Mary	12	19	On	On	Male singer can sound like Female voice with long romantic reverb. Use "Balance" on the Vocal Harmony display to add a male duet partner.
Mary->Bob	12	20	On	Off	Female singer can sound like Male voice with short reverb. Use "Balance" on the Vocal Harmony display to add a female duet partner.
FlangingVocals	12	44	Off	On	Useful for modern Pop, Rock and Dance music.
JazzySisters	12	21	On	On	Good for Bass and Tenor Singers. Harmony parts add 3 female Jazz singers.
QuartetOnStage	12	22	On	On	Good for Rock and Pop Music. Harmony parts make up a quartet.
DelayedHarmony	12	45	On	On	Useful in several genres with a tempo-synced delay choir as background.
KidsChoir	12	23	On	Off	Want to be a child again? Use this preset type and sing with your friends...
ChorusChoir	12	46	On	On	The chorus effect adds a rich and exciting characteristics to your voice and the harmony parts.
BohemianVocode	12	47	On	On	Tempo flanging Vocoder Type; good for Rock or Pop songs and Intros.
RobotVoice	12	48	On	On	Do you want to sound like a robot? This is the setting. Use Harm.3 for variation.
ChordalXG	90	0	On	Off	CHORDAL type setting of previous Vocal Harmony system.
DetuneXG	91	0	On	Off	DETUNE type setting of previous Vocal Harmony system.
ChromaticXG	92	0	On	Off	CHROMATIC type setting of previous Vocal Harmony system.
VocoderXG	89	0	On	Off	VOCODER type setting of previous Vocal Harmony system.
Thru	64	0	Off	Off	Bypass without any harmonies and effects.

Vocal Effect Type List / Liste der Gesangseffekt-Typen / Liste des types d'effets vocaux / Lista de tipos de efectos vocales / Lista de tipos de efeito vocal

Type Name	Description	MSB	LSB
Romantic Rev (Romantic Reverb)	Long reverb for vocal part. Romantic image.	1	0
80s Pop Rev (80s'Pop Reverb)	Long reverb for vocal part. 80's pop image.	1	16
Room	Reverb simulating the acoustics of a room.	2	0
Stage (Concert Stage)	Reverb simulating the concert stage.	3	0
Plate	Reverb simulating a plate reverb unit.	4	0
VocalDoubler	Immediate delay with center focused feeling.	5	16
StereoSpread	Immediate delay with spread feeling.	5	17
Delay	Produces simple delayed sounds: L, R, and C (center).	5	0
Short Delay	Produces short delayed sound with narrow image.	5	1
R&R Delay (Rock&Roll Delay)	Produces slap back echo sound. Good for Rock&Roll music.	5	18
Cross Delay	The feedback of the two delayed sounds is crossed.	8	0
Tempo Delay	Tempo-synchronized delay.	21	0
Tempo Cross (Tempo Cross Delay)	Tempo-synchronized cross delay.	22	0
Chorus	Conventional chorus program with rich, warm chorusing.	66	0
EQ Hi-Fi	Equalizer effect that boosts both high and low frequencies.	76	16
EQ Tel	Equalizer effect that cuts both high and low frequencies.	76	0
Gramophone	Produces Lo-Fi sound with gramophone image.	94	0
Robot	Produces Lo-Fi sound with robotic image.	94	16
Overdriven	Produces overdriven sound. Good for rock and dance music.	98	0
Scream&Shout	Produces heavy distorted sound.	98	16
TempoFlanger	Tempo-synchronized flanger.	107	0
TempoPhaser	Tempo-synchronized phaser.	108	0
TempoAutoPan	Tempo-synchronized auto pan.	121	0
No Effect	No effect.	0	0

Parameter Chart / Parametertabelle / Tableau des paramètres / Gráfico de parâmetros / Gráfico de parâmetro

Parameter	CVP -705	CVP -709	Backup/Restore				Voice Set	Voice Set Group	Song		Style		Registration		Parameter Lock Group
			System	MIDI	User Effect	Music Finder			Song	Song Setup Group	Style Data	OTS	Regist	Freeze Group	
Home															
Voice (Left)	○	○	×	×	×	×	○	–	○	Keyboard Voice	×	○	○	Style	–
Voice (Main)	○	○	×	×	×	×	○	–	○	Keyboard Voice	×	○	○	Voice	–
Voice (Layer)	○	○	×	×	×	×	○	–	○	Keyboard Voice	×	○	○	Voice	–
Part On/Off (Main)	○	○	×	×	×	×	×	–	○	Keyboard Voice	×	○	○	Voice	–
Part On/Off (Layer)	○	○	×	×	×	×	×	–	○	Keyboard Voice	×	○	○	Voice	–
Part On/Off (Left)	○	○	×	×	×	×	×	–	○	Keyboard Voice	×	○	○	Style	–
Song (MIDI/Audio)	○	○	×	×	×	×	×	–	×	–	×	×	○	Song	–
Registration Area Show/Hide	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Style	○	○	×	×	×	×	×	–	×	–	×	×	○	Style	–
Home (MIDI Song)															
Extra On/Off	○	○	×	×	×	×	×	–	×	–	×	×	○	Song	–
Left On/Off	○	○	×	×	×	×	×	–	○	Guide Setting	×	×	○	Song	–
Right On/Off	○	○	×	×	×	×	×	–	○	Guide Setting	×	×	○	Song	–
Channels Show/Hide on Song Recording Window	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Home (Audio Song)															
Pitch Shift	○	○	×	×	×	×	×	–	×	–	×	×	○	Song	–
Time Stretch	○	○	×	×	×	×	×	–	×	–	×	×	○	Song	–
Vocal Cancel	○	○	×	×	×	×	×	–	×	–	×	×	○	Song	–
Style Control															
ACMP On/Off	○	○	×	×	×	×	×	–	×	–	×	○ (On)	○	Style	–
Auto Fill In	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Section	○	○	×	×	×	×	×	–	×	–	×	×	○	Style	–
Sync Start	○	○	×	×	×	×	×	–	×	–	×	○ (On)	○	Style	–
Sync Stop	○	○	×	×	×	×	×	–	×	–	×	×	○	Style	–
Transpose															
Transpose	○	○	×	×	×	×	×	–	×	–	×	×	○	Transpose	–
Tempo															
Master Tempo	○	○	×	×	×	×	×	–	○	Tempo	○	×	○	Tempo	–
Song															
Syncho Start	○	○	×	×	×	×	×	–	×	–	×	×	○	Song	–
Channel On/Off	○	○	×	×	×	×	×	–	×	–	×	×	○	Song	–
Registration															
Regist Memory Contents	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Items to Register Show/Hide on Registration Memory Window	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Regist Contents Name	○	○	×	×	×	×	×	–	×	–	×	×	○	–	–
One Touch Setting															
OTS Link	○	○	×	×	×	○ (On)	×	–	×	–	×	×	×	–	–
Menu															
Short Cut	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Split Point & Fingering															
Split Point (Left)	○	○	○	×	×	×	×	–	×	–	×	×	○	Style	Split Point
Split Point (Style)	○	○	○	×	×	×	×	–	○	Guide Setting	×	×	○	Style	Split Point
Fingering Type	○	○	○	×	×	×	×	–	×	–	×	×	○	Style	Fingering Type
Chord Detection Area	○	○	○	×	×	×	×	–	○	Guide Setting	×	×	○	Style	–
Manual Bass	○	○	○	×	×	×	×	–	○	Guide Setting	×	×	○	Style	–
Transpose															
Master Transpose	○	○	×	×	×	×	×	–	×	–	×	×	○	Transpose	–
Song Transpose	○	○	×	×	×	×	×	–	×	–	×	×	○	Transpose	–
Keyboard Transpose	○	○	×	×	×	×	×	–	×	–	×	×	○	Transpose	–
Transpose Assign	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Balance															
Offset Volume Style	○	○	×	×	×	×	×	–	×	–	×	×	○	Style	–
Volume Left	○	○	×	×	×	×	×	–	○	Keyboard Voice	×	○	○	Style	–
Volume Main	○	○	×	×	×	×	×	–	○	Keyboard Voice	×	○	○	Voice	–
Volume Layer	○	○	×	×	×	×	×	–	○	Keyboard Voice	×	○	○	Voice	–
Volume Mic	○	○	×	×	×	×	×	–	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting

Parameter	CVP-705	CVP-709	Backup/Restore				Voice Set	Voice Set Group	Song		Style		Registration		Parameter Lock Group
			System	MIDI	User Effect	Music Finder			Song	Song Setup Group	Style Data	OTS	Regist	Freeze Group	
Offset Volume Song	○	○	×	×	×	×	×	–	×	–	×	×	○	Song	–
Aux In Volume	○	○	×	×	×	×	×	–	×	–	×	×	×	–	–
WLAN Volume	○	○	×	×	×	×	×	–	×	–	×	×	×	–	–
Piano Room															
Voice	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Style	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Style Part On/Off	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Detail Setting															
Environment	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Lid Position	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Tune	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Dynamics Control	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Section Control	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Fingering Type	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Split Point	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Piano Lock	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Score															
View Setting															
Size	○	○	○	×	×	×	×	–	○	Score Setting	×	×	×	–	–
Left On/Off	○	○	○	×	×	×	×	–	○	Score Setting	×	×	×	–	–
Right On/Off	○	○	○	×	×	×	×	–	○	Score Setting	×	×	×	–	–
Chord On/Off	○	○	○	×	×	×	×	–	○	Score Setting	×	×	×	–	–
Lyrics On/Off	○	○	○	×	×	×	×	–	○	Score Setting	×	×	×	–	–
Pedal On/Off	○	○	○	×	×	×	×	–	○	Score Setting	×	×	×	–	–
Note On/Off	○	○	○	×	×	×	×	–	○	Score Setting	×	×	×	–	–
Fingering On/Off	○	○	○	×	×	×	×	–	○	Score Setting	×	×	×	–	–
Color On/Off	○	○	○	×	×	×	×	–	○	Score Setting	×	×	×	–	–
Detail Setting															
Right Ch	○	○	○	×	×	×	×	–	○	Score Setting	×	×	×	–	–
Left Ch	○	○	○	×	×	×	×	–	○	Score Setting	×	×	×	–	–
Key Signature	○	○	×	×	×	×	×	–	○	Score Setting	×	×	×	–	–
Quantize	○	○	○	×	×	×	×	–	○	Score Setting	×	×	×	–	–
Note Name	○	○	○	×	×	×	×	–	○	Score Setting	×	×	×	–	–
Lyrics															
Background (*1)	○	○	○	×	×	×	×	–	○	Lyrics Setting	×	×	×	–	–
Text Viewer															
Text File	○	○	×	×	×	×	×	–	×	–	×	×	○	Text	–
Mixer															
Panel															
Filter															
Harmonic Content (Left)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Style	–
Harmonic Content (Main)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	–
Harmonic Content (Layer)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	–
Brightness (Left)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Style	–
Brightness (Main)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	–
Brightness (Layer)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	–
EQ															
High Gain (Style) Offset	○	○	×	×	×	×	×	–	×	–	×	×	○	Style	–
High Gain (Left)	○	○	×	×	×	×	○	EQ	○	Keyboard Voice	×	○	○	Style	–
High Gain (Main)	○	○	×	×	×	×	○	EQ	○	Keyboard Voice	×	○	○	Voice	–
High Gain (Layer)	○	○	×	×	×	×	○	EQ	○	Keyboard Voice	×	○	○	Voice	–
High Gain (Song) Offset	○	○	×	×	×	×	×	–	×	–	×	×	×	–	–
Low Gain (Style) Offset	○	○	×	×	×	×	×	–	×	–	×	×	○	Style	–
Low Gain (Left)	○	○	×	×	×	×	○	EQ	○	Keyboard Voice	×	○	○	Style	–
Low Gain (Main)	○	○	×	×	×	×	○	EQ	○	Keyboard Voice	×	○	○	Voice	–
Low Gain (Layer)	○	○	×	×	×	×	○	EQ	○	Keyboard Voice	×	○	○	Voice	–
Low Gain (Song) Offset	○	○	×	×	×	×	×	–	×	–	×	×	×	–	–

Parameter	CVP -705	CVP -709	Backup/Restore				Voice Set	Voice Set Group	Song		Style		Registration		Parameter Lock Group
			System	MIDI	User Effect	Music Finder			Song	Song Setup Group	Style Data	OTS	Regist	Freeze Group	
Effect															
Insertion Effect Depth (Left)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Style	–
Insertion Effect Depth (Main)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Voice	–
Insertion Effect Depth (Layer)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Voice	–
Insertion Effect Depth (Mic)	○	○	×	×	×	×	×	–	○	Vocal Harmony/Mic Setting	×	×	○	Vocal Harmony/Mic Setting	Vocal Harmony/Mic Setting
Chorus/Reverb															
Reverb Depth (Style) Offset	○	○	×	×	×	×	×	–	×	–	×	×	○	Style	–
Reverb Depth (Left)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Style	–
Reverb Depth (Main)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Voice	–
Reverb Depth (Layer)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Voice	–
Reverb Depth (Mic)	○	○	×	×	×	×	×	–	○	Vocal Harmony/Mic Setting	×	×	○	Vocal Harmony/Mic Setting	Vocal Harmony/Mic Setting
Reverb Depth (Song) Offset	○	○	×	×	×	×	×	–	×	–	×	×	×	–	–
Chorus Depth (Style) Offset	○	○	×	×	×	×	×	–	×	–	×	×	○	Style	–
Chorus Depth (Left)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Style	–
Chorus Depth (Main)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Voice	–
Chorus Depth (Layer)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Voice	–
Chorus Depth (Mic)	○	○	×	×	×	×	×	–	○	Vocal Harmony/Mic Setting	×	×	○	Vocal Harmony/Mic Setting	Vocal Harmony/Mic Setting
Chorus Depth (Song) Offset	○	○	×	×	×	×	×	–	×	–	×	×	×	–	–
Pan/Volume															
Pan (Style) Offset	○	○	×	×	×	×	×	–	×	–	×	×	○	Style	–
Pan (Left)	○	○	×	×	×	×	×	–	○	Keyboard Voice	×	○	○	Style	–
Pan (Main)	○	○	×	×	×	×	×	–	○	Keyboard Voice	×	○	○	Voice	–
Pan (Layer)	○	○	×	×	×	×	×	–	○	Keyboard Voice	×	○	○	Voice	–
Pan (Mic)	○	○	×	×	×	×	×	–	○	Vocal Harmony/Mic Setting	×	×	○	Vocal Harmony/Mic Setting	Vocal Harmony/Mic Setting
Pan (Song) Offset	○	○	×	×	×	×	×	–	×	–	×	×	×	–	–
Volume (Style) Offset	○	○	×	×	×	×	×	–	×	–	×	×	○	Style	–
Volume (Left)	○	○	×	×	×	×	×	–	○	Keyboard Voice	×	○	○	Style	–
Volume (Main)	○	○	×	×	×	×	×	–	○	Keyboard Voice	×	○	○	Voice	–
Volume (Layer)	○	○	×	×	×	×	×	–	○	Keyboard Voice	×	○	○	Voice	–
Volume (Mic)	○	○	×	×	×	×	×	–	○	Vocal Harmony/Mic Setting	×	×	○	Vocal Harmony/Mic Setting	Vocal Harmony/Mic Setting
Volume (Song) Offset	○	○	×	×	×	×	×	–	×	–	×	×	○	Song	–
Style															
Filter															
Harmonic Content	○	○	×	×	×	×	×	–	×	–	○	×	○	Style	–
Brightness	○	○	×	×	×	×	×	–	×	–	○	×	○	Style	–
EQ															
Low Gain	○	○	×	×	×	×	×	–	×	–	○	×	○	Style	–
High Gain	○	○	×	×	×	×	×	–	×	–	○	×	○	Style	–
Effect															
Insertion Effect Depth	○	○	×	×	×	×	×	–	×	–	○	×	○	Style	–
Chorus/Reverb															
Reverb Depth	○	○	×	×	×	×	×	–	×	–	○	×	○	Style	–
Chorus Depth	○	○	×	×	×	×	×	–	×	–	○	×	○	Style	–
Pan/Volume															
Pan	○	○	×	×	×	×	×	–	×	–	○	×	○	Style	–
Volume	○	○	×	×	×	×	×	–	×	–	○	×	○	Style	–
Song Ch 1-8															
Song Ch 9-16															
Filter															
Harmonic Content Song Part	○	○	×	×	×	×	×	–	○	Filter	×	×	×	–	–
Brightness Song Part	○	○	×	×	×	×	×	–	○	Filter	×	×	×	–	–
EQ															
EQ Low Gain Song Part	○	○	×	×	×	×	×	–	○	EQ	×	×	×	–	–
EQ High Gain Song Part	○	○	×	×	×	×	×	–	○	EQ	×	×	×	–	–
Effect															
Insertion Effect Depth Song Part	○	○	×	×	×	×	×	–	○	Effect	×	×	×	–	–

Parameter	CVP -705	CVP -709	Backup/Restore				Voice Set	Voice Set Group	Song		Style		Registration		Parameter Lock Group
			System	MIDI	User Effect	Music Finder			Song	Song Setup Group	Style Data	OTS	Regist	Freeze Group	
Chorus/Reverb															
Reverb Depth Song Part	○	○	×	×	×	×	×	–	○	Effect	×	×	×	–	–
Chorus Depth Song Part	○	○	×	×	×	×	×	–	○	Effect	×	×	×	–	–
Pan/Volume															
Part Volume Song	○	○	×	×	×	×	×	–	○	Volume	×	×	×	–	–
Part Pan Song	○	○	×	×	×	×	×	–	○	Pan	×	×	×	–	–
Master															
Compressor															
On/Off	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Type	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Threshold Offset	○	○	×	×	○	×	×	–	×	–	×	×	×	–	–
Ratio Offset	○	○	×	×	○	×	×	–	×	–	×	×	×	–	–
Output Offset	○	○	×	×	○	×	×	–	×	–	×	×	×	–	–
EQ															
Type	○	○	○	×	×	×	×	–	×	–	×	×	×	–	Master EQ
Parameter	○	○	×	×	○	×	×	–	×	–	×	×	×	–	Master EQ
Channel On/Off															
Channel On/Off (Song)	○	○	×	×	×	×	×	–	×	–	×	×	○	Song	–
Channel On/Off (Style)	○	○	×	×	×	×	×	–	×	–	○	×	○	Style	–
Voice															
Voice (Style)	○	○	×	×	×	×	×	–	×	–	○	×	○	Style	–
Voice (Song)	○	○	×	×	×	×	×	–	○	Voice	×	×	×	–	–
Reverb															
Type	○	○	×	×	×	×	×	–	○	Effect	○	×	○	Style/Song	Reverb Type
Return Level	○	○	×	×	×	×	×	–	○	Effect	○	×	○	Style/Song	Reverb Return Level
Chorus															
Type	○	○	×	×	×	×	×	–	○	Effect	○	×	○	Style/Song	–
Return Level	○	○	×	×	×	×	×	–	○	Effect	○	×	○	Style/Song	Chorus Return Level
Assign Detail Setting															
Variation Effect Type	○	○	×	×	×	×	×	–	○	Effect	○	×	○	Style/Song	–
Variation Effect Return Level	○	○	×	×	×	×	×	–	○	Effect	○	×	○	Style/Song	Variation Effect (System) Return Level
Insertion Effect 1 Type	○	○	×	×	×	×	×	–	○	Effect	×	×	○	Voice/Style/Song	–
Insertion Effect 2 Type	○	○	×	×	×	×	×	–	○	Effect	×	×	○	Voice/Style/Song	–
Insertion Effect 3 Type	○		×	×	×	×	×	–	○	Effect/ Vocal Harmony/ Mic Setting	×	×	○	Voice/Style/ Song/ Mic Setting	Vocal Harmony/ Mic Setting
Insertion Effect 3 Type		○	×	×	×	×	×	–	○	Effect	×	×	○	Voice/Style/Song	–
Insertion Effect 4 Type		○	×	×	×	×	×	–	○	Effect	×	×	○	Voice/Style/Song	–
Insertion Effect 5 Type		○	×	×	×	×	×	–	○	Effect	×	×	○	Voice/Style/Song	–
Insertion Effect 6 Type		○	×	×	×	×	×	–	○	Effect/ Vocal Harmony/ Mic Setting	×	×	○	Style/Song/ Mic Setting	Vocal Harmony/ Mic Setting
Insertion Effect 7 Type		○	×	×	×	×	×	–	×	–	×	×	○	Style	–
Insertion Effect 8 Type		○	×	×	×	×	×	–	×	–	×	×	○	Style	–
Effect Parameter (Reverb/Chorus/Variation)	○	○	×	×	○	×	×	–	○	Effect	×	×	×	–	–
Effect Parameter (Insertion 1-2)	○		×	×	○	×	×	–	○	Effect	×	×	○	Voice/Style/Song	–
Effect Parameter (Insertion 3)	○		×	×	○	×	×	–	○	Effect/ Vocal Harmony/ Mic Setting	×	×	○	Voice/Style/ Song/ Mic Setting	Vocal Harmony/ Mic Setting
Effect Parameter (Insertion 1-5)		○	×	×	○	×	×	–	○	Effect	×	×	○	Voice/Style/Song	–
Effect Parameter (Insertion 6)		○	×	×	○	×	×	–	○	Effect/ Vocal Harmony/ Mic Setting	×	×	○	Song/ Mic Setting	Vocal Harmony/ Mic Setting
Effect Parameter (Insertion 7-8)		○	×	×	○	×	×	–	×	–	×	×	×	–	–
Music Finder															
Sort By	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Sort Order	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Search Keyword	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Record	○	○	×	×	×	○	×	–	×	–	×	×	×	–	–

Parameter	CVP-705	CVP-709	Backup/Restore				Voice Set	Voice Set Group	Song		Style		Registration		Parameter Lock Group
			System	MIDI	User Effect	Music Finder			Song	Song Setup Group	Style Data	OTS	Regist	Freeze Group	
Keyboard Harmony															
Harmony/Echo	○	○	×	×	×	×	×	—	○	Keyboard Voice	×	○	○	Harmony	—
Type	○	○	×	×	×	×	○	Keyboard Harmony	○	Keyboard Voice	×	○	○	Harmony	—
Volume	○	○	×	×	×	×	○	Keyboard Harmony	○	Keyboard Voice	×	○	○	Harmony	—
Speed	○	○	×	×	×	×	○	Keyboard Harmony	○	Keyboard Voice	×	○	○	Harmony	—
Assign	○	○	×	×	×	×	○	Keyboard Harmony	○	Keyboard Voice	×	○	○	Harmony	—
Chord Note Only	○	○	×	×	×	×	○	Keyboard Harmony	○	Keyboard Voice	×	○	○	Harmony	—
Minimum Velocity	○	○	×	×	×	×	○	Keyboard Harmony	○	Keyboard Voice	×	○	○	Harmony	—
Mic Setting															
EQ Low Frequency	○	○	×	×	○	×	×	—	×	—	×	×	×	—	—
EQ Low Gain	○	○	×	×	○	×	×	—	×	—	×	×	×	—	—
EQ Mid Frequency	○	○	×	×	○	×	×	—	×	—	×	×	×	—	—
EQ Mid Gain	○	○	×	×	○	×	×	—	×	—	×	×	×	—	—
EQ High Frequency	○	○	×	×	○	×	×	—	×	—	×	×	×	—	—
EQ High Gain	○	○	×	×	○	×	×	—	×	—	×	×	×	—	—
Noise Gate On/Off	○	○	×	×	○	×	×	—	×	—	×	×	×	—	—
Noise Gate Threshold	○	○	×	×	○	×	×	—	×	—	×	×	×	—	—
Compressor On/Off	○	○	×	×	○	×	×	—	×	—	×	×	×	—	—
Compressor Threshold	○	○	×	×	○	×	×	—	×	—	×	×	×	—	—
Compressor Ratio	○	○	×	×	○	×	×	—	×	—	×	×	×	—	—
Compressor Out	○	○	×	×	○	×	×	—	×	—	×	×	×	—	—
Pitch Detect Vocal Type	○	○	×	×	○	×	×	—	×	—	×	×	×	—	—
Pitch Detect Background Noise Cut	○	○	×	×	○	×	×	—	×	—	×	×	×	—	—
Pitch Detect Speed	○	○	×	×	○	×	×	—	×	—	×	×	×	—	—
User Setting	○	○	○	×	○	×	×	—	×	—	×	×	×	—	—
Mic Volume	○	○	×	×	×	×	×	—	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Talk Setting															
Talk Setting Volume	○	○	×	×	○	×	×	—	×	—	×	×	×	—	—
Talk Setting Pan	○	○	×	×	○	×	×	—	×	—	×	×	×	—	—
Talk Setting Reverb Depth	○	○	×	×	○	×	×	—	×	—	×	×	×	—	—
Talk Setting Chorus Depth	○	○	×	×	○	×	×	—	×	—	×	×	×	—	—
Talk Setting Reduction Level	○	○	×	×	○	×	×	—	×	—	×	×	×	—	—
Talk EQ Low Frequency	○	○	×	×	○	×	×	—	×	—	×	×	×	—	—
Talk EQ Low Gain	○	○	×	×	○	×	×	—	×	—	×	×	×	—	—
Talk EQ Mid Frequency	○	○	×	×	○	×	×	—	×	—	×	×	×	—	—
Talk EQ Mid Gain	○	○	×	×	○	×	×	—	×	—	×	×	×	—	—
Talk EQ High Frequency	○	○	×	×	○	×	×	—	×	—	×	×	×	—	—
Talk EQ High Gain	○	○	×	×	○	×	×	—	×	—	×	×	×	—	—
Talk Noise Gate On/Off	○	○	×	×	○	×	×	—	×	—	×	×	×	—	—
Talk Noise Gate Threshold	○	○	×	×	○	×	×	—	×	—	×	×	×	—	—
Talk Compressor On/Off	○	○	×	×	○	×	×	—	×	—	×	×	×	—	—
Talk Compressor Threshold	○	○	×	×	○	×	×	—	×	—	×	×	×	—	—
Talk Compressor Ratio	○	○	×	×	○	×	×	—	×	—	×	×	×	—	—
Talk Compressor Out	○	○	×	×	○	×	×	—	×	—	×	×	×	—	—
Vocal Harmony															
On/Off	○	○	×	×	○	×	×	—	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Type	○	○	×	×	×	×	×	—	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Mode	○	○	×	×	×	×	×	—	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Song Channel	○	○	×	×	×	×	×	—	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Keyboard	○	○	×	×	×	×	×	—	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Song Channel Mute/Play	○	○	×	×	×	×	×	—	×	—	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting

Parameter	CVP -705	CVP -709	Backup/Restore				Voice Set	Voice Set Group	Song		Style		Registration		Parameter Lock Group
			System	MIDI	User Effect	Music Finder			Song	Song Setup Group	Style Data	OTS	Regist	Freeze Group	
Balance	○	○	×	×	○	×	×	–	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Chord Source	○	○	×	×	×	×	×	–	×	–	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Chordal Type	○	○	×	×	○	×	×	–	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Effect On/Off	○	○	×	×	○	×	×	–	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Effect Type	○	○	×	×	○	×	×	–	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Effect Depth To Lead	○	○	×	×	○	×	×	–	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Effect Depth To Harmony	○	○	×	×	○	×	×	–	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Reverb Depth	○	○	×	×	○	×	×	–	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Chorus Depth	○	○	×	×	○	×	×	–	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Harmony Edit															
Transpose Mode	○	○	×	×	○	×	×	–	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Pitch Correct	○	○	×	×	○	×	×	–	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Session Table	○	○	×	×	○	×	×	–	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Key Root	○	○	×	×	○	×	×	–	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Key Type	○	○	×	×	○	×	×	–	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Lead Pitch Detect Speed	○	○	×	×	○	×	×	–	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Harmony Pitch Detect Speed	○	○	×	×	○	×	×	–	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Harmony Effect	○	○	×	×	○	×	×	–	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Harmony Stability	○	○	×	×	○	×	×	–	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Lead Vibrato Depth	○	○	×	×	○	×	×	–	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Harmony Vibrato Depth	○	○	×	×	○	×	×	–	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Vibrato Speed	○	○	×	×	○	×	×	–	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Vibrato Delay	○	○	×	×	○	×	×	–	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Part Mixer															
Lead Transpose	○	○	×	×	○	×	×	–	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Lead Detune	○	○	×	×	○	×	×	–	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Lead Formant	○	○	×	×	○	×	×	–	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Lead Volume	○	○	×	×	○	×	×	–	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Lead Pan	○	○	×	×	○	×	×	–	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Lead Octave	○	○	×	×	○	×	×	–	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Harmony 1 Transpose	○	○	×	×	○	×	×	–	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Harmony 1 Detune	○	○	×	×	○	×	×	–	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Harmony 1 Formant Shift	○	○	×	×	○	×	×	–	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Harmony 1 Volume	○	○	×	×	○	×	×	–	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Harmony 1 Pan	○	○	×	×	○	×	×	–	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Harmony 1 Degree	○	○	×	×	○	×	×	–	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting

Parameter	CVP -705	CVP -709	Backup/Restore				Voice Set	Voice Set Group	Song		Style		Registration		Parameter Lock Group
			System	MIDI	User Effect	Music Finder			Song	Song Setup Group	Style Data	OTS	Regist	Freeze Group	
Harmony 2 Transpose	○	○	×	×	○	×	×	–	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Harmony 2 Detune	○	○	×	×	○	×	×	–	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Harmony 2 Formant Shift	○	○	×	×	○	×	×	–	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Harmony 2 Volume	○	○	×	×	○	×	×	–	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Harmony 2 Pan	○	○	×	×	○	×	×	–	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Harmony 2 Degree	○	○	×	×	○	×	×	–	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Harmony 3 Transpose	○	○	×	×	○	×	×	–	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Harmony 3 Detune	○	○	×	×	○	×	×	–	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Harmony 3 Formant Shift	○	○	×	×	○	×	×	–	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Harmony 3 Volume	○	○	×	×	○	×	×	–	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Harmony 3 Pan	○	○	×	×	○	×	×	–	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Harmony 3 Degree	○	○	×	×	○	×	×	–	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Vocal Harmony Effect															
Parameters	○	○	×	×	○	×	×	–	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Voice Edit															
Common															
Volume (Main)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	–
Volume (Layer)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	–
Volume (Left)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Style	–
Touch Sense Depth (Main)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	–
Touch Sense Depth (Layer)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	–
Touch Sense Depth (Left)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Style	–
Touch Sense Offset (Main)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	–
Touch Sense Offset (Layer)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	–
Touch Sense Offset (Left)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Style	–
Part Octave (Main/Layer)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	–
Part Octave (Left)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Style	–
Sound															
Mono/Poly (Main)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	–
Mono/Poly (Layer)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	–
Mono/Poly (Left)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Style	–
EG Attack (Main)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	–
EG Attack (Layer)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	–
EG Attack (Left)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Style	–
EG Decay (Main)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	–
EG Decay (Layer)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	–
EG Decay (Left)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Style	–
EG Release (Main)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	–
EG Release (Layer)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	–
EG Release (Left)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Style	–
Vibrato Depth (Main)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	–
Vibrato Depth (Layer)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	–
Vibrato Depth (Left)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Style	–
Vibrato Speed (Main)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	–
Vibrato Speed (Layer)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	–
Vibrato Speed (Left)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Style	–
Vibrato Delay (Main)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	–
Vibrato Delay (Layer)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	–
Vibrato Delay (Left)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Style	–
Modulation Filter (Main)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	–
Modulation Filter (Layer)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	–
Modulation Filter (Left)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Style	–

Parameter	CVP-705	CVP-709	Backup/Restore				Voice Set	Voice Set Group	Song		Style		Registration		Parameter Lock Group
			System	MIDI	User Effect	Music Finder			Song	Song Setup Group	Style Data	OTS	Regist	Freeze Group	
Modulation Amplitude (Main)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	–
Modulation Amplitude (Layer)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	–
Modulation Amplitude (Left)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Style	–
Modulation LFO Pitch (Main)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	–
Modulation LFO Pitch (Layer)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	–
Modulation LFO Pitch (Left)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Style	–
Modulation LFO Filter (Main)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	–
Modulation LFO Filter (Layer)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	–
Modulation LFO Filter (Left)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Style	–
Modulation LFO Amplitude (Main)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	–
Modulation LFO Amplitude (Layer)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	–
Modulation LFO Amplitude (Left)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Style	–
Effect															
Insertion Effect On/Off (Main)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Voice	–
Insertion Effect Type (Main)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Voice	–
Insertion Effect On/Off (Layer)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Voice	–
Insertion Effect Type (Layer)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Voice	–
Insertion Effect On/Off (Left)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Voice	–
Insertion Effect Type (Left)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Voice	–
Insertion Effect Variation On/Off (Main)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Voice	–
Insertion Effect Variation Value (Main)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Voice	–
Insertion Effect Variation On/Off (Layer)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Voice	–
Insertion Effect Variation Value (Layer)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Voice	–
Insertion Effect Variation On/Off (Left)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Voice	–
Insertion Effect Variation Value (Left)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Style	–
Insertion Effect Type Parameter (Main)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Voice	–
Insertion Effect Type Parameter (Layer)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Voice	–
Insertion Effect Type Parameter (Left)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Voice	–
Vibe Rotor On/Off (Main)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Voice	–
Vibe Rotor On/Off (Layer)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Voice	–
Vibe Rotor On/Off (Left)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Style	–
EQ															
EQ Low Freq (Main)	○	○	×	×	×	×	○	EQ	○	Keyboard Voice	×	○	○	Voice	–
EQ Low Freq (Layer)	○	○	×	×	×	×	○	EQ	○	Keyboard Voice	×	○	○	Voice	–
EQ Low Freq (Left)	○	○	×	×	×	×	○	EQ	○	Keyboard Voice	×	○	○	Style	–
EQ High Freq (Main)	○	○	×	×	×	×	○	EQ	○	Keyboard Voice	×	○	○	Voice	–
EQ High Freq (Layer)	○	○	×	×	×	×	○	EQ	○	Keyboard Voice	×	○	○	Voice	–
EQ High Freq (Left)	○	○	×	×	×	×	○	EQ	○	Keyboard Voice	×	○	○	Style	–
Pedal															
Function Assign	○	○	×	×	×	×	○	Pedal	○	Keyboard Voice	×	○	○	Pedal	–
Detail Setting	○	○	×	×	×	×	○	Pedal	○	Keyboard Voice	×	○	○	Pedal	–
Organ Flute															
Footage (Main)	○	○	×	×	×	×	○	–	○	Keyboard Voice	×	○	○	Voice	–
Footage (Layer)	○	○	×	×	×	×	○	–	○	Keyboard Voice	×	○	○	Voice	–
Footage (Left)	○	○	×	×	×	×	○	–	○	Keyboard Voice	×	○	○	Style	–
Type (Main)	○	○	×	×	×	×	○	–	○	Keyboard Voice	×	○	○	Voice	–
Type (Layer)	○	○	×	×	×	×	○	–	○	Keyboard Voice	×	○	○	Voice	–
Type (Left)	○	○	×	×	×	×	○	–	○	Keyboard Voice	×	○	○	Style	–
Vibrato On/Off (Main)	○	○	×	×	×	×	○	–	○	Keyboard Voice	×	○	○	Voice	–
Vibrato On/Off (Layer)	○	○	×	×	×	×	○	–	○	Keyboard Voice	×	○	○	Voice	–
Vibrato On/Off (Left)	○	○	×	×	×	×	○	–	○	Keyboard Voice	×	○	○	Style	–
Vibrato Depth (Main)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	–
Vibrato Depth (Layer)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	–
Vibrato Depth (Left)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Style	–
Vibrato Speed (Main)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	–
Vibrato Speed (Layer)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	–
Vibrato Speed (Left)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Style	–
Attack Footage (Main)	○	○	×	×	×	×	○	–	○	Keyboard Voice	×	○	○	Voice	–
Attack Footage (Layer)	○	○	×	×	×	×	○	–	○	Keyboard Voice	×	○	○	Voice	–
Attack Footage (Left)	○	○	×	×	×	×	○	–	○	Keyboard Voice	×	○	○	Style	–

Parameter	CVP -705	CVP -709	Backup/Restore				Voice Set	Voice Set Group	Song		Style		Registration		Parameter Lock Group
			System	MIDI	User Effect	Music Finder			Song	Song Setup Group	Style Data	OTS	Regist	Freeze Group	
Attack Mode (Main)	○	○	×	×	×	×	○	–	○	Keyboard Voice	×	○	○	Voice	–
Attack Mode (Layer)	○	○	×	×	×	×	○	–	○	Keyboard Voice	×	○	○	Voice	–
Attack Mode (Left)	○	○	×	×	×	×	○	–	○	Keyboard Voice	×	○	○	Style	–
Attack Length (Main)	○	○	×	×	×	×	○	–	○	Keyboard Voice	×	○	○	Voice	–
Attack Length (Layer)	○	○	×	×	×	×	○	–	○	Keyboard Voice	×	○	○	Voice	–
Attack Length (Left)	○	○	×	×	×	×	○	–	○	Keyboard Voice	×	○	○	Style	–
Response (Main)	○	○	×	×	×	×	○	–	○	Keyboard Voice	×	○	○	Voice	–
Response (Layer)	○	○	×	×	×	×	○	–	○	Keyboard Voice	×	○	○	Voice	–
Response (Left)	○	○	×	×	×	×	○	–	○	Keyboard Voice	×	○	○	Style	–
Volume (Main)	○	○	×	×	×	×	○	–	○	Keyboard Voice	×	○	○	Voice	–
Volume (Layer)	○	○	×	×	×	×	○	–	○	Keyboard Voice	×	○	○	Voice	–
Volume (Left)	○	○	×	×	×	×	○	–	○	Keyboard Voice	×	○	○	Style	–
Style Creator															
Basic															
Pattern Length	○	○	×	×	×	×	×	–	×	–	○	×	×	–	–
Tempo	○	○	×	×	×	×	×	–	×	–	○	×	×	–	–
Beat	○	○	×	×	×	×	×	–	×	–	○	×	×	–	–
Rec Channel															
Step Edit															
Main Filter	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Control Change Filter	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
SFF Edit															
Play Root															
Play/Source Root	○	○	×	×	×	×	×	–	×	–	○	×	×	–	–
Play/Source Chord	○	○	×	×	×	×	×	–	×	–	○	×	×	–	–
NTR/NTT															
NTR	○	○	×	×	×	×	×	–	×	–	○	×	×	–	–
NTT	○	○	×	×	×	×	×	–	×	–	○	×	×	–	–
NTT Bass	○	○	×	×	×	×	×	–	×	–	○	×	×	–	–
High Key/Note Limit															
High Key	○	○	×	×	×	×	×	–	×	–	○	×	×	–	–
Note Limit Low	○	○	×	×	×	×	×	–	×	–	○	×	×	–	–
Note Limit High	○	○	×	×	×	×	×	–	×	–	○	×	×	–	–
RTR															
RTR	○	○	×	×	×	×	×	–	×	–	○	×	×	–	–
Song Creator															
Setup															
Setup Select	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Step Edit															
Main Filter	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Control Change Filter	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Style Filter	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Regist Sequence															
Regist Sequence Data	○	○	×	×	×	×	×	–	×	–	×	×	○	–	–
Regist Sequence On/Off	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Regist+ Pedal	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Regist- Pedal	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Sequence End	○	○	×	×	×	×	×	–	×	–	×	×	○	–	–
Voice Setting															
Tune															
Tuning Main	○	○	×	×	×	×	×	–	○	Keyboard Voice	×	○	○	Voice	–
Tuning Layer	○	○	×	×	×	×	×	–	○	Keyboard Voice	×	○	○	Voice	–
Tuning Left	○	○	×	×	×	×	×	–	○	Keyboard Voice	×	○	○	Style	–
Octave (Main)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	–
Octave (Layer)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	–
Octave (Left)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Style	–
Pitch Bend Range (Main)	○	○	×	×	×	×	×	–	○	Keyboard Voice	×	○	○	Voice	–
Pitch Bend Range (Layer)	○	○	×	×	×	×	×	–	○	Keyboard Voice	×	○	○	Voice	–
Pitch Bend Range (Left)	○	○	×	×	×	×	×	–	○	Keyboard Voice	×	○	○	Style	–

Parameter	CVP -705	CVP -709	Backup/Restore				Voice Set	Voice Set Group	Song		Style		Registration		Parameter Lock Group
			System	MIDI	User Effect	Music Finder			Song	Song Setup Group	Style Data	OTS	Regist	Freeze Group	
Portamento Time (Main)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	–
Portamento Time (Layer)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	–
Portamento Time (Left)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Style	–
Piano															
VRM On/Off	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Damper Resonance	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
String Resonance	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Reverb Depth	○	○	×	×	×	×	×	–	×	–	×	×	○	Voice	–
Chorus Depth	○	○	×	×	×	×	×	–	×	–	×	×	○	Voice	–
Tuning Curve	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Key Off Sampling	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Voice Set															
Voice Set On/Off (Main)	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Voice Set On/Off (Layer)	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Voice Set On/Off (Left)	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Setting															
Category Button	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
SA2 Auto Articulation		○	○	×	×	×	×	–	×	–	×	×	×	–	–
Style Setting															
Setting															
Dynamics Control	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Display Tempo	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Stop ACMP	○	○	○	×	×	×	×	–	×	–	×	×	○	Style	–
ACMP On/Off Default	○	○	○	×	×	×	×	–	×	–	×	×	○	Style	–
OTS Link Timing	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Synchro Stop Window	○	○	○	×	×	×	×	–	×	–	×	×	○	Style	–
Change Behavior															
Section Set	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Tempo	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Part On/Off	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Music Finder Style Tempo	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Song Setting															
Guide															
Type	○	○	○	×	×	×	×	–	○	Guide Setting	×	×	×	–	–
Lamp	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Lamp Timing	○	○	○	×	×	×	×	–	○	Guide Setting	×	×	×	–	–
Part Ch															
Right	○	○	○	×	×	×	×	–	○	–	×	×	×	–	–
Left	○	○	○	×	×	×	×	–	○	–	×	×	×	–	–
Auto Set	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Lyrics															
Language	○	○	○	×	×	×	×	–	○	Lyrics Setting	×	×	×	–	–
Play															
Repeat Mode	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Quick Start	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
MIDI Song Fast Forward Type	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
USB MIDI Song Auto Open	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Chord Detection Priority	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Rec															
Audio Rec Format	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Metronome															
Metronome															
Volume	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Sound	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Time Signature	○	○	×	×	×	×	×	–	○	–	○	×	×	–	–
Tap Tempo															
Volume	○	○	×	×	×	×	×	–	○	Keyboard Voice	×	○	○	Style	–
Sound	○	○	×	×	×	×	×	–	○	Keyboard Voice	×	○	○	Style	–

Parameter	CVP-705	CVP-709	Backup/Restore				Voice Set	Voice Set Group	Song		Style		Registration		Parameter Lock Group
			System	MIDI	User Effect	Music Finder			Song	Song Setup Group	Style Data	OTS	Regist	Freeze Group	
Tuning															
Master Tune															
Master Tune	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Scale Tune															
Scale Type	○	○	×	×	×	×	×	–	×	–	×	×	○	Scale	–
Base Note	○	○	×	×	×	×	×	–	×	–	×	×	○	Scale	–
Tune	○	○	×	×	×	×	×	–	×	–	×	×	○	Scale	–
Part Select	○	○	×	×	×	×	×	–	×	–	×	×	○	Scale	–
Keyboard															
Keyboard															
Touch Curve	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Fixed Velocity	○	○	×	×	×	×	×	–	×	–	×	×	○	Voice	–
Touch Response Part On/Off	○	○	×	×	×	×	×	–	×	–	×	×	○	Voice	–
Left Hold	○	○	×	×	×	×	×	–	○	Keyboard Voice	×	○	○	Style	–
Assignable															
Pedal															
Function Assign	○	○	×	×	×	×	○	Pedal	○	Keyboard Voice	×	○	○	Pedal	–
Detail Setting	○	○	×	×	×	×	○	Pedal	○	Keyboard Voice	×	○	○	Pedal	–
Depends On Main Voice	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
AUX Pedal Polarity	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Fade In Time	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Fade Out Time	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Fade Out Hold Time	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Assignable															
Function Assign	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Detail Setting	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Registration Freeze															
Setting	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
MIDI															
Setting	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Preset Setting Name	○	○	×	○	×	×	×	–	×	–	×	×	×	–	–
System															
Local Control	○	○	×	○	×	×	×	–	×	–	×	×	×	–	–
Clock	○	○	×	○	×	×	×	–	×	–	×	×	×	–	–
Transmit Clock	○	○	×	○	×	×	×	–	×	–	×	×	×	–	–
Transpose MIDI Input	○	○	×	○	×	×	×	–	×	–	×	×	×	–	–
Start/Stop	○	○	×	○	×	×	×	–	×	–	×	×	×	–	–
SysEx Transmit	○	○	×	○	×	×	×	–	×	–	×	×	×	–	–
SysEx Receive	○	○	×	○	×	×	×	–	×	–	×	×	×	–	–
Chord SysEx Transmit	○	○	×	○	×	×	×	–	×	–	×	×	×	–	–
Chord SysEx Receive	○	○	×	○	×	×	×	–	×	–	×	×	×	–	–
Transmit															
Ch	○	○	×	○	×	×	×	–	×	–	×	×	×	–	–
Filter	○	○	×	○	×	×	×	–	×	–	×	×	×	–	–
Receive															
Part	○	○	×	○	×	×	×	–	×	–	×	×	×	–	–
Filter	○	○	×	○	×	×	×	–	×	–	×	×	×	–	–
On Bass Note															
Bass (On Bass Note)	○	○	×	○	×	×	×	–	×	–	×	×	×	–	–
Chord Detect															
Chord Detect	○	○	×	○	×	×	×	–	×	–	×	×	×	–	–
Utility															
Speaker/Connectivity															
Speaker	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Stereophonic Optimizer	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
IAC	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
IAC Depth	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
AUX In Noise Gate	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Content (*1)	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–

Parameter	CVP -705	CVP -709	Backup/Restore				Voice Set	Voice Set Group	Song		Style		Registration		Parameter Lock Group
			System	MIDI	User Effect	Music Finder			Song	Song Setup Group	Style Data	OTS	Regist	Freeze Group	
Display															
Home Theme	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
LCD Brightness	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Time Stamp	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Pop-up Display Time	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Transition Effect	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Voice Area	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Touch Sound	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Parameter Lock															
Parameter Lock	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
System															
Language (*1)	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Owner Name (*1)	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Auto Power Off	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Voice Guide	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Voice Guide Controller	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Voice Guide Volume	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–

*1: Cannot be reset with Factory Reset.



ZN97450

Manual Development Department
© 2015 Yamaha Corporation

Published 04/2015 MWAP*.-**C0

ZN97450